

# FLAMING SKOUL


IMMERSE YOURSELF

**N70C** | **ACTIVE**  
NOISE CANCELLATION  
WIRELESS HEADPHONES

USER MANUAL


## FIRST TIME SETUP: BLUETOOTH PAIRING

- 1 Turn on the Bluetooth in your device settings.




- 2 Press and hold button for 5 seconds. Release. Lights will flash blue/red.

- 3 Select "Flaming Skull N70C" in your device Setting to connect.




Once successfully connected, the headphone will memorize your device and automatically pair when turned on in the future.



Power on 3S,  
Pairing 5S.

## BUTTON FUNCTIONS




**Connected To Bluetooth:** Press Once to Cycle Transparency / ANC On / ANC Off.  
Press Twice to Active "Spatial Audio"  
Press Triple to Active "Children Mode"

**Volume Down:** Press Once  
**Track Backward:** Press & Hold 1+ Seconds

**Power On / Off:** Press & Hold 3+ Seconds  
**Play / Pause / Answer / Hang Up Calls:** Press Once  
**Reject Incoming Call:** Press & Hold 1 Second  
**Activate Siri (iOS) Or "Ok Google" (Android):** Press Twice  
**Bluetooth Pairing:** See First Time Setup  
**Low latency Gaming mode:** Press Triple

**Volume Up:** Press Once  
**Track Forward:** Press & Hold 1+ Seconds

## CHARGING




**CHARGING CABLE**

Red light when charging, off when fully charged.  
White light when Noise Canceling / Transparency mode is on.

Connect to computer or USB 5V 1A (or less ) output device.

## Audio INPUT



**NOTE :**

- The TYPE-C INPUT will override your Bluetooth device connection. Unplug and press power button 3 + seconds to revert back to Bluetooth.
- Answer/hang up/reject of the button will not work when the audio input is connected.
- The volume will be dependent on your TYPE-C device settings, Adjust accordingly.

## Troubleshooting

- If the headphones are not working correctly, turn them on/off or hold "+" and "-" button at the same time for 5 seconds when headphones are on to reset.
- If the headphones won't turn on, recharge the battery and try again.
- If the headphones won't charge, make sure the power supply works, is 5V 1A, and not damaged.
- If the headphones make no sound or do not show as an available device, make sure they are not paired to a different device already.
- To re-enter pairing mode hold the power button for 5 seconds when headphones are off.

## Important Safety Information

- Avoid dropping.
- Do not disassemble.
- Do not submerge in water.
- The product should not be exposed to dripping or splashing.
- Avoid extreme temperatures.
- The product should not be exposed to excessive heat such as sunshine, fire or the like.
- Use original or certified cables.
- Clean with a dry, soft lint-free cloth. Do not use any corrosive cleaner or oil.
- Do not use the product outdoors during thunderstorms.

## Warning

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Notice

This product complies with the radio interference requirements of the European Community.

## CAUTION

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;  
Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;  
A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

## Hearing Safety

- To avoid hearing damage, do not listen for extended periods at high volume.
- Do not turn the volume so high that you're unable to hear your surroundings.
- Do not use headphones while driving.
- You should use caution or temporarily discontinue use in potentially hazardous situations.

## Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## CAUTION

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;  
Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;  
A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

## Important Safety Information

- Avoid dropping.
- Do not disassemble.
- Do not submerge in water.
- The product should not be exposed to dripping or splashing.
- Avoid extreme temperatures.
- The product should not be exposed to excessive heat such as sunshine, fire or the like.
- Use original or certified cables.
- Clean with a dry, soft lint-free cloth. Do not use any corrosive cleaner or oil.
- Do not use the product outdoors during thunderstorms.

## Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Notice

This product complies with the radio interference requirements of the European Community.

## CAUTION

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;  
Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;  
A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

## Important Safety Information

- Avoid dropping.
- Do not disassemble.
- Do not submerge in water.
- The product should not be exposed to dripping or splashing.
- Avoid extreme temperatures.
- The product should not be exposed to excessive heat such as sunshine, fire or the like.
- Use original or certified cables.
- Clean with a dry, soft lint-free cloth. Do not use any corrosive cleaner or oil.
- Do not use the product outdoors during thunderstorms.