

本书就基本的使用方法进行说明，有关于详细的使用方法，从下面开始请看“使用说明书”。

入 门

- ● 使用本产品前请务必阅读本书收到、阅读后，请妥善保管来修改标记元素的显示属性。
- ● 一般的智能手机屏幕和步骤记载着。根据您使用的机器和环境显示和步骤不同。使用机器请同时看说明书。

⚠ 注意

- ● 充电用外壳不是防水滴/耐汗。
- ● 当水附着在麦克风和扬声器上时，音质中所述修改相应参数的值。此时，干请用擦过的布擦拭或使其干燥。

确认包里的东西

耳机（左/右） X1



耳机软塞（S/M/L） X2

＊购买时，安装在耳机上。

充电器 X1



※ 耳机充电，USB AC适配器或USB

充电线 X1

说明书/保证书 X1

配对（连接）

①把左右的耳机放入充电用的盒子里

②再次取出左右耳机

※即使只使用一侧，第一次也按照这个顺序请配对。



自动进入配对模式。

🔊从右耳机*开始配对模式声音响起。

＊也有左（L）的情况。

③用对应机器进行配对操作

智能手机操作示例＞

※根据使用环境的不同，步骤和显示也不同。
※蓝牙设置屏幕上显示的耳机名称显示为“TW-HEART-02”或结尾的“R”/“L”时褪色为此颜色。

1.在主页画面中，点击[设定]

2.点击蓝牙



3.打开蓝牙



4.点击 TW-HEART-02



配对完成后，连接到对应机型的画面表示完成等，LED从红・白的闪烁变成白将条目添加到文档注册表。

🔊配对完成的声音响起。

4.点击 TW-HEART-02

5.如果显示配对请求消息点击[配对]

※有时也不会显示。


Bluetoothペアリングの要求
"Headset"がお使いのペアリングを求めています。
戻る
ペアリング

如下所示，配对完成。



第2次以后，左右两边的耳机都是充电用的取出后，自动与“R”或“L”冉连接的形式。另外，只取出其中一只耳机这样的话，可以作为单声道使用。

打电话

用多功能按钮操作。

通话	左(L)	右(R)
接电话	按其中一个	
通话结束/来电拒绝	长按其中一个	
接受中断通话*	1结束通话：长按其中一个 1通话保留：哪个按一次	

＊只能在签订中断通话服务合同时使用。

使用外音输入功能

在音乐播放中和待机中（连接中）用多功能按钮本机可以操作功能。

※ 只使用一侧时，不能使用本功能。
※本功能使用中，通话和Siri/语音控制器的启动时，本功能会自动关闭。
※使用本功能时，会发出微弱的“沙一”声。
※不是所有的外音都能听到。音乐的音量大的情况等，听不到外部声音进行调试。

XY-5216 6973D 产品UI

配对名：TW-HEART-02 芯片型号：6973D 按键开机 电源仓：5V开机

按键功能	实现状态	操 作	提示音	指示灯	备注
开机	关盖情况下	打开充电仓上盖，取出耳机	/	白灯亮2秒	
	耳机在充电仓外	长按功能键3秒	POWER ON	红蓝灯闪灯	
关机	耳机在充电仓外	耳机放入充电仓，关闭充电仓盖子	/	红灯长亮（充电）	
		长按功能键3秒	POWER OFF	红灯亮2秒	
		耳机无连接，5分钟自动关机	POWER OFF	红灯亮2秒	
配对（单耳）	开盖情况下	开机即进入配对状态	/		右耳灭灯，左耳红蓝双闪
TWS配对	关盖情况下	打开充电仓盖子，左右耳会自动组队回连，然后进入手机蓝牙界面搜索设备，选择TW-HEART-02进行配对连接	/	主机红蓝交替闪，副机无灯闪	左右耳第一次配对需要用配对盒子配对
开机回连手机	关盖情况下	打开充电仓盖子，如果左右耳之前组队过，左右耳首先会自动回连，连上之后会再连接手机	connected	无灯闪	
与手机断开连接	待机	关闭手机蓝牙或远距离断开	disconnected	主机红蓝交替闪，副机无灯闪	
	中英文提示音切换(默认英)	未连接状态下3击/连接状态下5击	/		
功能键	暂停/播放	单击右耳	/	无灯闪	左右耳单独使用，单击都为暂停/播放
	上一曲	双击左边耳机	/	无灯闪	单耳使用双击为下一曲
	下一曲	双击右边耳机	/	无灯闪	
	音量加	三击右边耳机	/	无灯闪	单耳使用长按为音量加
	音量减	三击右边耳机	/	无灯闪	
	电话进来	单击任意一边	/	无灯闪	
	通话中结束电话	长按任意一边1秒	/	无灯闪	
	开启Siri	长按任意一边2秒	/	无灯闪	
	开启/关闭通透	单击左耳	/	无灯闪	
低电报警	各种开机状态中	当电池电压低于3.3V	每隔20提示一次“滴”声	无灯闪	
低电关机	各种开机状态中	当电池电压低于3.1V时耳机将自动关机	/	无灯闪	
充电	各种开机状态中	放入充电仓关盖	/	充电中耳机红灯长亮，充满灯灭	
充电电流	30mA				

打开/关闭电源

打开电源

把耳机从充电罐中取出



切断电源

※确认收纳正确后再盖上盖子请关上。



*耳机开始充电了。

给手机充电

给充电用的充电罐充电

背面连接充电用电缆



※在收纳耳机的状态下你也可以同时给耳机充电。
※充电用外壳充满电后，指示灯熄灭。

给耳机充电

装在充电用外壳里



※耳机充满电后就熄灯。

重新连接/断开连接

重新连接

第2次以后，从充电用的电源上取耳机提交时会自动重新连接但重新连接否则，对应设备无以下操作。操作例：依次点击[设定]➞[蓝牙]浏览“TW-HEART-02”



断开连接

使用对应设备进行解除连接的操作。

操作例：依次点击[设定]➞[蓝牙]
关闭蓝牙



想删除注册信息（复位）

想删除登录在耳机中的机器的信息或动作不稳定时，请复位。

①在放入充电用外壳的状态下，左右旧的耳机按住（L/R）的多功能按钮5秒钟



②用对应机器解除配对（已配对）

操作示例：
“设置”➞“蓝牙”➞“TW-HEART-02”
取消注册此设备 或者点击“切断”

③与对应设备连接时，请参考下列“配对”（连接）“进行配对

复位后耳机进入配对模式要花一点时间。把左右的耳机从充电用的盒子里拿出来了然后，把耳机彼此靠近放置，向右左边的耳机用红色和白色闪烁配对请在进入Mode之前等待。

安全注意事项

这里所示的注意事项是使用的人和其他人为了防止对人的危害、对财产的损害于未然因为记载了内容，所以请一定要遵守。

表示图画的意思

以下显示的区分不遵守显示内容，使用错误的情况下产生的危害和损害的程度。

⚠危険	这个表示，如果处理错误，死亡或重伤的危险迫在眉睫的内容
⚠警告	这个表示，如果处理错误，死亡或重伤的内容
⚠注意	该显示在处理错误时可能会受伤2假设发生了物质损害3。

＊1：重伤：失明、受伤、烧伤（高温、低温）、触电、骨折、因中毒等留下后遗症的，以及住院、长期治疗的明细栏样式中定义的设置。
＊2：轻伤：治疗不需要住院或长期住院，受伤、烧伤指喉咙（高温、低温）、触电等。
＊3：物损：涉及房屋、家产及家畜、宠物等指扩大损害。

禁止・强制的绘画表示说明

❗ 指示	基于指示的行为的强制（必须执行）的符号
⊘ 禁止	是表示禁止（不能做的事）的记号
⊘ 分解禁止	它是一个不能分解的符号
⊘ 水ぬれ禁止	在有水的地方使用，或者被水弄湿表示不能做某事的记号
⊘ ぬれ手禁止	表示不能用湿手处理符号

⚠危険

为了防止火灾、烫伤、受伤、触电等

❗ 指示

使用中，保管中，异味，异音，发烟，发热，变形发现破损、芯线露出、断线等异常时立即停止使用

发生异常后，请勿修理本产品。高的可能会有触控器或触击。

当电池漏液或有异味时立即停止使用，远离烟火

引起漏液的液体，可能会起火、破裂等的意外。

本产品在5℃~35℃环境下使用

关于对应机器的使用温度范围，请使用请看对应机器的使用说明书。

长时间充电未完成时，停止充电

有过充电的危险。

⊘ 禁止

微波炉、H烹调器等加热烹调器、或者放入锅等高压容器等危险的地方

不使用指定以外的方法充电

不在以下位置使用或存储

- · 烟火、暖气设备周边、阳光直射的地方、火焰天下的车内等，高温的地方和热的家里水位
- · 浴室、厨房、加湿器旁边等水分和湿气多的地方，结露的地方
- · 灰尘多的地方
- · 摇晃的台子上和倾斜的地方等，不稳定地点
- · 盖上布和毛毯等的状态

连接器或插座上有导电性异物（项链或发夹、铅笔芯、金属挂件等）使之接触，与这些一起携带，保证不受管

请不要让灰尘进入内部。有起火、破裂、发热的危险。

刺尖锐的东西（钉子等），硬的东西（锤子等）敲打、踩踏等，过了不施加过分的力量

有起火、破裂、发热、漏液的危险。

不要投入火中，也不要加热

有起火、破裂、发热、漏液的危险。

⊘ 分解禁止

不分解、改造

⊘ 水ぬれ禁止 ⊘ ぬれ手禁止

除了雨、水以外的果汁、海水、宠物尿、化妆水、肥皂水等液体，或高温或不浇低温水。另外，这些液体或水珠

有雨、汗、水附着时，用干布擦拭请收纳在充电用外壳中。这些以外的液体附着时，请停止使用。

充电用外壳不是防滴/耐汗的。汗水，雨水水、海水、宠物尿、化妆品、肥皂水等不要用乐剂等弄湿，也不要用湿漉漉的手处理好的。另外，花瓶、花盆、杯子、化妆品等，液体不要放在装有身体的容器附近

万一如果湿了，请停止使用。

⚠警告

为了防止低温烫伤和故障等

❗ 指示

使用前，耳机和充电用电缆的连接确认内部无异物。

⊘ 禁止

不在以下位置使用或存储

- ・寝具上
- ・婴幼儿触手可及的地方
- ・宠物附近
- · 产生加油站等易燃气体

充电中，长时间不触摸

睡着了无意中长时间触摸，本制不要把东西放在口袋里。

⚠注意

为了防止受伤、故障等

❗ 指示

不使用时，拆卸充电用套管。

连接充电用套管时，连接器的方向注意身体，慢慢地插入里面。取得取下时，请务必拿着连接器，不要拧立刻拔掉

行驶中，司机用手拿着智能手机等通话、操作、注视显示器法律禁止这样做。运气除了转中以外，道口、车站的站台、车通过的道路、施工现场等，如果听不到周围的声音就会有危险请不要在产生的地方使用。

孩子使用时，监护人使用的方法教，不使之错误的使用方法

为了防止失明和皮肤伤害等

❗ 指示

本产品破损时，请注意破损的锋利物品进行调试。另外，在内部物质等泄漏的情况下不要附着在手等皮肤和衣服上。

万一附着后立即用清水冲洗来修改标记元素的显示属性。进入眼睛或嘴巴的时候，马上请用冷水清洗，接受医生的诊疗。

由于使用本产品，在皮肤产生异状情况下立即停止使用，接受医生的诊疗。

为了防止耳聋等

❗ 指示

使用前：降低支持机型的音量

使用中感到不舒服时，请立即停止使用。

⊘ 禁止

不要音量太大，也不要长时间连续使用

电波注意事项

本产品是基于电波法的小功率数据通信系统作为系统无线电台的无线设备，工程设计认可正在接受证明。因此，使用本产品有时候你不需要无线电台的执照。此外本产品仅在日本国内使用。

本产品具有与以下设备或无线电台相同的频带来修改标记元素的显示属性。

- ・产业・科学，医疗用机器
- ・工厂生产线等使用的移动体识别用无线电台
  - –站内无线电台（需要许可证的无线电台）
  - –特定小功率无线电台（不需要许可证的无线局）
- ・业余无线电台（需要执照的无线电台）

在使用本产品之前，在附近进行移动体识别用室内无线电台、特定小功率无线电台及亚马逊 A请确认无线电台没有运行请给我。

万一从本产品移动体识别用的室内无线电台对较大场景进行渲染期间已观察到该故障迅速变更本产品的使用场所或使用请中止工作。

此外，本产品中移动体识别用特定小功率对无线电台或业余无线电电台有害的在发生电波干扰的情况下，有什么困难吗？发生的时候，软银选择请联系窗口。

⚠警告

⊘ 禁止

可能会因本产品的误动作而产生重大影响近距离使用

引起漏液的液体，可能会起火、破裂等意外。

医院和飞机内等禁止使用电波场所不使用本产品

通过本产品的电波可能会影响电子设备。

基于电波法的认证号码

R: Ⓡ210-177476 L: Ⓡ210-177470

关于保修

客户在充分理解下列保证规定的基础上请使用本产品。

保修规定

保修内容

1. 本产品附带的保证书（以下称为“保证书”）中规定的保修期（从本产品购买日开始计算）内，在适当的使用环境及使用方法下发生的本产品商品（仅以主体部分为对象，附带品、消耗品等不包括）故障，无偿更换本产品来修改标记元素的显示属性。无论保修期内外，都不能进行修理处理没有。另外，关于本产品的外观、美观等的明细栏样式中定义的设置。另外，交换了更换后的产品交付日30天以上或更换前保修期的剩余期间中所述修改相应参数的值。

保修范围

2. 以下情况不在保修范围内。
   - （1）超过保修期的。
   - （2）无法出示保修单及出现故障的本产品时。
   - （3）保证书中未记载客户信息的。
   - （4）保证书上记载销售店、购买年月日，或者购买没有证明（收据、交货单）的情况。
   - （5）保证书中存在伪造、修改等情况。
   - （6）本公司及本公司指定的机构以外的第三方以及因客户改造、拆卸、修理而发生故障的。
   - （7）连接或组装到本公司规定的设备以外使用，发生故障或损坏时。
   - （8）超过通常设想的使用环境范围的温度、湿度、振动等导致故障时。
   - （9）使用说明书中记载的内容（危险、警告、注意等）的情况。
   - （10）使用说明书中未记载的功能及品质被要求交换的情况。
   - （11）本产品的消耗部件自然磨损或自然劣化时褪色为此颜色。
   - （12）从正规销售店以外购买本产品时（弗里玛网站、弗里玛应用程序等个人间买卖网站等购买或转让）。
   - （13）购买本产品后的运输中或保管中发生的冲击、掉落等发生故障时。
   - （14）地震、火灾、落雷、风灾水灾、其他天变地异、公因有害、异常电压等外部因素发生故障时。
   - （15）除前款所示外，故障原因为客户使用被认为在方法中的情况。
   - （16）发现其他不允许交换的事由时。

更换

3. 请求更换时，首先，软银选择客户窗口
   请联系我。关于交换的详细手续方法我来带路。另外，在联络时，请确认以下信息请在手边准备好报告。

[所需信息]

- （1）产品名称、产品型号
- （2）判断为故障的症状具体来说）
- （3）发生状况（发生的日期、发生的条件等）具体来说）
- （4）发生频率（发生的次数、发生的时间等）＜具体），
- （5）使用环境（手机机型名称・OS/ＯS巴-约翰周边设备等）
- （6）回送地址（姓名、住址、联系方式[10:00~19:00联系电话号码“）
- （7）保证书、购买证明

4. 与客户联系后，从客户窗口按照您介绍的方法，将保证书放入本产品添加软银活动支持中心来删除它。发送本产品时保证请填写您的住址和姓名。
   另外，从顾客那里得到的个人信息，原则上是在交换本产品的目的范围内使用但是，为了确保理光等本产品的安全如果您需要与客户联系请事先谅解有利用的事情。此外，关于个人信息的处理请参阅公司隐私政策。
5. 关于要求更换的本产品，该机型的产品不能更换时，与保修对象产品同等的性能的其他产品（但不限于新品））来定义自定义外观。
6. 更换后的旧产品等在任何情况下都返还不做。
7. 在存储媒体、存储产品等中在保险杠支架中心更换产品
   实施时不进行数据的保护，全部粉碎处分钟，数据无法恢复。

免责声明

8. 关于本产品的故障，本公司故意或重大过失除有损失外，本公司的债务违约及非法行为为等损害赔偿责任，以本产品购入价款为上限。
9. 任何情况下均可能导致本产品出现故障或其他瑕疵无论是否预见到起因的特别损害本公司不承担责任。
10. 数据的消失或破损等，本公司除上述故意或重大过失外在范围内承担责任。

保修规定的变更

11. 本公司未经事先通知或同意的明细栏样式中定义的设置。小的的情况下，保证的提供条件根据变更后的保证内容的形式。另外，关于变更后的保证规定公司将根据通知客户视为同意。

有效范围

12. 该保证规定仅在日本国内有效。另外，关于本产品在日本国外的使用本公司不作任何保证。
(This warranty is valid only in Japan.)

关于本产品・本书的注意事项

本产品请在日本国内使用。在日本国外使用时，本公司概不负责。
同时，关于本产品不支持日本国外的技术

关于运用本产品的结果对其他产品的影响公司概不负责。

本产品及本书根据改良等各种情况进行预告中所述修改相应参数的值。

USB Type-C是USB Implementers Forum的是商标。

蓝牙软件和徽标为蓝牙SIG，Inc.的注册商标，SBC&S株式会社根据感觉使用。

另外，记载的公司名、计划名、系统名、产品名称一般是各公司、个人的注册商标或商标。

为了长期使用

内置于耳机和充电用外壳中的鼠标穆伊恩电池随着使用或经过天数可用时间变短。即使充分充电也使用如果可能时间下降到一半以下，请购买新产品请购买。根据使用方法和环境可以使用的时期不同，但如果长期不使用，请执行以下操作：来定义自定义外观。

- ・在满充电状态或电池-电量为零的状态下请不要定期保管。每3个月从充电罐中取出耳机然后，再次收纳，耳机的LED亮起中所述修改相应参数的值。不亮的情况下，几十分钟请充电。

关于小型充电式电池的再利用

本产品使用锂离子电池正在使用。锂离子电池这是一种可以完全释放的贯重资源。书目产品内置锂离子电池所以作为一般的垃圾废弃不来。根据产品寿命等进行处理循环）时，请联系以下内容。

Li-ion

保修卡

型 号： TW-HEART

保修时间： 自购买之日起1年

客户填写栏 ※使用保证书时，所有项目都用楷书明确请填写。

（注音假名）
贵 姓 类型

电话号码 （ ） —

〒 —

住 址

销售店填写栏 ※购买的销售店可以填写或者确认购买请出示证明书（收据、交货单等）。如果无法确认购买，或者填写遗漏、篡改在某些情况下，保修单和保修规定无效。

销售店名称 印

购买日期 年 月 日

电话号码 （ ）



This paper explains the basic usage.
For more detailed use See
"instruction manual".

Introduction

- ● Please read this book before using this product After you read it, please keep it carefully Please.
- ● General SMON tofon screens and procedures. According to your equipment and environment Display and procedure are different. Handling of your equipment See also the instructions.

⚠ Attention

- ● The case is not water-resistant while charging
- ● Sound quality when water adheres to Mike and spike May change. In that case, dry Wipe or dry with the cloth.

Check out the package

Earphone(R/L)　X1



Aa-pi (S / M / L)X2

*: It is attached to the ihon on purchase

Charge kettle X1





※USB AC adapter or USB USB charger
A personal computer is required.

Charge kettle X1

Guide book X1

Pair

① **Putting the left and right ahahones into charge**

② **Remove left and right earphones**

※ Even in case of using only the first time in this procedure Pair, please.



Automatic peeling mode.

🔈 From the right aabon The sound rings.

＊Left (L).

③ **Pairing operation with corresponding devices**

Example of SMA tofon operation

※Depending on your environment, the procedure and the display are different.

※Bluetooth name displayed on Bluetooth setting screen "TW-HEART-02" or "R" / "L" May be reversed.

1.On the screen, tap settings

2.Tap [Bluetooth]



3.Turn Bluetooth



4.Tap [TW-HEART-02]



When pairing is completed, connect to the corresponding model screen Completion and display from LED blinking red and white Only flashing.

🔈 The sound of pairing completes.

4.Tap [TW-HEART-02]

5.If the message of the pairing request appears, Tap [pairing]

※It is also not displayed.


Bluetoothペアリングの要求
"Headset"がお使いのペアリングを求めています。
戻る
ペアリング

It is pairing completion when displayed as follows.



After the second or later, both sides of the ahahon were chargedAutomatically connect to "R" or "L". In addition, it takes only one of the two. You can use it as a mono.

Make a call

Works with multi function buttons.

Calls	左(L)	右 (R)
Get a call	Press one at a time	
Call termination / incoming refusal	Long press	
Receive interrupt calls	End of call: Long press Hold the first call: Whichever press	

＊Interrupt call can be used only during service.

Using external sound capture function

During the music playback or during standby Ability to operate.

※You can't use this function when you use only.
※During use of this function At startup, this feature will automatically turn off.
※During this functional use, the sound of "saichi" is faint.
※Not all the outside sounds are heard. Music Of a sound volume, the condition of being loud Yes.

XY-5216 6973D product UI

Paired name: TW-HEART-02 Chip type: 6973D
Power supply bin: Hall breaks the 5V boot

Key function	Implementation state	operation	Prompt tone	Pilot lamp	remark
Power on	With the lid closed	Open the charging bay cover	/	The white light is on for 2 seconds	
	The headset is on Outside charging bay	Hold down the function key for 3 seconds	POWER ON	The white light is on for 2 seconds	
Power Off	The headset is onOutside charging bay	Put the headphones in the charging bay, Close the charging bay cover	/	The red light keeps on. (Charge)	
		Hold down the function key for 3 seconds	POWER OFF	The red light is on for 2 seconds	
		The headset is not connected. Automatic shutdown in 5 minutes	POWER OFF	The red light is on for 2 seconds	
Paired (monaural)	With the lid open	Boot in Pairing state	/	The white light flashes quickly	
TWS pairing	Close the lid Under this circumstance	Open the charging compartment lid, The left and right ears will automatically team up Connect back and then into the hand Bluetooth interface search set If yes, select DYASGE Pair connection	/	Main engine red and white Alternating flashes, The auxiliary engine has no light flash	Left and right ear control Primary pairing Need to use box-matching right
Boot back Connect a mobile phone	Close the lid Under this circumstance	Open the charging compartment lid, If left and right ear before the group Line up, left and right ears first It will automatically connect back. Connect Then it connects to the phone again	connected	No light flash	
With mobile phone disconnect	Bide one's time	Turn off Bluetooth or Remote disconnect	disconnected	Host red and white Alternate, pilot No light flash	
	English and Chinese Tone switching (default English)	3 clicks/in the disconnected state 5 hits in the connected state	/		
Function key	Pause/play	Click right ear	/	No light flash	Auricular alone Use, click All are paused / Play back
	Previous song	Double click left earphone	/	No light flash	Monaural use Double click down A piece of (music)
	Next song	Double click right earphone	/	No light flash	
	Volume plus	Press and hold the right earphone for 1 second	/	No light flash	Monaural use Long press for tone dosing
	Volume down	Press and hold the left earphone for 1 second	/	No light flash	
	Call in	Click either side	/	No light flash	
	On the line End call	Press and hold either side for 1 second	/	No light flash	
	On Siri	Three strikes to either side	/	No light flash	
	Open / Close through	Click left ear	/	No light flash	
Low current alarm	Various boot In status	When the battery voltage is lower than 3.3V	Every 20 lifts Show once "Drip" sound	No light flash	
Low power shutdown	Various boot In status	When the battery voltage is lower than 3.1V, When the headset will automatically shut down	/	No light flash	
charging	Various boot In status	Put the charging bin close cover	/	Charging earphone The red light keeps on, Full light out	
Charging current	30mA				

Turn on / off

Turn on

Remove iahon from charge kettle



Turn off

※After confirming that it is properly housed Please close it.



*Earphone charge starts.

Earphone charge starts. Charge Kees / iPhones

Charge the charging case

Connecting the charging pull to the back



※Charge kettle with charge storage
You can also charge iabon at the same time.
※When charging charge becomes full charge, the LED goes off.

Charge an alarm

Store in charge case



※When the earphone is fully charged, it goes off.

Reconnect / disconnect

Reconnect

After the 2nd time, I take iahonh from charge
Automatically reconnects when you exit
If not, the following devices do not operate.
Operation example: tap [set] random
[Bluetooth] in order At a glance Tap



Disconnect

Connect to the corresponding device.

Operation example: tap [set] random
[Bluetooth] in order Turn [Bluetooth] off



I want to delete registration information (reset)

I want to delete the information of the equipment registered in If the operation is unstable, reset it.

① **Left and right earphones in charge case Press (L / R) multifunctional button for 5 seconds**



② **To remove a pairing**

Operation example:
[settings] [Bluetooth] [registration]
Tap or tap

③ **For pairing with corresponding devices, "pairing" Pair**

After the reset, iabon enters the peeling machine It takes some time to go. Left and right earphones were taken out of charge After you left ihon on the right side Left iphonephon flashing in red and white Wait until you enter the mode.

Safety caution

The following notes are used by others and others To prevent damage to a person or damage to property Please note that the contents are described.

The meaning of a picture

The classification of the following display does not observe the display contents, and uses the wrong use It explains the extent of the damage and the damage caused in case.

⚠ Danger	If this display is incorrect, the death is Incurable danger of falling or injury It is assumed that
⚠ Warning	If this display is incorrect, the death is It is assumed that it may assume "fall or serious injury"Contents
⚠ Attention	This display is "light" If it is assumed that the possibility of It is assumed that the material damage

＊1: Severe injuries: blindness and injury It is hospitalized and it is hospitalized after the poisoning It refers to the thing requiring the hospital.
＊2: Minor injuries: treatment or hospitalization Hot (cold), electric shock, etc.
＊3: Material damage Points to extended damage.

Explanation of prohibition and forced picture display

❗ 指示	Force an act based on instructions Is a sign indicating
⊘ 禁止	A sign indicating prohibition
⊘ 分解禁止	It is a symbol indicating that it should not be resolved
⊘ 水ぬれ禁止	Wet or wet to water It is a symbol that indicates not to be
⊘ ぬれ手禁止	Indicate not to be treated with wet hands Symbol

⚠ Danger

To prevent fire, injury, or electric shock

❗ 指示

During the storage, odor, abnormal sound, smoke, heat, deformation A field where abnormalities such as damage, core exposure or disconnection are observed The application will stop using immediately

Please do not repair this product after the outbreak. Co There is a possibility that the nectar and the pot may act.

Battery leaks or smells Leave the fire away from fire

Fire on a liquid leaked and fears such as ignition or rupture

This product is used in the 35of 5

For use temperature range of corresponding equipment, use Please see the instruction manual of the corresponding equipment.

If charging is not completed for a long time, stop charging

There is a possibility of overcharge.

⊘ 禁止

Heating cooker, pressure cooker, microwave oven Put it in a high pressure container such as a kettle Not

Do not charge in other ways than specified

Not used or stored in the next place

Fire, heating equipment, ambient spot, flame
A place in which the temperature is high, such as inside a car
Pancreas
Moisture and humidity in bathroom, kitchen, humidifier
A place where dew condensation occurs
A lot of dust
Unstable, such as on top of a swollen table or sloping place
Location
The state of being covered with cloth or blankets

Conductive foreign body in the connector or pot Hair pin, pencil core, metal strap Contact or carry with them Not pipe

Please keep the dirt inside. There may be ignition, rupture, and fever.

A sharp object By tapping or stepping Do not add strength

A sharp object By tapping or stepping There are fire, bursting, exothermic, and leakage of liquid.

Not put into heat or add heat

There are fears of ignition, rupture, heat, and leakage.

⊘ 分解禁止

Not disintegrated or modified

⊘ 水ぬれ禁止　⊘ ぬれ手禁止

Jealousy, seawater and pet other than rain and water Liquid such as urine, cosmetics, soap water, or high temperature Low temperature water. These liquids and water Not immersed in

If rain, sweat or water sticks, wipe with dry cloth Please store it in the charge case. These Discontinue use if any liquid is attached No.

Charge casing is not dewatering / sweating. Sweat, rain Water, seawater, pet urine, cosmetics, soap water, etc Do not use such as a dressing agent or handle with a hand. In addition, vases, pots, cups and cosmetics Not placed near a container

If it is wet, please discontinue use.

⚠ Warning

To prevent low temperature burn or failure

❗ 指示

Ihon and charge kettle before use It is confirmed that there is no foreign substance inside the TA / PO. Remove from something

⊘ 禁止

Not used or stored in the next place

Above the bedding
The reach of a baby
Close to pet
Gas fired gas
A possible place

Do not touch long during charging

I did not intentionally touch and sleep for hours Please do not put the product in your pocket.

⚠ Attention

To prevent injury or injury

❗ 指示

Remove the charge kettle when not in use

Connecting the charging casing to the connector Please note slowly and insert into the back. Take When you remove it, you always have a connector Pull out

During driving, the driver holds a SMON tofon Call, watch or watch the display It is prohibited by law. Luck In addition to the rolling stock, the crossing of the railroad track, the wheelchair of the station, the way of the car Danger is dangerous if the surrounding sound is heard Please do not use this product at any place.

How a guardian treats when a child uses Teach me wrong

To prevent blindness or skin injury

❗ 指示

When this product is damaged, be careful of damaged goods. Also, if the inside substance leaks, the face To prevent from adhering to skin or clothing

Washes washed quickly with clean water Please. If you enter your eyes or mouth Please wash with fresh water and consult your doctor.

If skin abnormalities occur due to the use of this product Immediately discontinue use and receive a doctor's medical care

To prevent hearing loss

❗ 指示

To reduce the volume of the corresponding model

If you feel sick during use, use immediately Cancel

⊘ 禁止

Do not use large volume or continuously for a long time

Attention about radio waves

Small power data communication system based on radio method Wireless design of radio station I have a witness. Therefore, use this product When you need a radio station license. And This product can be used only in Japan.

The same frequency band as the following equipment or radio station

The same frequency band as the following equipment or radio station. Industrial, scientific and medical equipment
The movement used in manufacturing lines of factories
A radio station for body identification
Campus radio stations (radio stations required)
Specified small power radio station Bureau)
Amateur radio station

Use this product to identify nearby moving objects before use Mobile radio station, specified small power radio station, and amako Confirm that no radio station is running No.

Mobile radio station for mobile object identification If an electromagnetic interference is harmful to the Do you want to quickly change the place of use of this product Please discontinue use.

Specified small power for mobile object identification Harmful to radio stations or amateur radio stations If there is a radio interference, something is wrong Bing Web: Softbank selection Please contact us.

⚠ Warning

⊘ 禁止

Fear of serious impact of this product Do not use near certain equipment

Fire on a liquid leaked and fears such as ignition or rupture

It is prohibited to use radio waves Do not use this product

Radio equipment of this product It may affect electronic equipment.

Authentication number based on radio law

R: Ⓡ210-177476　L: Ⓡ210-177470

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction