



Outdoor Sports
Bluetooth speaker

Usermanual

please read the instructions carefully before using the product

Audio key/interface introduction




Introduction to microphone keys

1. Power on key : long press to turn on/off short press switch : microphone adjustment / reverberation adjustment / style adjustment / double click control audio playback pause.

3. -key : short press to switch microphone volume down Reverb volume decrease / accompaniment volume decrease : Long press Control the previous music

2. +key : short press to switch microphone volume up Reverb volume increase accompaniment volume increase; Long press Control the next music

4. Long press the tube to silence the original sound to turn on/off, short press the magic sound to change the sound effect



Type-c Charging port DC5V-1A

Warm tips: Do not use a fast charger to charge the stereo and microphone

Product use

1. (Volume One): Short press (Volume One) switches to the previous song, long press (Volume One) volume gradually decreases
2. (Light key: short press to change the light color, long press to turnoff the light
3. (Power button: Press and hold for 3 seconds to turn on, press and hold again to turnoff
4. (Function key: short press to switch Bluetooth mode, radio mode, audio mode
5. (Pause button: short press to pause/play music; long press in radio modeAutomatic channel search
6. Volume +): Short press (Volume + to switch to the next song, long press Volume + The volume gradually increases
- 7.AUX1: audio input; supports 3.5mm wired phone for simple singing
8. USB port: supports U disk insertion, default format MP3 format
9. [AUX2]: Audio output; supports computers, mobile phones, notebooks, music Use the 3.5mm pin of the device etc.
10. (TF card: supports TF card format, default format MP3 format
11. (Indicator light: audio power-on indicator lightblue, flashing status bag pairing,Always on Pairing successful
12. [Type-c port]: Supports 5V2A charging power, prohibiting the use of super Fast charging equipment

Warm Tip: if there is an exception, please contact online customer service

Audio instructions

Power Key

Long Press: Switch Machine, Short Press: Switch the volume of the accompaniment volume phone simple reverb size

Volume+

Increase microphone volume

Microphone Keys

Long press the tube to silence the original sound to turn on/off, short press the magic sound to change the sound effect

Five voice changing effects: professional mode, male to female, female to male, Warcraftsound, Lolita sound

Instructions for the use of the microphone

1. Wireless pairing: before using pairing, you need to turn on the audio power, and then turn on the microphone power to connect the microphone automatically

2. Voice prompt: increase the volume of the maximum voice prompt, the minimum volume without voice prompt

Features

1. Wireless Bluetooth speakers support a variety of Bluetooth devices, such as mobile phones, laptops, projectors, wireless adapters and other Bluetooth devices
2. Insert TF card or U disk to play music files in MP3 format.
3. With button function for mode switching and volume adjustment and other simple button operation
4. DC charging using DC5V2A, built-in charging battery power.
5. Can connect audio output devices, such as mobile phone/MP3/MP4/PC, etc.
6. Choose a more convenient Wireless microphone (single or double) based on your needs

Warning Sign

1. Do not let the product into water, or put in water immersion.
2. Don't put weights on products
3. Do not expose the product to the sun, should be placed in a dry and ventilated place.
4. If the product surface damage or mechanical, electronic equipment failure please do not use this product and please contact our service center
5. Please do not disassemble the equipment by yourself. If you disassemble the equipment, you will bear any loss

Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement.

The device

can be used in portable exposure condition without restriction.