

Multilingual User Manual (in PDF)

Please scan the QR code below to download the user manual in multiple languages.




The supported languages include: English, French, Spanish, German, Italian, Russian, Turkish, Arabic, Vietnamese, Malay, Khmer, Traditional Chinese, Simplified Chinese, etc.

Packing List


Smartwatch (including silicone strap), Magnetic charging cable, User manual



Smartwatch



Magnetic charging cable





Strap



User manual

About the Watch




Watch Charging

- Please fully charge the watch before first use.
- The magnetic charging cable's USB connector needs to be plugged into a power adapter or a computer's USB port to function.
- The charging cable's magnetic connector automatically attaches to the back of the watch. When charging, please ensure that the metal contacts on the back of the watch are closely connected to the charger's magnetic connector.

Note:

- Please use the original KOSPET magnetic charging cable to charge the watch. Before charging, ensure that both the charging cable and the watch are dry and clean.
- Please use a power adapter with an output current of 500mA or higher and ensure that it is certified to meet safety standards.



Watch Wear and Care Tips

Cleaning and Maintenance After Water Activities

After water activities (e.g., swimming, surfing), promptly shake the watch to remove residual water from holes in the watch case. Wipe the watch body and the strap with a soft cloth dampened with clean water. Allow them to dry completely before wearing the watch again to prevent salt deposits that may affect the normal use of the watch.

Cleaning Tips After Workouts

After intense activities (e.g., running, hiking, cycling), sweat and acidic residues may accumulate on the watch. Please rinse the watch with clean water and dry it promptly to minimize long-term corrosion.

Cleaning Precautions

Do not use soap, hand sanitizer, shampoo, or other harsh chemicals to clean the watch, in order to avoid skin irritation or component damage caused by residues.

Device defects or damage caused by improper cleaning or chemical exposure is not covered under warranty.

Usage Environment Precautions

Do not expose the watch to the following conditions to maintain its water resistance.

- High-temperature environments (e.g., saunas, hot showers)
- High-pressure water (e.g., diving, water skiing)
- Strong corrosive liquids or UV/radiation exposure

Note: Prolonged exposure to extreme conditions accelerates gasket deterioration, which may lead to water ingress.

App Download and Installation

Before using the smartwatch, please download the Apexmove App where you can access more health and fitness data insights and customize various settings, which helps you to embrace a healthier and more active lifestyle.

Method 1:

Scan the QR code on the right to download and install the App.



App QR code



Apexmove

Method 2:


Enter the keyword "Apexmove" in the Apple App Store or Google Play Store to download and install the App.



App Store




Google Play



App Registration and Login

1. Once the installation is completed, open the App, allow it access BT and location, and grant other necessary permissions on the smartwatch.



2. To fully experience all the features of the smartwatch, please register and log into the App before use.

