



TANK X2 Ultra

User Manual

Download Multilingual User Manual (in PDF)

Please scan the QR code below for the user manual in multiple languages.




The supported languages include: English, French, German, Italian, Spanish, Turkish, Arabic, Russian, Ukrainian, and Traditional Chinese.

Packing List


Smart band (including strap), Magnetic charger, User manual



Smart band (including strap)




Magnetic charger



User manual

About the Band




Band Charging

- Please fully charge the smart band before first use.
- Please plug the magnetic charger's USB connector into a power adapter or a computer's USB port.
- Attach the smart band to the charger, keep it in a proper direction and position and ensure that the metal contacts on the back of the band are closely connected to the charger.

Notes:

- Please use the KOSPET original magnetic charger to charge the band, and make sure the charger is dry and without metallic foreign objects on it.
- Please use the power adapter with output current of 500mA or more, which is certified to meet safety standards.



App Installation

Please download the KOSPET FIT App before using the smart band to access more sports and health data, personal settings and beyond, facilitating your journey towards a healthier, more active lifestyle.

Method one: Scan the QR code on the right to download and install the App.



App QR code



KOSPET FIT




App Store




Google Play


Method two: Enter “KOSPET FIT” on App Store or Google Play to download and install the App.



App Registration and Sign-in




1. Open the App, allow it to access Bluetooth, location, and grant other necessary permissions on your phone.




2. Register and sign in to the App.

Band Pairing



1. Follow the prompts on the App to find and add the device (smart band).




2. Allow the band to connect to the App on your smart band.

Note: Please don't pair the watch directly via your mobile phone's Bluetooth on Settings.

Bluetooth Calling Setup



For both iPhones and Android phones:

Once the App is connected to the band, tap the call icon on the band to enable Bluetooth calling.



OTA Update

Enter the Device page on the App, then tap Firmware Update for the latest firmware version.



Band Gestures




Shortcut Menu

Swipe down on the watch face to enter the Shortcut Menu that can be customized by tapping the "+" icon.




Notification Center

Swipe up on the watch face to enter the Notification Center that can be customized by tapping Edit at the bottom.



Shortcut Cards

Swipe left on the watch face to enter the Shortcut Cards. Swipe down on the page for more information.



Unread Notifications

Swipe right on the watch face to view unread notifications.

Use of Physical Buttons

POWER button


Short press

- Short press to turn on the screen.
- Short press on the watch face to enter the App list.
- Short press on other feature pages to return to the watch face.
- Short press to mute when there is an incoming call.
- Short press during a workout to pause/continue/unlock the current workout.
- Short press on Stopwatch/Timer to pause/resume the stopwatch or timer.

Long press

- Long press for 3s to power on/off, restart, or activate Emergency SOS.
- Long press for 12s to force a restart.
- Long press for 3s during workouts to end and save the data.
- Long press for 5s to disable the power saving mode when it's been enabled.





SPORT button

Short press

- Short press to turn on the screen.
- Short press on the watch face to enter the workout list. Short press again to return to the watch face.
- Short press on other pages to return to the previous page.
- Short press during a workout to pause/continue/unlock the current workout.

Long press

- Long press for 3s during workouts to end and save the data.


Change Watch Faces

- Long press the watch face, then swipe left or right to replace the current watch face.
- Enter the KOSPET FIT App to download more watch faces on Watch Face Gallery, including those for always-on display.



Sports Recognition

Once enabled, the band will remind you whether to enter the corresponding sports mode via a pop-up reminder, when you begin one of these sports — walking, running, cycling, elliptical trainer, or rowing machine.



Warranty Policy

KOSPET provides a two-year warranty on the products purchased through our official online store(<http://www.kospet.com>).

For more information, please visit: <https://kospet.com/pages/kospet-warranty-policy>.

For further questions, welcome to email us: after-sales@kospet.com, or call +1(507)668-8466, from Monday to Friday, from 08:00 a.m. EST to 05:00 p.m. EST.

Security Tips

- Please do not expose the band to extremely high-temperature environments or near high-temperature equipment, such as ovens, microwaves, or water heaters. High temperatures may cause battery explosions or other safety accidents.
- The band contains an irremovable lithium-polymer battery. Non-professionals are prohibited from disassembling it to avoid potential safety hazards.
- This band has passed multiple waterproof tests before leaving the factory. During daily use, wear and tear on internal components may affect its sealing performance. Please wear your band carefully while swimming or diving, but avoid wearing it in saunas or during hot showers.
- This product is not a professional medical device. Heart rate, blood pressure, and other health-related data detected by the band are for reference only and cannot be used as clinical basis.

FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This user manual is published by KOSPET that reserves the right of final interpretation. We may make adjustments to this manual anytime if necessary. Feature descriptions on the foregoing pages are provided for reference only.

The E-label information

To access the e-label information, in the device

- 1.Go to the main interface

- 2.Enter the setting interface

- 3.Select About, as shown in the interface



Watch You Want