

vibesonly.com

Size: Insertable length 3", Internal diameter maximum 1", Base length 3" Base width 1"

Weight: 50g

Materials: Body-safe silicone with high-quality ABS detail

Battery: Lithium Ion

Charging Time: 2 hrs

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Vibes Only™

Analise Anal Vibe

Instruction Manual

Buckle up for some butt stuff!

Follow our simple guide to anal play, and unlock the next level of pleasure – perfect for solo exploration or with a partner.

Why you'll love the Analise anal vibrator:

- Connects to the Vibes Only app
- Stimulates internally and externally
- Designed for all genders
- Unassumingly powerful
- 3 intensity levels
- 3 vibration patterns
- Medical-grade silicone
- Water resistant



Connect with
Bluetooth

Guide To Anal Play

Anal stimulation can be pleasurable for everyone, as it heightens sensations in your sensitive nerve endings. Use the Analise on yourself or your partner, for foreplay or during sex.

Consent Is Key

Never surprise your partner; always ensure you've received enthusiastic consent.

Go If You Gotta Go

B-hole stuff can get messy. We recommend using the bathroom an hour before you use your vibrator.

Relaxation Is Key

Be gentle with your body. If you're stressed or nervous, your body will tighten up.

Lube Is Your Bestie

Liberally use a water-based lubricant to reduce friction, re-apply often. Silicone lubricant should not be used with your Analise.

Feel Free to Warm Up

You can always use fingers to get your b-hole ready.

Take It Slow

Insert slowly, take breaks if you need to, and start your vibrator on the lowest setting.

No Double Dipping

Don't touch the vulva with the same hand, your mouth, or with a vibrator after it's touched the anus, to avoid spreading bacteria.

Aftercare


Clean your vibrator using antibacterial soap and warm water. Wash and dry thoroughly, then store in a clean, dry place out of sunlight.

Hope you're ready, this vibrator only gets better...

Connect to the Vibes Only app to unlock a whole new world of pleasure by controlling your vibrator in the palm of your hand, or give control to your partner. The Analise works in tandem with the app for a full-blown journey into orgasmic bliss.

Get connected

Scan this code to download the Vibes Only app on your phone.



Start vibing

This vibrator comes partially charged. To get it all the way up, charge before use.



On your device, hold down the power button for two seconds to turn on.

Your Bluetooth will be enabled when the device turns on. The light will flash to indicate it is discoverable.

The app will detect your device. Select it, and your vibrator is synced!



To adjust intensity and patterns manually: Click the button to cycle through the steady speed levels, then the patterns.

Power your vibrator

Charging instructions

If your vibrator is feeling a little lowkey, it may be time for a charge.


Due to the unique design, each Vibes Only model charges slightly differently.

First, plug your USB cord into a standard charging block (high-power charging blocks may damage the battery).

Insert the DC jack (long skinny piece) into the small circle opening (tight hole) on the bottom of your vibrator. Be gentle, but firm, until it's in as deep as it can go.

The light on your vibrator will flash to indicate that it's charging.

When it is fully gassed up (approx. 2 hrs) the light will change to a steady glow.



Care for your vibrator ...and it will love you back!

Care instructions

We can't recommend using a water-based lubricant enough, such as Vibes Only Juiced Up. Avoid using a silicone-based lubricant as this could kill your vibrator.

After every use, clean with warm water and antibacterial soap or toy cleaner. Dry thoroughly with a clean towel or air dry. Store in a cool, dry place and keep your vibrator away from toys made of other materials. Remember to charge periodically to maintain the battery life.

What not to do

- Use with oil-based massage oils or lubricants as it may damage the silicone.
- Leave your vibrator in direct sunlight or ever expose it to extreme heat.

Troubleshooting

Your vibrator's light does not pulse when the charger is connected? This could be why:

- Battery is fully charged (go off!)
- Battery is drained and will require several minutes to recognize that it is being charged.
- Charger is not properly connected. Check your charging block and charging pin.

Your vibrator does not connect with your phone when the button is pressed?

- Battery is drained and your device requires charging.
- Make sure you give Vibes Only permission to access Bluetooth on your phone settings.
- The Bluetooth on your phone is not enabled. Make sure to enable, or reset your phone if needed.
- You have exceeded the 10 seconds required for your vibrator to 'find' a device. Reset both your vibrator and your phone by turning off, waiting 30 seconds, then turning on. Now try again making sure your phone has fully restarted, with the Bluetooth switched on.

If you experience any other problems with your Vibes Only product or have any questions regarding operation, visit www.vibesonly.com or please contact help@vibesonly.com.

What's your vibe?

Discover more:



@VibesOnly



vibesonly.com



Available on the
App Store



GET IT ON
Google Play

