Manual

Works with
Apple Find My

Quick Tips for Pairing

If pairing with Find My app fails, please take any of following actions:
1. **Network Switch:**
Switch between WiFi and mobile data on your phone. Now attempt pairing again with the Find My app.
2. **Factory Reset:**
To reset the device:
Remove the device from the Find My app.
Make sure the device is turned on by pressing the button twice and you hear a beep.

Then hold down the button for about 8 seconds until it beeps again.
Release the button to complete the factory reset. The device can now be re-paired with the Find My app.

Product Overview



Wallet x 1

Please note: This illustration sheet is shared by various wallet models. Therefore, the actual wallet you receive may differ from the one illustrated above.

Smart Tag x 1

Quick Instructions

Hey there! Thanks for choosing our product. Here's a quick rundown on how to get your device up and running smoothly.

Note: The smart tag is only compatible with Apple Find My. The latest version of Apple iOS is recommended.

1. Turning on the Device

Hold down the button for about 5 seconds until you hear a beep - that means it's on!

2. Pairing the Device with Your iPhone

Open up the Find My app and follow these steps:
2.1 Get your device close to your iPhone. Tap on the Items tab, hit the '+' button, and select Add Other Item.
2.2 Follow the prompts to connect and name your device a name and emoji.
2.3 Agree to link it to your Apple ID and tap Finish.

3. Enabling Lost Mode

In the Find My app:
3.1 Go to the Items tab and select your item.
3.2 Tap on Lost Mode, enable it, and follow the instructions to add contact info.
3.3 Customize your lost message and tap Activate to wrap it up.

4. Removing the Device

In the Find My app:
Go to the Items tab, select your device, and hit Remove Item. Confirm the removal to complete the process.

Note: After removing the device from the app, it'll beep six times, entering pairing mode. If not re-paired within 10 minutes, it exits pairing. To pair again, press the button once; it will ring, ready to pair with the app.

Additional Info on Device Button Functions:

1. Power On:

Hold down the button for about 5 seconds until you hear a beep.(Ensure that the battery is already installed.)

2. Device Status Check:

Double-click the button to hear a beep confirming it's on.

3. Pairing Mode:

After removing the device from the app, it'll beep and enter pairing mode. To pair again, press the button once.

4. Factory Reset:

Remove the device from the Find My app.
Make sure the device is turned on by pressing the button twice and you hear a beep.
Then hold down the button for about 8 seconds until it beeps again.
Release the button to complete the factory reset. The device can now be re-paired.

5. Power Off

When the device is on, press the device button five times within two seconds. The device will beep, indicating it will be powered off.

FAQ:

1. How can you confirm if the device is turned on?

Double-click the device button, and the device will beep, indicating it's operational. If it doesn't beep, it's turned off. Long-press the button for five seconds to turn it on.

2. How can you replace the battery?

2.1 Open the device from the notch side.
2.2 Replace the battery with a new one (positive pole upward).
2.3 Assemble the device and long-press the button for five seconds to restart it.



Article 12: Without permission, any company, firm, or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the approved low power frequency electric machinery.

Article 14: The application of low power frequency electric machineries shall not affect navigation safety nor interfere a legal communication, if such interference is found, the service will be suspended until improvement is made and the interference no longer exists. Legal communication refers to wireless telecommunication operated according to telecommunications laws and regulations.

The low power frequency electric machinery should be able to tolerate interference from electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.

European Union–Disposal Information

The symbol above signifies that according to local laws and regulations, your product and/or its battery must be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

How to put wallet and smart tag together

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

FCC Warning
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Regulatory Safety Information

KEEP BATTERIES OUT OF REACH OF CHILDREN.

WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN.
Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the esophagus.

If you suspect your child has swallowed or inserted a button battery, immediately call the 24-hour Poison Information Centre for fast expert advice.

- Immediately dispose of used batteries and keep them away from children.
- Do NOT dispose of batteries in household trash.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.

- Keep in the original package until ready to use.
- Call a local poison control center for treatment information.
- Verify suitable emergency call numbers for your country.

- Do not use if the compartment is not secure.
- Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous. Risk of fire and burns.
- Do not recharge, disassemble, heat (-20°C to +70°C), or incinerate.

Rated voltage 3V
Rated current ~15 mA