



Just for You



YM-111

Product Model: YM-111
FCCID: 2BEON-YM111
Wireless Version: V5.3
Frequency Response: 20Hz-20KHz
Impedance: 32ohm
Rated Power: 8mW
Charging Case Battery Capacity: 300mAh
Earbud Battery Capacity: 30mAh
Input: DC5V==1A
Play Time: 4H
Standby Time: 250H



Functions

Wireless stereo sound: Support wireless connection to play music.
Wireless calls: Support wireless connection for HD Calls.
Main-secondary earbud switching: Support main-secondary earbud switching.
Battery indicator: Support earbud battery indication for IOS phones.

Instructions

Power on/off: Charging Case with power, open the lid of the Charging Compartment and Pick up The Earbuds To Pair Automatically.

Put the earbuds back into the charging case, close the cover and power off.

Wireless connection

Turn on the wireless function on your phone, open the charging case cover, and click to connect the name (YM-111) Displayed on your phone.

Buttons:

One click: Play/ Time out

One click: Answer the call/ Hang up

Tap the right ear 2 times: Volume up

Tap the left ear 2 times: Volume down

Tap your left ear three times: Previous song

Tap your right ear three times: Next song

Temperature/humidity range

Place the product in a dry and ventilated space, avoid contact with corrosive Substances, and keep away from fire and heat sources. The product should be charged Once every 3 months during storage.

Working: 0-40°C, Storage: -10-45, Working humidity: Less than 70% Storage humidity: Less than 70%

Warnings

1. Do not use any abrasive detergent to clean this product.

2. Do not hear this product or keep it close to a fire source, such as a cooking stove.

3. Do not expose this product to direct sunlight for a long time.

4. Do not dispose of this product in the fire to avoid explosion.

5. Do not try to disassemble this product to make any modifications, for it does Not contain any maintenance components.

6. Do not use this product in the rain.

7. If the product is not for use for a long period of time, please store it in a Dry environment, and charge it at least once a month to extend its life and Avoid extreme temperatures and dust.

Warranty

This product is covered under warranty for a period of one year from the date of sale Limited to normal use and maintenance of the machine parts, materials and functions.

Problems and failures verified upon further identification will be provided free Repair and replacement parts.

This warranty does not apply

(A) to a product that is out of warranty;

(B) to damage caused by operating the product outside the permitted or intended uses described by Remax;

(C) to a product that has been disassembled, repaired or modified without the authorization of Remax;

(D) if warranty card and proof of purchase cannot be presented;

(E) to damage caused by earthquake, fire or other external causes, natural disasters, etc.

Note: The warranty does not include product transport costs and does not provide on-site maintenance services.

Consumers are welcome to register on the official website and put forward valuable opinions so that our company can develop new products.

www.zouiks.com

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.