


EK653


Product user guide

Wireless Keyboard and Mouse Combo



Package contents:



- Nano Receiver (inside mouse battery cover)
- Quick start guide
- Wireless Combo



- 1 Open the battery cover
install the battery (note the +/- electrodes)


- 2 Take out the receiver

- 3 Insert it into the USB
port of computer



- 4 The keyboard and mouse share a USB receiver, which is in the
mouse battery compartment

- 5 Flip the switch to ON



Basic Parameters

Mouse Specifications:

Wireless data transmission: 2Mbps
Frequency: 2403.85-2479.85MHz
Channel: 16
Engine: no light
Operating distance: 20m
Working voltage: 1.5V
Working current: 12mA
Mouse button life: Over 5 million clicks
Mouse size: 111.51x74.11x42.32mm
Chip Solution: Bk
Mouse battery: 1 AA alkaline battery
(The package does not contain batteries)

Mouse tracking performance:

Mouse return rate: 250Hz

Mouse step operating current:

Working current = 12mA
Standby current = 0.3mA
Sleep current = 30 μ A

Keyboard Specifications:

Frequency: 2403.85-2479.85MHz
Channel: 16
Operating distance: 20m
Working voltage: 1.5V
Working current: <5mA
Keyboard button life: Over 10 million keystrokes
Keyboard size: 435.92x178.6x27.49mm
Chip Solution: Bk
Keyboard battery: 1 AAA alkaline battery
(The package does not contain batteries)

System requirements:

System combination
IBM - compatible PC
Windows: XP(x64) / 7 / 8 / 10
Mac OS X (version 10.4 or later)
An available USB port

(2)In case of quality problems within 60 days, the hardware product can be replaced at the purchase place or repaired at the specified repairing block, and the expiration date of the replaced hardware is the remaining days.

(3)In case of quality problems within 1 year, the product can be repaired at the specified repairing block.

Warranty term

The equipment is provided with a limited product hardware warranty service for 1 year from the date of purchase

Security reminder

Please do not open or repair the equipment. Please do not use the equipment in a wet environment. Please wipe the equipment using the dry cloth.

Keyboard Pairing Method (When Unresponsive):

- 1.Press and hold Esc and +/- (the key next to Backspace) for 8 seconds.
- 2.Release the keys, plug in the USB receiver, and place the keyboard close to the receiver. Wait a few seconds, then press any key on the keyboard to complete pairing.

Mouse Pairing Method (When Unresponsive):

- 1.Press and hold the Left Button, Right Button, and Scroll Wheel simultaneously for 8 seconds.
- 2.Release the buttons, plug in the USB receiver, and place the mouse close to the receiver. Wait a few seconds, then move the mouse to check if it responds.

If there is no response, repeat the process.

Shortcut key function

FN+	F1	F2	F3	F4
Shortcut function	Music	Volume-	Volume+	Mute
FN+	F5	F6	F7	F8
Shortcut function	Prev Track	Next Track	Play/Pause	Stop
FN+	F9	F10	F11	F12
Shortcut function	Webpage	Email	My Computer	Search

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

100g书写纸
一专+一白 3295C
120x165mm
展开360x165mm