

说明书

充电

自第一次使用充电盒或充电线前使用

1. 将充电线插入充电盒的充电接口。

2. 充电时指示灯会亮起。当充电线充电灯熄灭，指示灯即为充电完成。

开关机 ON/OFF

1. 开机：按住多功能键大约5秒，指示灯亮1秒，并听到提示音“开机”，直到指示灯交替闪烁，此时即可正常使用。

2. 关机：按住多功能键大约5秒，指示灯亮1秒，并听到提示音“关机”，此时指示灯熄灭进入关机状态。

操作方法

开/关机	(长按5秒) 触摸感应开关
暂停/播放	(单击) 触摸感应开关
上一曲	(连续三次) 触摸感应开关
下一曲	(连续两次) 触摸感应开关
接听电话	(单击) 触摸感应开关
拒接来电	(双击) 触摸感应开关

提示：电量过低时请在手机上充电

充电注意事项：

1. 使用USB-C充电线连接充电盒的USB接口或手机充电线USB接口充电(充电线请使用原厂或认证品牌)

2. 在充电过程中红色的灯亮

3. 避免在充电时充电盒内放入其他物品

音量调节、播放音乐

1. 音量：通过音量键调节。调节音量时手机耳机、蓝牙耳机、蓝牙耳机。

2. 下一曲：单击播放键，连续3次单击播放键，即可切换下一曲。

3. 播放音乐：短按多功能键，可启动手机上的音乐播放。短按多功能键可暂停播放。

4. 电量不足时充电或充电盒充电。

5. 温馨提示：本产品支持快充充电，请在不影响快充的前提下，使用快充充电。

来电提醒

1. 来电时，蓝牙耳机会提示来电。 (ICL3000000000)

产品合格证

CERTIFICATE OF QUALITY

产品型号: WZZM32

产品名称: 无线耳机

执行标准: GB 4943.1-2022

检验人员: 01

检验结论: 合格

Manual

Charging

Before the first use, the battery must be fully charged before use.

1. Connect the charger cable to the headphone jack.

2. When charging, the indicator light shows a red light. When fully charged, the red light goes out, and the blue light shows a fully charged state.

Turn ON/OFF

1. Power on: Press and hold the multifunction button for about 5 seconds. The blue light will stay on for 1 second, and there will be a voice prompt "Power on".

2. Power off: Press and hold the multifunction button for about 5 seconds. The red light will stay on for 1 second, and there will be a voice prompt of "Shutdown". At this point, the Bluetooth response will enter the shutdown state.

Operation Method

On/Off	(Long press for 5 seconds) Touch sensing switch
Power/Play	(Click) Touch sensing switch
Previous song	(Three consecutive clicks) Touch sensing switch
Next song	(Continuous double click) Touch sensing switch
Answer phone	(Click) Touch sensing switch
Reject incoming call	(Double click) Touch sensing switch

Reminder: Volume increase or decrease needs to be adjusted on the phone

Precautions For Charging :

1. Use a USB-C charger that is compatible with the USB port. (For example, verification charger)

2. The red light in the charging process

3. Recharging and discharging will reduce the battery performance. This is a normal rechargeable battery.

Volume adjustment, playing music

1. Volume: When making a call or playing music, adjusting the volume can only be done with the phone. Quickly press 5 times to switch between Chinese and English.

2. Next track: When playing music, briefly press the multifunction key 3 times to switch to the next track.

3. Play music: Short press the multifunction key to activate the music player on the phone, and short press the multifunction key to play/pause.

4. Music or call record may be deleted when the battery is low.

5. Note: reminder: This product supports 1A charging head charging. It is recommended not to use fast charging.

Caller number

1. When a call is made, the Bluetooth headset will report the phone number, such as 13800000000.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) The device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Product certificate

CERTIFICATE OF QUALITY

Product model: WZZM32

Product Name: Wireless earbuds

Designated By: EN 62368-1

Inspection: 01

Inspection conclusion: qualified

成品32X42mm