

尺寸：90X90mm
材质：80克双胶纸，双面印刷 折页效果

MCHOSE 迈从®



— G3 用户指南 —

无线鼠标



温馨提示：本说明书中的图片均为示意图，可能与实物有偏差，请以实物为准。

·2.4G连接



①将开关拨至【ON】　②短按【模式切换键】至【2.4G模式】　③取出【USB接收器】插至电脑USB接口即可使用

·无线连接



①将开关拨至【ON】　②短按【模式切换键】至【无线1】　③搜索配对名为【G3 Mouse】的设备，连接成功后指示灯灭

·无线2连接方式与无线1相同，可以通过短按【模式切换键】切换模式。
·无线1、2的配对名称均为【G3 Mouse】。

·清除配对记录

·在无线模式下，用【模式切换键】+【回报键】，长按3秒清除配对记录，鼠标无线1、无线2指示灯闪烁5秒提示清除成功，可在无线模式下连接新的设备。
在无线1、无线2模式下单按【模式切换键】，可断开已连接的设备，若没连接新的设备，则再次切换该通道后，会自动回连断开的设备。

·有线连接




①将标配USB线缆Type-C一端插进鼠标对应接口　②将线缆USB一端插进电脑对应接口即可使用

*在2.4G或无线模式下，插上USB线缆后将切换为有线模式并同时会给鼠标充电。

·DPI


DPI档位：单击【DPI切换键】可循环切换六档DPI。



·省电模式

鼠标无任何操作下，5分钟进入一级休眠，移动鼠标可唤醒；15分钟进入二级休眠，点击按键可唤醒。

·充电



·当【指示灯】红色闪烁时，请及时给鼠标进行充电。
·通过配备的USB转换器鼠标与电脑连接，即可为鼠标充电，充电过程中【指示灯】红灯常亮，充满时绿灯常亮。

充电说明

1. 建议仅使用电脑 USB 接口对鼠标进行充电；
2. 请勿使用充头手机充电器对鼠标充电；
3. 请勿使用劣质非标电源适配器对鼠标进行充电；
4. 请勿使用过压过流电源适配器对鼠标进行充电；
5. 充电时请远离高温设备；
6. 长时间不使用时请关闭电源开关。

以上充电说明同样适用于其他带充电功能设备（键盘/鼠标/耳机/音箱等）

·规格参数

型号： G3
充电电流： 0.35±0.05A
充电电压： 5±0.25V
充电接口： Type-C

注意：本设备经过测试，符合 FCC 规则第 15 部分对 B 类数字设备的限制。这些限制是旨在提供合理的保护，防止有害干扰住宅安装。该设备产生、使用并可以辐射无线电波频率能量，如果不按指定说明安装和使用，可能会对无线电通信造成有害干扰。但是不能保证在特定安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰（可以通过关闭和打开设备来确定），我们鼓励用户尝试通过以下一项或多项措施来纠正干扰：
- 重新调整或搜双接收天线。
- 增加设备和接收器之间的距离。
- 将设备连接到与接收器所连接电路不同的电路插座上。
- 请咨询经销商或经验丰富的广播/电视技术人员寻求帮助。

未经合规负责方明确批准的更改或修改可能会导致用户操作设备的权限失效。
本设备符合 FCC 规则第 15 部分的规定。操作须满足以下两个条件：
(1) 该设备不会造成有害干扰。
(2) 该设备必须接受接收到的任何干扰，包括可能导致不期望操作的干扰。

保修卡


感谢您购买本公司产品，在保修期内如果产品出现任何质量问题,请联系我们。联系时请提供此保修卡，以便我们为您提供完善的售后服务。

产品型号：_____　用户姓名：_____
出厂编号：_____　保修地址：_____
购买日期：_____　保修联系人：_____
购买地址：_____　联系电话：_____
销 售 员：_____　邮　编：_____

合格证


执行标准：GB4943.1-2022

MCHOSE



— G3 USER MANUAL —

WIRELESS MOUSE



Warm reminder: The pictures in this manual are schematic diagrams and may differ from the actual objects. Please refer to the actual objects.

·2.4G CONNECTION



①Turn the switch to 【ON】　②Short press the 【mode switch button】 to 【2.4G mode】　③Take out the 【USB receiver】 and plug it into the computer USB port to use it

·WIRELESS CONNECTIONS



①Turn the switch to 【ON】　②Short press the 【Mode Switch Button】 to 【Wireless 1】　③Search for the paired device named 【G3 Mouse】 After the connection is successful, the indicator light turns off.

·The connection method of Wireless 2 is the same as that of Wireless 1. You can switch modes by short pressing the 【Mode Switch Key】.
·The pairing names of Wireless 1 and Wireless 2 are both 【G3 Mouse】.

·CLEAR PAIRING RECORD

In wireless mode, use the 【Mode Switch button】 + 【Mouse Wheel】 and press & hold for 3 seconds to clear up the matched record. The Wireless1 and Wireless2 indicators will flash for 5 seconds to indicate successful clearing. You can connect new devices in wireless mode;
Single-press the 【Mode Switch button】 in Wireless1 or Wireless2 mode to disconnect the connected device. If there is no new device is connected, after switching to the different channel, the disconnected device will be automatically reconnected.

·WIRED CONNECTION




①Plug one end of the standard USB cable Type-C into the corresponding port of the mouse　②Plug the USB end of the cable into the corresponding port on your computer to use it

*In 2.4G or wireless mode, after plugging in the USB cable, it will switch to wired mode and charge the mouse at the same time.

·DPI


DPI gear: Click the 【DPI switch button】 to cycle through six DPI gears.



·POWER SAVING MODE

The mouse will go to first level Auto-sleep mode after 5 minutes of sitting idle and go to second level Auto-sleep mode after 15 minutes of sitting idle. Press any botton to wake it up.

·CHARGE



·When the 【Indicator light】 flashes red, please charge the mouse in time.
·Connect the mouse to the computer through the equipped USB cable to charge the mouse. During the charging process, the 【Indicator light】 will flashes red, and be green when fully charged.

⚠ CHARGING INSTRUCTIONS

1. It is recommended to only use the computer USB interface to charge the mouse;
2. Do not use a fast charging mobile phone charger to charge the mouse;
3. Do not use inferior non-standard power adapters to charge the mouse;
4. Do not use an overvoltage and overcurrent power adapter to charge the mouse;
5. Please stay away from high-temperature equipment when charging.
6. Please turn off the power switch when not in use for a long time.

The above charging instructions also apply to other devices with charging functions (keyboard/mouse/headphones/speakers, etc.)

·SPECIFICATIONS

Model: G3
Charging current: 0.35±0.05A
Charging voltage: 5±0.25V
Charging interface: Type-C

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARRANTY CARD

Thanks for your purchase，Please contact us if you have any quality issue with the product during the warranty period，Please provide this warranty card so that we can serve you better。

Model: _____　Username: _____
Serial number: _____　Warranty address: _____
Purchase date: _____　Warranty contact: _____
purchase address: _____　contact number: _____
Seller: _____　Zip code: _____

CERTIFICATE OF APPROVAL

Executive standard: GB4943.1-2022