





- 1、Align Center
2、Align center on the side without button

The side with ANC button move 1mm up
when align center

Silkscreen:
Black 430U

