


Karaoke microphone instruction manual




Welcome

Thank you for choosing to purchase our karaoke microphone. This microphone is equipped with advanced technology and strong compatibility, so you can easily enjoy the fun of practicing songs anytime and anywhere by simply connecting it to your audio playback device. We wish you a wonderful experience!

Function


This karaoke microphone speaker kit features 1-Wire communication technology, allowing you to easily enjoy singing through mobile karaoke, Bluetooth connection, or wireless accompaniment. It's compatible with both Apple and Android smartphones, so no matter which system you use, you can still enjoy it!



- ①-key:
Short press - Volume decrease
Long press - Previous song
- ② Mode key:
Short press - Transfer the color light effect
Long press - turn off the light
Double click - switch mode (Bluetooth TF AUX)
- ③-key:
Short press - Volume up
Long press - Next song
- ④ ON/OFF Key
Short press play/pause
Long press on/off
- ⑤ Indicator light:
Charging (red light)/Bluetooth (blue light)
- ⑥ Type-c
- ⑦ Headphone connector
- ⑧ TF card slot

Support Bluetooth connection to play music / support TF card to play music / karaoke sound reinforcement function / built-in reverberation sound effect function / headphone output function.

Function



- 1.Power on key : short press - microphone mute button means on/off
- 2.+key: short press - increase volume, long press - Reverb/ECHO increase
- 3.-key: short press - decrease volume, Long press - Reverb/ECHO Subtract
- 4.Microphone key : Short press - Accompaniment original song switch
Long press-Microphone sound effect mode switch (Reverb - Echo - Female to Male -Male to Female - Laurie sound - Magic female voice - Monster sound - Donald Duck -LittleYellow - Original sound)
Press and hold for 3S - Microphone sound effect switch to the first mode (soundcard space reverb mode)
- 5.Bluetooth / charging indicator : blue light / red light
- 6.Type-c : DC5V / charging

Instructions for microphone functions

Accessories



Loudspeaker box

Microphone



Type-c cable

Accessories

Loudspeaker box

Type-c cable



Instructions

Microphone

Instructions

Precautions for using speaker microphone

Switch on / off-

When the machine is turned off , the product starts automatically with the Chang An On / Off key . When the TF is not insertedwhen the card is used, it will enter the Bluetooth mode by default , and the voice prompt will be "Bluetooth mode"; Long pressThe ON /OFF key turns off the machine.

Bluetooth connectivity-

Open your phone's Bluetooth settings , search for the device name:KL01, and then make a pairing connection.After the connection is successful, there will be a prompt tone and the blue Light will always be on.

Mobile Playback-

After the Bluetooth connection is successful , open the mobile music player and download your favorite songs or the accompaniment can be played , and the volume can also be adjusted to the appropriate level on the mobile phone.

Tf card play-

Insert the TF card into the device , and the device will automatically play the music in the TF card.

Sound adjustment-

The volume of microphone and accompaniment can be adjusted through the buttons on the device control panel.

Charge-

Connect the standard charging line to the charger for charging. The red light is always on when charging , and it is full off.

Attention

1. Please disconnect the charger and turn it off before cleaning the machine.
2. Nonm ssionals are not allowed to disassemble the equipment by them selves to avoid machine failure and loss of warranty rights.
3. Please do not place the equipment in the direct sunlight to avoid premature aging of electronic parts.
4. Avoid using in places with flying dust or dirty environment (dust is easy to cause equipment failure)
5. Do not place the equipment in an excessively cold or overheated environment , which may cause the equipment to fail to operate normally.
6. It is recommended that the ambient temperature of the equipment used should not exceed-10°C-40C Which is relatively moderate 10%-95%.
7. Please do not put any objects into the equipment to avoid short circuit or circuit damage . Please do not spill any liquid on the product.
8. Avoid friction and collision between the machine and hard objects to avoid scratching ,falling off or other hardware damage.
9. The product shall not be exposed to the sun , fire or similar overheating environment.
10. It is forbidden to disassemble , impact , squeeze or put the product into fire.If the battery has serious failure , Do not continue to use.
11. This manual contains important information , please reserve it.

Bluetooth

- 1 . Press and hold the speaker power on key to start the machine , and the voice prompt "Bluetooth mode" will flash at the same time . Connectthe success blue light is always on.
 - 2 . Turn on the mobile phone Bluetooth and scan , search for the device , and then pair and connect , and you can hear it after connecting The device sends a successful connection tone.
 - 3 . After the microphone is turned on , it will automatically pair the speakers When the microphone is not paired , the blue light will flash , and the Bluetooth light will flashalways bright.
- Note : After the device is connected to the mobile phone once , Bluetooth has a memory function , and it will automatically connect when the phone is turned on , To disconnect , disconnect Bluetooth through the phone settings . If you listen to music only , you can turn the microphone volumeadjust to the minimum.

Sing K audio & microphone features

Intelligent anti squealing-

Sing loudly without howling within 10cm.

High radio sensitivity-

It is easy to sing with a 5-10cm microphonele. microphone is loud and has good sound quality.

Low latency-

he delay is less than 40ms.

AI functions-

5 kindsound effects ; One click to cancel the orginal sound ; Flexible adiustment of accompaniment reverberation and microphone volume.

Speaker

Bluetooth version : 5.3
Horn diameter : 57mm
Horn power : 6W
Working voltage : 3.7V
Frequency range : 20Hz-20kHz
Reverberation : echo sound effect reverberation
Power adapter : DC5V≤1A
(common with mobile phone charger)
Charging duration : 3.5-4 hours

Microphone

Pickup : back pole condenser microphone
Working voltage : 3.7V
Frequency range : 20Hz-20kHz
Power adapter : DC5V s 1A
(common with mobile phone charger)
Charging duration : about 2.5 hours

Information

Product name : mini karaoke microphone speaker set
Product model: KL01

Note : The company's products are constantly innovative and subject to change without notice

FCC WARNING

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modifica- tion is made.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful inter- ference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- The rating information is located at the bottom of the unit.

Note : The company's products are constantly innovative and subject to change without notice

INDUSTRY CANADA NOTICE

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présentappareilestconforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareildoit accepter tout brouillageradioélectriquesubi, même si le brouillageest susceptible d'encompromettre le fonctionnement.

CAN ICES-003(B)/NMB-003(B)