

1. If the ear canal is impacted with cerumen, use with caution and seek professional treatment at a hospital.
2. Do not use this product when there are people exercising or frolicking nearby to avoid accidental injury caused by collision.
3. Do not allow children to use this product alone to prevent accidental injury.
4. Do not place the device in liquids or humid environments to avoid product damage.
5. Do not expose the device to direct sunlight or heat sources for a long time to prevent product damage.
6. During use, the product temperature will rise slightly. This is a normal phenomenon, so you can use it with confidence.
7. To ensure safety during use, maintain a stationary posture continuously and do not shake.
8. To keep the ear canal hygienic and safe, replace the ear spoon cover or spoon head when it becomes loose or after more than 30 uses.
9. Do not use this product near precision instruments or professional electronic equipment to avoid interference.
10. Do not knock or drop this product. Stop using it if it is damaged due to collision or dropping.
11. Keep the product and its accessories out of the reach of children.
12. If not used for a long time, charge the product regularly.
13. Do not disassemble, modify or repair this product without authorization.
14. When cleaning the lens, it is recommended to gently wipe it with a cotton swab dipped in clean water. Do not use corrosive liquids such as alcohol (which may corrode the lens) or hard/sharp objects (which may scratch the lens).