


Instructions for Use

1



Scan Code Download APP



Rhythm Mode


Switch

Dynamic Mode

Smart Wi-Fi controller


2

Scan the QR Code to Download
the TUYA APP



3


Long press the switch button 8s until the light flashes red (keep pressing it until the red light flashes to release)




4

Network Configuration 1: Click the "+" sign to add a device

Click on the "+" sign




Select Add Device



5 Network Configuration 1: Click Add

Click "Add"




6

Network Configuration 1:
Input your wi-fi password and
wait seconds to pair



7 Network Configuration 1: Currently matching Wi-Fi, Wait 5 seconds to complete matching



1


Network configuration 2: Press and hold the "ON" button until the red light flashes

Press and hold the "ON" button for 8 seconds




2 Network Configuration 2: Click the "+" sign to add a device

Click on the "+" sign




Select Add Device



3 Network Configuration 2: Click Add


Click "Add"



4

Network Configuration 2:
Input your wi-fi password and
wait seconds to pair

Your Home/Office Wi-Fi
Name and Password



The image shows a smartphone screen with a Wi-Fi configuration interface. At the top, the status bar displays the time 13:52, signal strength, and battery level. The main heading is "Enter Wi-Fi Information" with a subtitle "Choose Wi-Fi and enter password". There are two input fields: "Wi-Fi Name" with a Wi-Fi icon on the left and a copy icon on the right, and "Wi-Fi Password" with a lock icon on the left and a copy icon on the right. Both fields contain masked text. At the bottom, there is an orange "Next" button.

13:52

Enter Wi-Fi Information

Choose Wi-Fi and enter password

Wi-Fi Name

Wi-Fi Password

Next

Network Configuration 2:

5

Currently matching Wi-Fi, Wait 3-5 seconds to complete matching

