

Quick Guide

Model: Z05

View the quick setup guide
Scan QR



Tips: Please make sure that the router is turned on and able to access the Internet before setting!

Step 1

Please turn off cellular data at the beginning of the installation. Plug the Extender into a power outlet near your Router. ([Recommended within 20 feet](#))

Step 2

Go to your Phone settings. Open WiFi, and turn it on. Search for the network name "[Extender-2.4G-xxxx](#)" and click on it to connect



Step 3

Wait for the management page to pop up automatically and click the "Start" button to proceed to the next step, If the management page does not pop up, please open a web browser and input:


192.168.8.1



or scan QR Code:


Step4

Click the "Next" button to proceed to the next step,
The default initial login password is "admin"



Step 5:

Default Repeater Mode, click "Next" to proceed



Step 6

Select the existing network you want to extend and click "**Next**", e.g. My router. If your home WiFi does not appear, please refresh it several times.



Step 7

Enter your existing network password in the password field and click "**Next**"; confirm that the current configuration information is correct and click "Save"



Step 8

Please note: Directly return to the WiFi page without clicking on "More Settings", otherwise the settings will fail



Step 9

The new WiFi SSID defaults to the "router name_Ex". Enter the same password as the main router to connect and access the network.




Get✓✓

When the steps are complete, your Extender automatically reboots. Place it in the best location for better service(halfway between your router and the Poor signal area.)

!!!

The Extender's default name is your router name_Ex , e.g. My network_Ex .The password remains the main router password.



METHOD #2 CONNECT WITH WPS (IF SUPPORTED BY YOUR ROUTER)

Step1

Plug your WiFi extender into an outlet near your router, then wait for the wireless LED to turn on and stay solid. (Recommended within 20 feet)



Step2

Press the WPS button on your main router for 1-2 seconds.




Step3

Within 30 seconds press the WPS button on the Extender for 1-2 seconds.



Step4

After 30 seconds, a network will appear. The new WiFi SSID defaults to the "**router name_Ex**". The network will have the same password as your current network.



Step5

Move the Extender to the best position which is halfway between your router and the area that has poor WiFi signal.
Congratulations! The WiFi extender has been set up and you can go online.

HOW TO RESET THE REPEATER

Use reset needle press and hold the RST hole on the right side of the WiFi extender for 5-8 seconds until the light flashes to restore factory settings. (WHILE STILL PLUGGED IN)

1. My WiFi says connected but I have no internet connection.

- If the WiFi is connected, but there is no internet, check that the router's WiFi is actively working and try to restart the router.
- Check the status of the WiFi indicator light. If it stays on, it means it is connected to the router successfully, and it might be more of an IP conflict. You can try to Wireless Bridge Mode so that the devices connected to both routers can interact with each other.

2. Why does the internet speed drop when connecting to the extender?

- The WiFi Extender supports 2.4G networks and not 5G.
- The WiFi Extender is used to extend the range of your WiFi (which your main router WiFi can't cover). It does not increase internet speed.
- Sometimes, the signal (coverage or speed) drops due to external influences--a microwave oven, nearby cell towers nearby, a neighbor's WiFi on the same channel, walls, and partitions in a building made of certain materials blocking a WiFi signal.
- Try the Extender in different positions: place it at different angles or locations for a better signal.

3. Why are some devices at home (printer, CCTV camera, TV, iPhone) unable to connect to the Extender?

- This means the device does not recognize the Extender.
- The device should be in the same network as your router. You may set up the Extender in Wireless Bridge Mode to see if it will work.

4. What is the user name and password for setting up the Extender?

- After setting up, connect to the new WiFi name "router name_Ex" The password is now the same as your WiFi main router.

5.How far should the Extender be from the router?

- It should be between the router and the area with a good signal. The position must be able to receive a good WiFi signal from the router.

6. Does the extender work with 5G?

- No, only with 2.4G.

7.Why am I unable to enter the web page?

If you cannot open the web page, follow these steps:

- If access fails, please check if the correct SSID "WiFi Extender-xxxx" is connected.

If you are still unable to open the webpage, please check and try these:

- Check if you are connected to the WiFi extender during setup. This is necessary because before connecting to the router, the WiFi Extender should have no internet access. Your mobile will usually auto-connect to the other WiFi or ask if it is connected to the present WiFi or not. You must be connected to the WiFi Extender during setup.
- Please press and hold the RST button of the WiFi Extender for 5-8 seconds to reset it to restore factory settings. Set up the extender again.
- Disable your mobile's data during setup.
- Use another mobile phone to try.

GUARANTEE

- **IMPORTANT:** All WiFi extenders on the market are designed to increase or improve WiFi coverage. That means It can improve the locations which are getting weak signals from your router and **NOT TO INCREASE WIFI SPEED**
- According to the laws of physics, WiFi Extenders will always be slower than your existing router. This is because the WiFi extender has to split its bandwidth between the router.
- **Note!** Based on 380 000+ sold units, the extender may not be effective or doesn't work in 3% of cases due to interference or incorrect setup.
ONE OF THEM? Contact our friendly customer service team. We'll give a full money refund or a replacement and you can keep the old product to avoid to hassle of shipping the product back.

WARNING

1. Keep the device away from water, fire, humidity or hot environments.
2. Do not attempt to disassemble, repair, or modify the device.
If you need service, please contact us.
3. Do not use the device where wireless devices are not allowed.
4. The socket-outlet shall be installed near the equipment and shall be easily accessible.

5. For pass through devices, plug the power strips into the integrated electrical sockets of the devices, but devices of the same or another type not be stacked in normal use. Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device, Please use this product with care and operate at your own risk.

FCC Statement

15.105

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

KDB447498 D01 v05r02 (P5)
FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

15.19
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 / KDB784748 D01 v08 (P4)

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Scan the QR code with the camera to watch how
to setup the WiFi Extender



RECOMMEND



ALTERNATIVE