


Sonic electric toothbrush

BM03

Instruction manual

Safety Precautions	2
Parts Names and Included Items	7
Charging	8
About Modes	9
Basic Usage	10
Brush Sterilization with UVC-LED	12
Maintenance	13
Replacing the Brush Head	14
Storage	14
Disposal	14
Specifications	15
Contact Information	15
Warranty	16



- Please read this instruction manual carefully and use the product correctly.
- Keep the instruction manual in a safe place and refer to it when necessary.
- Be sure to read the "Safety Precautions" before use.

Safety Precautions

This section explains important guidelines for the correct and safe use of the product.

Be sure to read these instructions before use and follow the provided information for proper operation.

Indicator Meanings

 WARNING	Indicates potential risk of death or serious injury ^{※1} if handled improperly.
 CAUTION	Indicates potential risk of minor injury ^{※2} or physical damage ^{※3} if handled improperly.

- ※1 Serious injury refers to cases such as blindness, wounds, burns (high temperature, low temperature, chemical), electric shock, fractures, poisoning, etc., that leave aftereffects or require hospitalization or long-term outpatient treatment.
- ※2 Minor injury refers to wounds, burns, electric shocks, etc., that do not require hospitalization or long-term outpatient treatment.
- ※3 Property damage refers to expanded damage related to houses, household goods, livestock, pets, etc.

■ Power Instructions

WARNING

- Use with AC 100-240V.
- Do not damage the plug or charging cable.
Do not process, forcibly bend, pull, twist, place heavy objects on, pinch, or bring near high-temperature areas. May cause fire or electric shock.

- Do not plug or unplug with wet hands. May cause electric shock.
- Insert the power plug all the way in.
- When unplugging, hold the plug to pull it out - do not pull on the cord.
- Regularly remove dust from the power plug. May cause fire.
- Do not use if the power plug/charging cable is damaged, or if the charging cable or outlet connection is loose.
- May cause electric shock, short circuit, or fire.

■ Power Instructions



WARNING

- Do not disassemble or modify the product.
- This product requires supervision when used by persons with physical, sensory or mental disabilities, or those lacking experience/knowledge (including children).
- Do not charge with the charging cable bundled or coiled.
- Do not charge in wet areas (such as bathrooms) or humid locations.
- Do not submerge the charger in water or wash it.
- Children must be supervised by a guardian when using this product.
- Only charge using the charger included with this product.

- If any abnormality or malfunction is observed, immediately stop using or charging the product and disconnect the charging cable from the main unit. May cause fire or electric shock.
- Do not use the product for purposes or methods not described in this instruction manual.
- Consult your dentist before use if any of the following apply to you:
 - You have implanted medical devices such as pacemakers
 - You have abnormalities in your mouth such as gum problems
 - You have allergic tendencies
- If itching, redness, or hives occur during use, stop using immediately and consult your dentist.
- Do not insert metal objects such as pins or wires, or any foreign objects into gaps between the main unit or any connection parts.
- May cause electric shock, injury, or malfunction.
- Do not store the product within reach of infants.
- Prevent infants from playing with the product.
- Keep away from flames, stoves, or other heating appliances.
- May cause fire, electric shock, or malfunction.
- Do not use, store, or leave the product in high-temperature locations such as near open flames, in direct sunlight, or in hot vehicles exposed to sunlight.
- May cause ignition, battery rupture, or overheating.

- Do not dispose of the product in fire.
May cause fire or battery explosion.
When disposing of the product, please consult the retailer where you purchased it or the customer service center.
- If liquid leaking from the battery gets into your eyes, do not rub them. Rinse thoroughly with running water and seek immediate medical treatment.
May cause permanent eye damage.
- Do not touch any leaking battery fluid.
- If liquid from the battery comes into contact with skin or clothing, rinse immediately with running water.
May cause skin irritation.
- When cleaning the charger, always unplug the power plug from the outlet.
May cause electric shock, short circuit, ignition or fire.
- Disconnect the charging cable from the charging dock when not charging.
May cause electric shock or fire due to insulation deterioration.
- Do not use or charge the product in areas where flammable gases may be present.
May cause explosion or fire.




CAUTION


- Do not use if you have reduced sensitivity in your oral cavity.
May cause damage to your mouth.
- Do not share the brush head with others.
- Do not use toothpastes containing high amounts of abrasive agents (such as those for tobacco stain removal or whitening).
May damage your teeth.
- This product is for household use only. Do not use for commercial purposes or outside normal household settings.

Parts Names and Included Items


■ Main Unit × 1




■ Brush head × 2



■ USB charging plug × 1



■ Charger × 1



■ Storage case × 1



■ USB cable × 1



Charging Instructions


1 Insert the main unit straight into the charger.

2 Connect the charger's USB plug to your power adapter.

3 Plug the power adapter into an electrical outlet.

Charging Indicators:

- During charging:
Red blinking light
- When fully charged:
Green steady light





WARNING

Do not charge in places where water may be present, such as bathrooms, or in humid areas.

Mode Selection:

Each press of the operation button cycles through the following modes.

Please use your preferred mode:




Basic Usage Instructions

1

Attach the brush head to the main unit.

Align the brush head with the front of the unit and insert it straight.



2

Apply an appropriate amount of toothpaste to the brush.

3

To prevent toothpaste splatter, place the brush in your mouth first, then press the operation button once to turn on the power.

4

Press the operation button to switch to your preferred mode.



**KEY
POINT**

During initial use, you may experience a ticklish or unusual sensation, but you will become accustomed to it after several uses.


5

Gently place the brush so that the bristles lightly touch the teeth and move it slowly.

For the gum pockets and the border between teeth and gums, position the brush at a 45-degree angle so that the bristles enter the gum pockets, apply light pressure, and move slowly.

6

As shown in the diagram, divide the mouth into four sections—upper and lower, left and right—and spend about 30 seconds brushing each section in the following order:



Example brushing sequence:

① Outer surfaces of teeth → ② Chewing surfaces → ③ Inner surfaces of teeth.

Repeat the same process for the remaining three sections.



**KEY
POINT**


Every 30 seconds, the brush will automatically pause briefly to indicate the optimal brushing time for each area.

- The recommended brushing time is 2 minutes, but you may continue brushing if certain areas require more attention.
- You may brush your tongue while the power is on if desired. However, for more thorough cleaning, we recommend using commercially available tongue brushes or tongue cleaners.
- This product can be used during orthodontic treatment, though brush head wear may accelerate in such cases.
- First-time electric toothbrush users should begin brushing from the lower molars, where vibrations are less likely to cause discomfort. Let the electric toothbrush do the work - avoid applying pressure.

UVC-LED Brush Sterilization

Connect the storage case to a power source using the USB cable and close the lid to sterilize the brush head inside the case.

- The UVC-LED will illuminate during sterilization.
- (UVC-LED lifespan: approximately 10,000 hours)



Cleaning & Maintenance

Please clean the product after each use.

Important Notice

Do not use volatile organic solvents including benzene, thinner, alcohol, or similar substances. May cause discoloration, deformation, or product malfunction.

Main Unit Cleaning


After removing the brush head, rinse with water.

Important

Do not damage or scrub the waterproof rubber seal on the connection port with hard objects.

Brush Head Cleaning

After each use, remove the brush head from the main unit and thoroughly rinse away any debris from the bristle area and base surface with water.



Charger Maintenance

Unplug the USB plug and wipe off any dirt with a dry cloth.

Brush Head Replacement

To maintain optimal plaque removal performance, we recommend replacing the brush head every 3 months.

Storage Instructions

Do not store in the following locations:

- Areas with high temperature/humidity
- Areas exposed to oil fumes or steam
- Outdoor areas or direct sunlight
- Near flames or heat sources
- Dusty areas
- Within reach of children or pets

Disposal Instructions

This product contains lithium-ion batteries. Lithium-ion batteries are valuable recyclable resources.

When disposing of this product:

- Always follow your local government/municipality's regulations
- Dispose using proper methods



Li-ion

Specifications

Product Name	Sonic electric toothbrush
Battery	Lithium-ion battery 3.7V 1100mAh
Charging Voltage/Current	5V/0.5A
Charging Time	Approx. 8 hours
Dimensions	Main unit (excluding brush head): 26.5mm × 26.5mm × 176mm Charger: 47.2mm × 47.2mm × 30mm
Weight	Main unit (excluding brush head): 94.4g Charger: 63.2g
Included Accessories	Brush heads × 2 Charger × 1 Storage case × 1 USB cable × 1

Contact Information

Oralic Supplies Inc
Los Angeles, CA 90049
cs@brushmo.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.