


Warning

- Do not attach a long lany holder and do not operate the knob while riding.
- There is a risk that it may get caught in the spokes and cause you to fall.

Attention

- Keep fingers clear of knob turn path when unlocking to avoid injury.
- Reverse Procedure: While unlocked, press and hold release button until blue light turns off.
- Pre-Ride Inspection: Check for loose screws and proper knob operation before each use.



Fast, Superhuman, and Affordable.

- Control your lock with smartphone app
- Compatible with 99% of locks
- Share access via QR code
- Open Bluetooth API
- Unlock Sesame with a fingerprint
- IPX4 water-resistant

Federal Communications Commission (FCC) Statement This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions:
1) This device may not cause harmful interference, and
2) This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15.107 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment operates on a non-licensed radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Note: Changes or modifications made to the device not expressly approved by the manufacturer may void the user's authority to operate the equipment. This equipment is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.
This device complies with FCC RF radiation exposure limits set forth for portable communications devices. The device is tested and certified without restriction.

Irishima, 9-8, 1st chome, Irishima, Chuo Ward, Tokyo <https://jp.candyhouse.co>

@candy_house_jp

sesame@candyhouse.co

CANDY HOUSE JAPAN Co., Ltd

5th floor, Piano Arc

Irishima, 9-8, 1st chome, Irishima, Chuo Ward, Tokyo <https://jp.candyhouse.co>


@candy_house_jp

sesame@candyhouse.co

CANDY HOUSE JAPAN Co., Ltd

5th floor, Piano Arc

Sesame Bike3



Sesame Bike3

Combine it with other devices and enjoy Sesame even more.

- ※The following functions cannot be used with Sesame alone.
- Unlock Sesame with IC cards such as Suica
- Operate from Apple Watch Operate via iPhone / Google Assistant / Siri Remote operation
- Unlock Sesame with a PIN code
- Via WiFi module for remote access