

时间的时钟设置  时间的分钟设置  功能设置顺序，设置步骤 参考上图时钟和分钟的设置 1.时间的时钟设置 2.时间的分钟设置	3.闹钟的时钟设置 4.闹钟的分钟设置 5.年份的设置 6.月份的设置 7.天数的设置 12小时制和24小时制设置： 待机状态下按 键时间切换，默认是24小时制 闹钟开启和关闭闹铃： 长按2秒 键进行切换 华氏度和摄氏度的设置： 待机状态下按 键进行温度切换，默认为摄氏度
---	---

Alarm clock hour setting  Minute setting  The following is the function setting sequence , the setting steps refer to the above picture 1.Hour Setting 2.Minute Setting	3.Alarm Hour Setting 4.Alarm Minute Setting 5.Year Setting 6.Month Setting 7.Day Setting How to set 12 hour or 24 hour display Press 键 to switch between 12 and 24 hour mode Alarm setting (open and close) long press two minutes 键 to switch Fahrenheit and celsius setting In standby mode press the 键 to change the temperature, the default is celsius.	FCC WARNING This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user 's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC ' s RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.
--	---	--