


1. Asset5 Quick Start Guide

Make sure that you have:

- Smart Device: Android or iOS
- Tools for installation: a pry tool, zip-ties or double-sided tape.

Device Overview






1	Multi-function Button	2	Housing Cover
3	Housing	4	Battery
5	ON/OFF Switch	6	LED Indicator



7	SIM Card Slot	8	Tamper Button
---	---------------	---	---------------



Indication LED Patterns

Colour	Pattern	Description
Green	Blinking once in 0.4s	Bluetooth is advertising
	Always ON	Bluetooth is connected
Red	Blinking once in 0.4s	Modem is connected
	Blinking once in 5s	Modem in sleep mode
	Always ON	Modem trying to connect or when link to the server is open

Device preparation and Configuration

1 Disassemble by prying the cover off evenly from both sides of the cover. Use a plastic pry tool. Once the cover is sufficiently open, take it off by hand: 	2 Insert your SIM card (Nano SIM format): 
3 Turn ON the switch: 	4 Align GNSS antenna to the front of housing and assemble the Device: 
5 Download and install mDMP on you Smart Device: Android (link) iOS (link)	6 Press Multi-function button on the Device for 1 second to start BLE advertisement:


1 Disassemble by prying the cover off evenly from both sides of the cover. Use a plastic pry tool. Once the cover is sufficiently open, take it off by hand: 	2 Insert your SIM card (Nano SIM format): 
	
7 Open mDMP on your Smart Device and connect to Asset5: Default PIN is the last 6 IMEI digits.	

1 Disassemble by prying the cover off evenly from both sides of the cover. Use a plastic pry tool. Once the cover is sufficiently open, take it off by hand: 	2 Insert your SIM card (Nano SIM format): 
	


1 Disassemble by prying the cover off evenly from both sides of the cover. Use a plastic pry tool. Once the cover is sufficiently open, take it off by hand:



2 Insert your SIM card (Nano SIM format):



3 Upload configuration to Asset5:



Installation

Install the device with the label positioned upwards, make sure it is not covered by metal.


The internal antennas are very sensitive to the device's positioning. Wrong placement will result in reduced tracking accuracy!

Follow the recommendations:

- It is allowed to tilt up to 45 degrees on any axis, but the top surface in all cases must be facing up
- Install behind the dashboard
- Install as close to the windshield as possible
- Avoid installing near metal surfaces
- Do not install the device near heat emitting or moving parts

Fasten the device in the vehicle using zip-ties, double-sided tape or use [Asset5 Holder](#)

Make sure it is secured tightly.



Check in the server if data is received.

Certification information

FCC	Federal Communications Commission (FCC) Interference Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. RF exposure warning This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.
-----	---