



产品概览



蓝牙连接



机器开机后，两台设备短按对讲键，进入对讲模式，绿色LED灯快闪，并伴有提示音“对讲配对”，配对成功后会有提示音提示配对成功“对讲已连接”，此时就可以两人对讲通话。

对讲连接成功模式下：长按音量加/减键调节对讲音量加大/减小；

对讲跟蓝牙可独立工作,互不影响,当对讲跟蓝牙都连接后,两者声音可混合出来到喇叭端,可同时听到两个模式的声音。


当对讲连接成功后,音量加加减操作如下:①短按音量加加减调节蓝牙音乐音量大小;
②长按音量加加减调节对讲的音量大小;③双击音量加加减切换蓝牙音乐的下一曲和上一曲

说明书

1. 请勿将产品投入明火中, 避免发生爆炸;
2. 请勿拆卸产品, 避免产品电子器件损坏;
3. 请勿靠近尖锐器物对产品造成损坏;
4. 长时间不用, 请放置干燥处;
5. 使用蓝牙设备前, 请先将其充满电;
6. 如果充电时红灯不亮, 可能是电压过低;
7. 为了延长内置聚合物电池的使用寿命, 请每月至少为设备充电一次。

R1 Quick instruction manuals

Product Overview




IMPORTANT REMINDER:

Before installing the headset, please connect your mobile phone according to the guidelines in the quick manual to test the sound effect and volume.


If there is a big difference in sound effect and volume after installing into the helmet, please adjust the position of the speaker inside the helmet.

Power on/off

Double-tap to toggle voice announcement
(Disconnect Bluetooth)




On/Off Beep



LED flash

Press and hold for 3 seconds to turn on/off

Bluetooth connection




Bluetooth mode tone



Bluetooth pairing is successful:
LED light flashes slowly


Bluetooth waiting for pairing:
LED light blinks fast

Intercom pairing



Intercom pairing status:
Green light blinking fast

paired cue




Intercom pairing is successful:
Green light is on.

After the machine is turned on, the two devices short press the intercom button, enter the intercom mode, the green LED light flashes, and accompanied by a prompt tone "IntercomPairing", after successful pairing, there will be a tone prompting successful pairing "intercom has been connected", at this time you can two people intercom call. In the mode of successful intercom connection: long press the volume up/down key to adjust the intercom volume up/down;

Telephone function

Double-tap to toggle manual/automatic answer
(when Bluetooth is not connected)



Automatic
(5s after 15 seconds)



answer the phone



Manual answer
"short press"



answer the phone



(Incoming call)



decline to answer
the phone



(On the phone)



"Short press"
during a call



end a call



double-click



final code redial




short press



(on de-energization)

Cancel call

Voice assistant



(Under successful Bluetooth pairing status)
Long press to wake up voice assistant



(depending on mobile phone)
Long press again to exit

Music function



short press



(music pauses)



playable



(music playing)



pause



Volume-Key



(music playing)
Intercom not connected




Short press
on a song



(music playing)



Long press
volume down



Volume + key



(music playing)
Intercom not connected



Short press
on the next song




(music playing)



Long press
volume up


Mixing function



Bluetooth connection
successful



Intercom and Bluetooth are paired successfully.



navigator intercom concert

Intercom and Bluetooth can work independently of each other, do not affect each other, when the intercom and Bluetooth are connected, the two sounds can be mixed out to the speaker end, you can hear the sound of the two modes at the same time.

When the intercom is connected successfully, the volume up and down operation is as follows: ① short press volume up and down to adjust the volume size of the Bluetooth music; ② long press volume up and down to adjust the volume size of the intercom; ③ double-click volume up and down to switch the Bluetooth music of the next song and the previous song

Intercom reset

Bluetooth Intercom Connection Operation Overview (Intercom is disabled by default at startup)

1: Intercom Reconnection

For devices that have been previously connected, press the intercom button briefly after startup to enter intercom mode, and the two devices will automatically connect.

2: Clear Pairing and Restore Factory Settings

When the device is turned on without Bluetooth or intercom connected, simultaneously press and hold the volume down and volume up buttons for 5 seconds to clear all pairing information and restore factory settings. The blue and green lights will flash rapidly to indicate this.


3: Light-off mode

Simultaneously press the intercom button and volume up button to turn off all lights. Press both buttons again to turn them back on (default setting is on).

4: Phone priority function

Phone call answering: When both devices are connected via intercom and Bluetooth is connected to the phone, if a call comes in, the system will automatically switch to phone call answering mode. After hanging up, intercom mode will resume.

Press and hold 5S
at the same time,
will clear all pairing information.




Product List


R1 main unit*1




Speaker Microphone*1




Clip-on base*1



Velcro installation kit*1




Type-C charging cable*1




Instruction manual*1


Charging function



Charging red light is always on



(Plug in the charger to charge the machine while it is on and the machine will automatically shut down)



Full red light off

Caveat

1. Please do not put the product into the open fire to avoid explosion;
2. Please do not disassemble the product to avoid damage to the product's electronic devices;
3. Please do not close to sharp objects to cause damage to the product;
4. long time not used, please place in a dry place;
5. Before using the Bluetooth device, please fully charge it first;
6. If the red light does not come on when charging, it may be the voltage is too low;
7. In order to extend the service life of the built-in polymer battery, please charge the device at least once a month.

Warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.
- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.