

POWERSHOT

USER MANUALS





Choose your language

English

Deutsch

Español

Français

Click on one



Software notice

PowerShot by Kiiroo is to be used with the authorized FeelTechnology Software.

Downloading any third-party applications to control or interact with the PowerShot that are not mentioned above is done entirely at your own risk.

If a third-party application is downloaded, and it damages either the device software or hardware or leads to personal injury, neither Kiiroo, FeelRobotics nor any of their partners will be held liable.

Hardware notice

PowerShot was designed to be used alone or with compatible Kiiroo toys. The usage of any third-party hardware product in combination with PowerShot and violates the terms of usage and warranty, and Kiiroo will not be liable for any damage sustained.

National deviation 7.12.Z1

This appliance contains batteries that are non-replaceable.

For a part of class III construction supplied from a detachable power supply unit, the instructions state that the appliance is only to be used with the unit provided.

The appliance is not to be used by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction.

Kiiroo and FeelRobotics are constantly working to ensure their hardware and software are as secure as possible.

We recommend updating your app and device firmware every time there is an update. Keeping your device and app versions up-to-date ensures you have the newest features and guarantees your safety.

Logo usage

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.

Google Play and the Google Play logo are trade marks of Google Inc.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Kiiroo is under license.

Other trademarks and trade names are those of their respective owners.

Table of contents

Setting up your device	5
Charging and LED indicator	6
Modes	7
Bluetooth mode	
Custom mode set up	
Manual modes	
FeelConnect & Services	12
Ways to use PowerShot	13
Handling	15
Lubrication	
Disclaimer and warnings	16
Disposal specifications	17
Aftercare and help	18
Specifications & FAQ	
FCC statement, ISED statement	19

Set up your device

Using the magnetic USB charger provided, charge your device for about 1 hour 45 minutes until the LED light turns **solid green**.

**We recommend charging the device fully prior to the first use. The charging port can be found on the PowerShot (see picture).*

While your device is charging

Download the FeelConnect App so you are ready to pair your PowerShot with your mobile phone once it is charged.

Magnetic Charger





CHARGING AND LED INDICATOR

Insert the USB cable into a wall charger/charging port. The other end of the charging cable is magnetic and attaches to the magnets located in the front of the PowerShot.

Please note, a wall adapter is NOT included in the box.

We recommend using a wall adapter to fully charge your PowerShot in about 1 hour 45 minutes. A computer USB port delivers limited current and can exceed that time.

The LED light on PowerShot indicates the battery level and charging progress.



When the LED indicator blinks red, the battery is approximately 20% charged.



When the battery is over 20% but lower than 50% charged, the LED indicator will blink orange.



When the battery is over 50% but lower than 80% charged, the LED indicator will blink yellow.



When the battery is 95% charged, the LED indicator will blink green.



The LED light will turn solid green when PowerShot is fully charged. Please disconnect the charger before use.

POWERSHOT

MODES

Quick start

To turn on PowerShot, press and hold the **Multifunctional button** in the front (approximately 3 seconds) until the device turns on.

When PowerShot is turned on, it automatically enters Bluetooth pairing mode, indicated by a blinking blue light. To access manual mode, click once—manual mode is indicated by a purple light. Continue clicking to cycle through the five preset manual modes or return to Bluetooth mode.

To turn off PowerShot, press and hold the **Multifunctional button** (approximately 3 seconds) until the device turns off.

Multifunctional Button



POWERSHOT


MODES

Bluetooth Pairing Mode - indicated by a **blinking blue light**

To use PowerShot with a partner or interactive webcam, please download the FeelConnect app on your mobile phone and follow the instructions on screen to pair your PowerShot to the app.

When PowerShot is turned on, the LED light will blink blue, indicating that PowerShot is in Bluetooth Pairing Mode and ready to pair with the FeelConnect app.

Follow the onboarding instructions in the FeelConnect app to connect and set up your PowerShot. Once you are paired with the app, the LED light will turn solid blue.



Please note: When PowerShot connects to the FeelConnect app, you may be asked to complete the wireless firmware update. After completion, PowerShot will turn off. Simply turn it back on by holding the Multifunctional button for 3 seconds, and it's ready to use.

We recommend you always update your PowerShot firmware when prompted and do not skip.

POWERSHOT

MODES


Custom Mode - indicated by a yellow light

Once connected to the FeelConnect app, you can create a custom mode and save it directly to your PowerShot. After saving, you can disconnect from the app and use your custom mode offline, just like a manual setting.

Connecting to the FeelConnect App

Make sure your PowerShot is in Bluetooth pairing mode—this is indicated by a blinking blue light. Open the FeelConnect app and select **“Connect New Device”**. Choose PowerShot from the list of available devices and follow the prompts to connect.

Once paired, select **“Test Connection”** to confirm that your PowerShot is successfully linked. When the connection is confirmed, you'll be prompted to set up a custom mode. Tap **“Let’s Get Started”** to begin designing.




POWERSHOT

MODES

Setting up your custom mode

Choose a preset pattern or design your own, and set the vibration intensity as instructed in the app. You can assign a name to each custom mode you create, and save one to your PowerShot for offline use.



Using Custom Mode Offline

Once you've designed your custom mode, select “**Save to Toy**”. This stores the pattern directly on your PowerShot, so you can access it without connecting to the app. To use it, turn on your PowerShot and press the button once. You'll know you're in **Custom Mode** when you see a blinking yellow light.

After setting up custom mode

3 secs click

To turn PowerShot On/Off

Press and hold the Power/Mode button.



Bluetooth Mode

Your PowerShot is ready to connect to the FeelConnect app.

1 click



Custom Mode

Your PowerShot is now running your saved custom mode.

Clicking the Multifunctional Button again switches to Manual Mode, shown by a purple light.

POWERSHOT

MODES

Manual Mode - indicated by a purple light

PowerShot has 5 preset manual modes that do not require the FeelConnect app. Once PowerShot is turned on, click the **Multifunctional Button** again to enter manual mode. The purple light indicates that you have reached the first manual mode.

Click the **Multifunctional Button** to cycle through the manual patterns.

Once you've cycled through all 5 manual modes, you'll reach Bluetooth pairing mode again, indicating by a blinking blue light. Just click once more to return to Manual Mode.

Pause/unpause vibrations - indicated by a blinking purple light

To pause or unpause the vibrations, double click the **Multifunctional Button**. Double click again to resume vibrations.



*To factory reset PowerShot, press and hold **Multifunctional Button** for 10 seconds until you see the light blinking light blue. Then, press the button for 1 second to turn PowerShot on again.*

This will delete your custom mode from PowerShot if you have set it up.

POWERSHOT

FEELCONNECT & SERVICES

Feel your partner via FeelConnect

Using the FeelConnect app, partners can control your PowerShot from anywhere in the world. This feature is great for long-distance couples, and for app-controlled play when you are out and about.



*Partners can control PowerShot remotely using the FeelConnect app or a compatible Kiiroo interactive device. To control partner devices, use the **Interact function** in the FeelConnect app.*

Ways to use PowerShot

PowerShot can be used on its own or combined with other devices in Kiiroo's modular line for an enhanced interactive pleasure experience.

1. **Solo:** Enjoy PowerShot alone with the included mini-sleeve.
2. **+ Stroker:** Attach PowerShot to the **Compatible Stroker Case (sold separately)** to use your favorite Kiiroo sleeves.
3. **+ Keon:** Put your PowerShot-enhanced stroker into Keon for automated, hands-free pleasure, that delivers synchronized stroking and vibrations.



POWERSHOT

WAYS TO USE POWERSHOT

4. **+ PowerBlow:** Add PowerBlow to your PowerShot-enhanced stroker and experience mind-blowing suction that syncs with your favorite scenes.
5. **The Final Combo:** For fully immersive pleasure, combine all elements: PowerShot, the Compatible Stroker Case, your favorite Kiiroo Stroker sleeve, Keon and PowerBlow. This gives you synchronized stroking, vibration, and suction for maximum pleasure.



4



5



HANDLING

Use

Kiiroo Lube or any other water-based lubricant for a more comfortable experience and to help prolong the lifespan of your PowerShot.

Do not use

Silicone lubricant, massage oils or hand creams in your mini-sleeve as it will deteriorate the skin-like sleeve material.

Cleaning

Always clean your sleeve thoroughly after each use.

1. Remove the mini-sleeve from PowerShot.
2. Rinse the sleeve with warm water and Kiiroo Pure™ intimate toy cleaner or a specialized toy cleaner and allow it to air dry.
3. Rinse the PowerShot with warm water and Kiiroo Pure™ intimate toy cleaner or a specialized toy cleaner and allow it to air dry.
4. Dry completely before placing the sleeve back in the PowerShot.
5. After your sleeve has air dried, use the FeelNew Renewing Powder over your sleeve so that it remains smooth and soft.

Hygienic silicone is an easy material to clean. It will last for years when taken care of properly.



DISCLAIMER & WARNINGS

- Do not use the PowerShot if there are exposed electronic elements.

The PowerShot is FULLY WATERPROOF.

- Do not use the PowerShot if it is excessively hot to touch.
- Do not use the PowerShot on inflamed or irritated areas.
- Avoid leaving your PowerShot in direct sunlight and never expose it to extreme heat.
- Never use cleansers containing alcohol, petrol or acetone.
- Do not use heating appliances to dry the sleeve or device.
- Avoid using harsh soaps as they can damage the sleeve material.
- Always store the device out of reach of children.

Warnings

We, as Kiiroo make no medical claims with our devices.

This device is not to be used by or on minors (anyone under 18), or anyone who is unable or unwilling to express consent. This device is not intended for persons with reduced physical, sensory, or mental capabilities, or a lack of experience and knowledge, unless they have supervision or instruction concerning use of the device by a person responsible for their safety.

Kiiroo will not be held responsible for any undesirable results of misuse.

POWERSHOT

DISPOSAL SPECIFICATION

While PowerShot is made from eco-friendly materials, you should not dispose of PowerShot in your waste bin.

Like any other electronic device with a rechargeable battery, there are disposal regulations.

These regulations vary by local municipality, city and by country. Be aware of how electronics are disposed of where you live.

Kiiroo suggests you ask your local council center.

Also, consider that in your locality, PowerShot may be considered bio-waste because of its intimate nature.



POWERSHOT

AFTERCARE AND HELP

Specifications

Materials:	ABS, Body-friendly silicone, TPE
Size:	77 mm L x 80 mm W x 68 mm H
Weight:	146 g
Charging:	1.5 hours
User time:	over 4.5 hours
Waterproof:	Yes

Help

If you have any further problems with setup and installation or issues with using your device, please do not hesitate to contact our Customer Support team. Our team is there for your support and to help, whatever it is you may need. We aim to answer all questions within 48 hours of your query.

For frequently asked questions visit

www.kiiroo.com/faq
www.kiiroo.com

Contact

info@kiiroo.com

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.