

ion

search and repeated testing, we have made for people with oral sensitivity:

- Design enables real-time observation of tooth cleaning
- Bringing an intuitive use experience.
- Design provides finer gears to adjust water pressure/SS/MASSAGE mode. To meet the needs of control it as they please, further improving

...ing power and gum protection: Innovative technology outputs high-frequency ultrasonic waves to clean the blind areas of the mouth such as the tongue. It is also equipped with 2-second timer. When the power is turned on, the water flow will be strong. Reduce the impact on gums and

...thoughtfulness: Subverting the capacity of a toothbrush, it is newly upgraded to a 350ml super capacity. The entire mouth design with one injection of water. The plug-in design makes it easy to grasp the device.

enance

...nderstand the usage and techniques of this device.

- Against your gums or teeth to avoid

...for children and infants. Please store this device in a dry place. Do not use it as a toy.

Periodontal disease patients or those who have had the device for the past 2 months, please consult your doctor before use.

...recommended to add anti-inflammatory drugs or mouthwash to the product, as this may cause damage to the product.

...This product can deeply clean the mouth and effectively remove the formation of tartar, but it cannot replace daily brushing and flossing.

1. Periodontal disease patients or those who have had the device for the past 2 months, please consult your doctor before use.
2. Recommended to add anti-inflammatory drugs or mouthwash to the product, as this may cause damage to the product.
3. This product can deeply clean the mouth and effectively remove the formation of tartar, but it cannot replace daily brushing and flossing.
4. Do not disassemble or replace product parts by yourself, damaging the product and invalidating the warranty.
5. Do not put hot water above 50 degrees Celsius into the device, clean your mouth to avoid burns.
6. Please check the product carefully before use. If the product is damaged, please replace it before use.
7. Do not put this product into fire or heat it, and do not use it in a high temperature environment.
8. Do not immerse this product in water for a long time, which may cause malfunction or risk of fire, electric shock, etc.

Instructions for use

Nozzle installation and removal:

●Install

Insert the nozzle into the hole in the fuselage. When you hear a popping sound of the plug-in button, it is installed in place.



ion

search and repeated testing, we have made for people with oral sensitivity:

- Design enables real-time observation of tooth cleaning
- Bringing an intuitive use experience.
- Design provides finer gears to adjust water pressure/SS/MASSAGE mode. To meet the needs of control it as they please, further improving

...ing power and gum protection: Innovative technology outputs high-frequency ultrasonic waves to clean the blind areas of the mouth such as the tongue. It is also equipped with 2-second timer. When power is turned on, the water flow will be strong. Reduce the impact on gums and

...thoughtfulness: Subverting the capacity of a toothbrush, it is newly upgraded to a 350ml super capacity. The entire mouth design with one injection of water. The plug-in design makes it easy to grasp the device.

enance

...nderstand the usage and techniques of this device.

- Against your gums or teeth to avoid damage.
- Do not use on children and infants. Please store this device in a safe place. Do not use it as a toy.

Periodontal disease patients or those who have had the device for the past 2 months, please consult your doctor before use.

...recommended to add anti-inflammatory drugs or mouthwash to the product, as this may cause damage to the product.

This product can deeply clean the mouth and effectively remove the formation of tartar, but it cannot replace daily brushing and flossing.

1. Periodontal disease patients or those who have had the device for the past 2 months, please consult your doctor before use.
2. Do not put hot water above 50 degrees Celsius into the device to clean your mouth to avoid burns.
3. Please check the product carefully before use. If the product is damaged, please replace it before use.
4. Do not put this product into fire or heat it, and do not place it in a high temperature environment.
5. Do not immerse this product in water for a long time to avoid malfunction or risk of fire, electric shock, etc.

Instructions for use

Nozzle installation and removal:

●Install

Insert the nozzle into the hole in the fuselage. When you hear a popping sound of the plug-in button, it is installed in place.



oral surgery within
se. It is not
thwash to the

rely prevent the
to clean the tooth

y yourself to avoid

the water tank and

power cord or plug

t charge, use or

to avoid

u hear the
ace.

• **Disassembly**

Press and hold the nozzle insertion and extraction button, gently pull out the nozzle, and store the nozzle.



⚠ When the product is running, it is prohibited to press the nozzle insertion and extraction button.

Nozzle Function

Visual nozzle	Standard nozzle	Large elbow nozzle
Observe the cleaning status of the dental cavity in real time	Suitable for daily cleaning of interdental debris and soft dirt	Suitable for cleaning residue and soft dirt on the inside of teeth
		



oral surgery within
se. It is not
thwash to the

rely prevent the
to clean the tooth

y yourself to avoid

the water tank and

power cord or plug

t charge, use or

to avoid

u hear the
ace.

• **Disassembly**

Press and hold the nozzle insertion and extraction button, gently pull out the nozzle, and store the nozzle.

⚠ When the product is running, it is prohibited to press the nozzle insertion and extraction button.

Nozzle Function

Visual nozzle	Standard nozzle	Large elbow nozzle
Observe the cleaning status of the dental cavity in real time	Suitable for daily cleaning of interdental debris and soft dirt	Suitable for cleaning residue and soft dirt on the inside of teeth

Install App

Step 1:
Download "SUNUO" App
(Android 4.4, iOS 9.0 or above are supported)
For IOS:
Download and install the App "SUNUO" from App Store.
For Android:
Download and install the App "SUNUO" from Google Play Store.
Optional:
Scan the QR Code below to download the App.







Step 2:
① Short press * CONNECT SMART DEVICES *



① POWER KEY
Long press the power switch

② FLASHLIGHT


WiFi is not connected to the mobile phone and the light is flashing

After the WiFi is connected to the mobile phone, the light is always on

③ Click 'Start connect'



Step 3:
Connect wifi name: "SUNUO" and click the "Connect"



Install App

Step 1:
Download "SUNUO" App
(Android 4.4, iOS 9.0 or above are supported)
For IOS:
Download and install the App "SUNUO" from App Store.
For Android:
Download and install the App "SUNUO" from Google Play Store.
Optional:
Scan the QR Code below to download the App.







Step 2:
① Short press * CONNECT SMART DEVICES *



① POWER KEY
Long press the power switch

② FLASHLIGHT


WiFi is not connected to the mobile phone and the light is flashing

After the WiFi is connected to the mobile phone, the light is always on

③ Click 'Start connect'



Step 3:
Connect wifi name: "SUNUO" and click the "Connect"



2. Keep the product in a horizontal state and pour water into the water tank from the water injection port.

3. After injecting an appropriate amount of water, close the water injection cap.

4. It is recommended to use warm boiled water or tap water below 40°C. Never pour mouthwash directly into your mouth. Never inject chemical products such as toothpaste, salt, solid mouthwash tablets, etc., otherwise they may become clogged or damaged.

Features:

1 Off button

Press and hold for 2S to
turn on/off
Short press to pause

2 Mode key

Switching between
FLOSS/MESSAGE modes

3 Power Indicator

The green light is always on when
the battery is sufficient, the red
light is flashing when the battery is
low, and the red light is always on
when charging.

4 FLOSS mode light

When working in this mode, the green
light is always on and flashes when
paused.

5 MESSAGE mode light

When working in this mode, the green
light is always on and flashes when
paused.

Kind

1. Mode selector dial
2. Power indicator light
3. Power button
4. FLOSS mode light
5. MESSAGE mode light

6 Gear switch

Pull it clockwise to increase the gear, and pull it counterclockwise to decrease the gear.

There are 7 levels in FLOOSS mode, with intensity options from 8G~9G-10G-11G-12G-13G-14G.

There are 5 gears in MESSAGES mode, with intensity options from 10G/6G---11G/6.6G---12G/7.2G---13G/7.8G---14G/8.4G


The gear switch is self-returning, with a 45-degree rebound swing in both clockwise and counterclockwise directions.



A beeping sound will be heard when increasing or decreasing gears. If it exceeds the minimum or maximum gear, there will be no "beep" sound when the switch is pulled out.

tips

1. Before use, it is recommended to then place the nozzle against the gum at the start button to start rinsing. It is closed when using it to avoid water spraying.

2. When using it for the first time, according to personal needs. Pull it once to adjust the rebound rotation. You need to release it after use.



Tips to use

1. Before use, it is recommended to then place the nozzle against the gum at the start button to start rinsing. It is closed when using it to avoid water.
2. When using it for the first time, according to personal needs. Pull it once to adjust rebound rotation. You need to release the button.

Gear switch

- ⑥ Pull it counterclockwise to increase the gear, and pull it counterclockwise to decrease the gear.

There are 7 levels in FLOOSS mode, with intensity options from
8G~9G~10G~11G~12G~13G~14G.

There are 5 gears in MESSAGES mode, with intensity options from
10G/6G---11G/6.6G---12G/7.2G---13G/7.8G---14G/8.4G

The gear switch is self-returning, with a 45-degree rebound swing in both clockwise and counterclockwise directions.

A beeping sound will be heard when increasing or decreasing gears. If it exceeds the minimum or maximum gear, there will be no "beep" sound when the switch is pulled out.

tips

After adjustment and gear adjustment, with memory function. The next time you use it, the machine will automatically jump to the same gear as last time.

According to the working characteristics of the pump, the product will stop spraying continuously for up to 2 minutes. You need to press the start button to start. If the pause time exceeds 15 minutes, the machine will automatically shut down.

select the teeth cleaning mode first, tap between the teeth, and then click as recommended to keep the lips slightly splashing and damaging the gums.

 Slightly closed mouth distance

3. The nozzle should not be far away from the teeth. It should be the gap between the teeth and can be slightly tilted to avoid on the gums. At the same time, slowly move the nozzle along, close your lips slightly, keep your head bent, and let the water flow from your lips to avoid getting your clothes wet.

 Very far away

 Direct shot to the teeth

 Adjust gear

⚠ Kind tips

It is recommended to use warm boiled water or tap water. Never pour mouthwash directly into your mouth. Never use chemical products such as toothpaste, salt, solid mouthwash, etc., otherwise they may become clogged or damaged.

Charging guide



The red light flashes, indicating the battery is low. When charging, the red light stays on. When fully charged, the green light stays on.



Please use a 5V/1A or above adapter to charge.

Note: This product does not support use while charging, please use it rationally.

Cleaning and maintenance

Clean after use

After use, it is recommended to wash and dry it thoroughly before storing it to avoid the growth of bacteria.



1. Stop the device from running



2. Open clockwise

indicating low
the red light
charged, the



3. Use a wiper to clean the dirt inside the nozzle and water tank, and then wipe again with a dry cloth.



4. Close the bottom water tank, and then twist the water tank to align it with the key mark, that is, the water tank installation is completed.

Clean after use

Spray nozzle:

- Dentists recommend replacing nozzles every three months
- If the top of the nozzle is deformed, please replace it with a new one in time to avoid affecting use.

Straw:

- Do not bend or pull the spray and suction pipe.

Product body:

- When cleaning the main body of the product, make sure that the silicone plug of the charging port is installed in place throughout the process to prevent water from infiltrating.
- Stains on the surface of the product can be removed with a cloth dipped in neutral detergent, and then wiped clean with a dry cloth. If the product body is very dirty, it can be cleaned with water. Do not use diluent, gasoline, alcohol, etc. to wipe this product.
- Do not use hot water above 50°C for cleaning.

Water intake:

- Please check the water tank level, otherwise it may cause water intake failure, affecting your health.

Water tank:

- Please inject clean water into the water tank after you unplug the water tank after each use. To protect your health.
- When not using this product, please empty the water tank dry.



Please use a 5V/1A or above adapter to charge.

Note: This product does not support use while charging, please use it rationally.

Maintenance

to wash and dry it thoroughly before storing it.



2. Open clockwise



3. Use a wiper to clean the dirt inside the nozzle and water tank, and then wipe away the water stains with a dry cloth.



4. Close the body and then twist align it with the water tank cover.

Clean after use

Spray nozzle:

- Dentists recommend replacing nozzles every three months.
- If the top of the nozzle is deformed, please replace it in time to avoid affecting use.

Straw:

- Do not bend or pull the spray and suction pipe.

Product body:

- When cleaning the main body of the product, make sure to remove the silicone plug of the charging port is installed in place to prevent water from infiltrating.
- Stains on the surface of the product can be removed by dipping in neutral detergent, and then wiped clean. If the product body is very dirty, it can be cleaned with diluent, gasoline, alcohol, etc. to wipe this product.
- Do not use hot water above 50°C for cleaning.

Water intake:

- Please check the water inlet regularly to ensure that no stains remain, otherwise it may cause water leakage or breed bacteria and affect your health.

Water tank:

- Please inject clean water every time you use it. It is recommended that you unplug the water tank part and clean the inner wall of the water tank after each use. This will reduce the growth of bacteria and better protect your health.
- When not using this product for a long time, please keep the water tank dry.

The bottom water tank, the water tank to which the key mark, that is, the ink installation is completed.

After several months, replace it with a new one.

Makesure that the face throughout

Covered with a cloth
n with a dry cloth. If
with water. Do not
product.

Product number	Rated power	Input parameters
C2	5W	5V = 1A
Nozzle diameter	Pulse frequency	Water pressure
0.6mm	1500 times/minute	40~130PSI
Water tank capacity	Battery capacity	Noise
350ML	2000mAh	< 70dB
Charging port	Charging time	Waterproof level
Type-C	≈2H	IPX7
Dimensions (mm)	Operating mode	Net Weight
81.5×69×233mm	2MODEL/12gear	300G
Pixel	WIFI	Viewing angle
30W	2.4G	78°
Focusing range	Auxiliary lighting	Video resolution
20~100mm	6LEDs	1080P

ifications not expressly Approved by the party responsible avoid the user's authority to operate the equipment.

with part 15 of the FCC Rules. Operation is subject to the

ons;

ot cause harmful interference.(2) This device must accept

ference that may cause undesired operation.

ure Statement:

plies with FCC radiation exposure limits set forth for an

ment.

nce 

his Product (Waste Electrical & Electronic Equipment) (Ap-
with separate collection systems)

product, accessories or literature indicates that the
ronic accessories should not be disposed of with other
he end of their working life. To prevent possible harm to
uman, health from uncontrolled waste disposal, please
from other types of waste and recycle them responsibly
inable reuse of material resources.

uld contact either their retailer. where they purchased
local government office, for details of where and how
ems for environmentally safe recycling.

o contact their supplier and check the terms and
chase contract.

electronic accessories should not be mixed with other
or disposal.

 **RoHS**    

Made in China

ifications not expressly Approved by the party responsible
void the user's authority to operate the equipment.
with part 15 of the FCC Rules. Operation is subject to the
ons;
ot cause harmful interference.(2) This device must accept
ference that may cause undesired operation.
ure Statement:
plies with FCC radiation exposure limits set forth for an
-ment.

nce

his Product (Waste Electrical & Electronic Equipment) (Ap-
with separate collection systems)

product, accessories or litera-ture indicates that the
ronic accessories should not be disposed of with other
he end of their working life. To prevent possible harm to
uman, health from uncontrolled waste disposal, please
from other types of waste and recycle them responsibly
inable reuse of material resources.

uld contact either their retailer. where they purchased
local government office, for details of where and how
ems for environmentally safe recycling.

o contact their supplier and check the terms and
chase/contract.

electronic accessories should not be mixed with other
or disposal.

 CE RoHS

Made in China

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.