

T96 smart watch with earbuds

User Guide



Contents

Instructions use

1、Product Composition	2
2、Button Functions and Touch Control	2
3、Charging instructions and music storage (U-Disk)	3
4、APP Installation	4
5、APP Connection	4
6、Product Parameter	6
7、Instructions for using the watch	6
8、Other Functions	8
9、caveat	9
10、Turn on the app	10
11、fault resolution	12

Before using this product, please read this instruction manual to ensure safe and correct usage

1 English

Instructions use

The environment in which the product is used (too high or too low temperature, humid, rainy, diving or dusty environment), the operation specification, and the power is too low may affect the normal use of the product or even damage it. Please use the product correctly.

Please charge the product before using it for the first time, it takes about 4 hours to charge, if you don't use the smartwatch for a long time, please charge the smartwatch at least once a month.

Do not shower with hot water or put the smartwatch under high temperature; otherwise, the water resistance of the smartwatch will be damaged.

Keep the sensor close to the skin during measurement to avoid movement ;


Measurements are for reference only and should not be relied upon for medical purposes.

Some data is synchronised with phone or network data after connecting to the phone via APP. Such as time, weather, steps, sleep and so on. It can't be set artificially.

1、Product Composition


Product Composition:
Watch; Turn on the app; gine cable; Instruction manual; Packaging

2、Button Function and Touch



2 English

3、Charging instructions and music storage (U-Disk)



1.After the magnetic cable is successfully connected, the watch will show the charging icon; the other end is connected to the standard USB port for charging and copying files.

Attention:

- 1.1. Do not charge in a wet or watery environment.
 - 1.2. Make sure that the metal contacts on the watch body and the magnetic charging cable are not dirty or corroded.
 - 1.3. Periodically clean the metal contacts on the back of the watch and on the magnetic charging cable with a clean flannel. Make sure that the contacts of the watch and the magnetic charging cable are in full contact to ensure proper charging.
 - 1.4. This product is not equipped with a power adapter, in order to ensure personal and property safety, when charging, you can use the computer USB interface or choose the output does not exceed 5V/1A power adapter. Please purchase the power adapter through regular channels, and eliminate the use of low-quality, shoddy power adapters to avoid causing burst or fire.
- 2.One end of the magnetic cable is connected to the watch, the other end is connected to the USB port of the computer, when the computer reads out the watch USB flash drive and deposits the song, MP3 format only.

3 English

4、APP Installation

Scan the QR code or search "Fitcloudpro" in APP Store or App Store to download and install APP.



Note: Android supports 5.0 and above system, ios supports 10.0 and above system, Bluetooth hardware 4.0 and above.

5、APP Connection

1. Install and open the APP for the first time: follow the prompts to allow APP to obtain the corresponding permissions. The first time Apple mobile phone APP connection will prompt the Bluetooth pairing request, click "pairing" to connect, the watch can receive notification alerts from IOS system, such as incoming calls and SMS
2. Open the app and click "add device" and search "T96" to connect. If more than one device is in the vicinity, select the MAC address of your own watch (12-digit alphanumeric and numeric) to bind the device. (The watch MAC address can be viewed through the settings of the watch terminal>About-MAC address method.) When the Bluetooth icon appears on the top of the watch or the Bluetooth connection is successful, you can use the watch dialling code to control the mobile phone to make a call. Answer incoming calls from the mobile phone on the watch and view call log information on the watch. When using the Bluetooth call function, you need to make sure that the connection between the watch and the mobile phone is stable. If you find the connection is disconnected, please pull down the main interface and click the earphone icon turns blue, the connection is successful. As shown in the right picture


4 English

"Watch Music" mode: As shown in the figure below, the watch amplifier speaker (watch speaker) plays music from the watch memory.



"Mobile Music" mode: As shown in the figure below, The Bluetooth of mobile phone searches and connects to "T96", after successfully connecting, the watch can control the playback of mobile phone music. As shown in the picture on the right.

"Bluetooth earphone" mode: as below, take out the bluetooth earphone, watch bluetooth search and connect "T96-R or T96-L", after successfully connecting, the bluetooth earphone will play the watch music.



5 English

6、Product Parameter

Watch Chip: RTL8763EW+HX3605
Bluetooth Version: BLE5.1
Screen size: 1.52 inch, IPS colour screen
Watch Battery Capacity: 400 mAh
TWS Earphone Battery Capacity: 35mAh
Battery Type: Polymer Battery
Usage time: about 10 days
Waterproof grade: IP67 life waterproof
Charging method: magnetic charging
Working temperature: 0-40°C
Compatibility: IOS 10.0 or above; Android 5.0 or above.
Suitable for most mobile devices on the market.

7、Instructions for using the watch

Press the side button or lift your wrist to wake up the screen. Swipe up to access the information bar; swipe down to access the control centre; swipe left to access sports data; swipe right to access split-screen mode

1. Replacement Dials Long press the main page dial for 3 seconds to enter the watch dial replacement page. Or download the replacement dial on the page.
2. Control Centre Swipe down to enter the control centre. 1, Non-disturbance mode 2, Bright screen adjustment. 3, Settings. 4, Find my phone 5, Volume. 6, Voice assistant.

6 English

3. Do Not Disturb Mode Swipe down to the Control Centre and click the Do Not Disturb icon to confirm Do Not Disturb mode is on.
4. Brightness Adjustment Scroll down to the Control Centre and click the Brightness Adjustment icon to adjust the brightness of your device.
5. Settings Scroll down to the Control Centre and tap the Settings icon to access the feature settings.
6. Find My Phone Scroll down to the Control Centre and click the Find My Phone icon, your phone will vibrate to remind you.
7. Bluetooth Calling Scroll down to the control centre and click the audio icon to turn on the audio mode.
8. Voice assistant Scroll down to Control Centre, click Voice Assistant, click the button to enter voice or long press the function/back button for 3 seconds.
9. Sports Data Swipe down once to enter the sports data page to view the sports data and record steps, calories and kilometres respectively.
10. Messages Swipe down to the message bar to view messages
11. Heart Rate Swipe down twice to the heart rate page to start measurement and display data
12. Dialling function This function requires connection to audio Bluetooth. When entering dialling, you can enter the phone number to make a call as needed; long press 7 and 9 on the keypad to enter * and #.
13. Exercise Mode Press the function/back button to enter the function page to find sport. Tap to enter the sport mode and select your favourite sport.

7 English

14. Weather Press the function/return key to enter the function page to find the weather, click to view the weather
15. Music control Press the function/back key to enter the function page to find the music control, click and return to adjust the up/down, start/stop, volume up/down..

16. Blood pressure Press the function/back key to enter the function page to find blood pressure, click and measure
17. blood oxygen Press the function/back key to enter the function page to find blood oxygen, click and measure

8、Other Functions

- 1.Sleep 2.Chronograph 3.Timer 4.Alarm clock 5.Sedentary reminder 6.Drinking water reminder 7.Shake to take a picture 8.Women's physiological period (Turn on the app).

9. Recording function. Tap the red heart to start recording, tap again to stop recording and save. Tap the record button on the right side of the list to view and play the recording. Recording file copy: Use the data cable (charging cable) to connect to the computer for copying.



8 English

9、caveat

1. Why do I need to wear a smartwatch tightly when measuring my heart rate? Smartwatches use the principle of light reflection to calculate heart rate by penetrating the skin with a light source and collecting the signals reflected on the charger. If you don't wear it tightly, ambient light will enter the sensor and affect the measurement accuracy.

2. It is not recommended to wear them while taking a hot bath. The first factor: Hot bath will generate steam, due to the high temperature of the bath water, it is easy to generate a lot of steam. Steam is a gas with a small molecular radius, so it can easily penetrate the gaps in the smartwatch case. When the temperature drops, the water will gradually condense into water droplets, which can cause damage to the circuit board and thus damage the smartwatch.

3. When connecting Bluetooth, make sure the Bluetooth of your mobile phone and smartwatch is turned on. Make sure your smartwatch is not connected to another account when doing a Bluetooth search; Place your smartwatch and mobile phone as close as possible when doing a Bluetooth search.

4. If the user's mobile phone installed other software, such as mobile phone manager, in order to ensure the normal operation of the background APP, please open the mobile phone's message push and allow the background operation, otherwise it can not be pushed messages

5. To ensure the accuracy of the test data, after entering the blood oxygen test mode, remain relaxed and still during the test and make sure the smartwatch and your heart are at the same height. Please do not talk during the test. (This function provides data reference for blood oxygen changes before and after human exercise, and cannot be used for medical purposes)

9 English

10、TWS Earphone Features

- A: earphone pairing
1. earphone pairing, take the earphone out of the watch host, there is a boot tone, open the bluetooth in the mobile phone settings, find the corresponding bluetooth name T96-R/T96-L for bluetooth connection, factory before TWS earphone has been done between the pairing pair. Only the Bluetooth name T96-R/T96-L is displayed, and the mobile phone sees that it has been connected, which means that the product has been successfully connected.
 2. Remove the earphone from the watch and it will automatically switch on and pair with the connection.
 3. If the earphone is disconnected from the mobile phone during use or the earphone is not connected, the mobile phone needs to be reconnected to Bluetooth. There is a previously connected Bluetooth model in the Bluetooth under the mobile phone settings, please clear it first, and then search for Bluetooth T96-R/T96-L to connect.
 4. earphone couplets: If there is a situation where only one side of the earphone has sound, it is necessary to pair the couplets between the ears.

How to pair earphones with each other

1. Firstly, switch off both earphones by holding them down for 6 seconds at the same time.
2. Long press the two earphones at the same time to boot, boot the two earphones light alternately flashing state (at this time to keep your hand on the earphone touch point does not move), press the two earphones at the same time 7, press the end of the 7 after the two earphones will be automatically switched off at the same time
3. Put the two earphones into the watch compartment and then take out the two earphones at the same time, only one of the earphones lights up after switching on the watch. It means the earphones are paired successfully
8. The middle side of the earphone is a touch surface, used to touch control to answer/hang up the phone, control the music up/down, volume up/down, AI voice assist

10 English

11、Troubleshooting



C: Answer/hang up calls

When the earphone has an incoming call in the base of the watch, remove it from the watch will be automatically connected, the earphone is in the watch for a long time, incoming calls need to manually answer, double-click the button to answer the phone, double-click to hang up the phone, when the call put the earphone back to the watch, then the earphone is switched off. If the other party does not hang up the phone will automatically switch to the mobile phone to answer.

D: Music Operation

Double click for pause/play, long press for 2 seconds for previous/next song, triple click for volume +/-

E: AI voice assistant and making calls

The earphone has been connected to the Bluetooth state four clicks on the touch key to activate the iPhone mobile phone's Siri and Android mobile phone's voice assistant, can be operated through the voice assistant to make a phone call, check the weather, navigation maps and other functions. Activate the voice must be in the mobile phone in the standby interface or the main interface of the time to be effective!

Precautions for use

1. The measurement results of this product are for reference only and are not intended for any medical use. Please follow your doctor's instructions and do not rely on the results for self-diagnosis and treatment.
2. This product is IP67 life waterproof, can not be used for deep diving and long time soak in the water. In addition, this product is not anti-hot water, because water vapour will affect the watch
3. We reserve the right to modify the contents of this manual without notice. It is normal for some functions to differ in the corresponding software version.
4. Please use Restore Factory Settings with caution. Restoring Factory Settings will result in the loss of all APP content settings and watch history data.

11 English

5. After using the earphone, please promptly clean the earphone charging port of oil and water quality, including the watch earphone compartment debris



Please keep the earphones charging compartment clean Regularly clean the sweat and debris on the metal PIN

12、Warnings

Q: APP connection is unsuccessful or some functions are unstable

- A: 1. The watch battery may be too low and the product needs to be recharged.
2. Check whether certain functions are in the corresponding watch mode. For details, please refer to the description of Article 3 in V. APP Connection of this manual
3. Whether the Bluetooth of the mobile phone has been turned on
4. Whether the app's permissions are turned on in the phone's settings.
5. Excludes situations where multiple devices are in the vicinity, may be incorrectly connected to the phone or the phone is being used by another mobile phone (in this case, the device should be deleted from another tethered mobile phone, if you are using Apple phone, need to find the device name in your phone's Bluetooth and click on Ignore this device).
6. There are too many Bluetooth devices connected or have been connected to the phone. It is recommended that the number of Bluetooth devices connected or previously connected not exceed 10.
7. The distance between the phone and the watch is too long or there is an obstacle in between.

12 English

8. APP permissions in the mobile phone such as storage, phone, location information, camera, etc. are turned on (due to the large number of mobile phone brands, APP installation prompts and mobile phone setting APP permissions may be different, by default, according to the APP installation prompts to agree to turn on the corresponding permissions can be, such as operational errors or due to permissions problems caused by the use of the APP to prevent the use of the functions of the user, users are asked to set up the appropriate permissions of the APP according to the brand of their own mobile phone)
9. App or watch version needs to be upgraded

Q: Information, weather, time and other features can not be set to change, or can not be pushed

- A: 1. The watch battery may be too low and the product needs to be recharged.
 2. Need to turn on and select the corresponding functions of message alerts and weather push in the app.
 3. Turn on message push in app settings
 4. Whether the Bluetooth of the mobile phone has been turned on, and whether the mobile phone and the watch are connected properly
 5. Weather data is regularly updated by the APP in the background of the phone via a server and then synchronised to the watch.
 6. Please make sure the network connection is normal. Weather data provided by the server or different from other platform weather data
 7. The update and upgrade of the data server may cause data synchronisation problems, please wait patiently for the completion of the upgrade according to the announcement on the APP.
 8. The main thing on APP is to record and store the data, some functions cannot be operated and modified.
 9. The time on the watch is synchronised via the mobile phone connection and cannot be changed
- Q: Watch use jams
- A: 1. The watch battery may be too low and needs to be recharged

13 English

2. Memory usage is too high, restart your phone and watch and reconnect them
 3. The surrounding environment is poor, such as high and low temperature, humidity, please change the use of the environment
- Q: Incoming calls can't be synced to the watch
- A: 1. The incoming call reminder function in the message push function of the app should be turned on.
 2. Check if the watch is successfully connected to your phone
- If you have any other questions, please contact the seller .

12、Warnings

This product is not a medical device. The smartwatch and its apps cannot be used for the diagnosis, treatment or preventive treatment. Please consult a medical professional before changing your exercise and sleep habits to avoid serious injury. The manufacturer reserves the right to modify and improve the functional descriptions of the user guide and to update the content at any time without notice. This user guide is for informational purposes only. This user guide is for informational purposes only, and the smartwatch sold herein is subject to the final product.

14 English

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction