








100*130mm 双面折页

JAMSYNC Active Noise Canceling Headphones  ANC001 User Manual	Support & Service Information Thank you for choosing the ANC001 Active Noise Canceling Headphones! This user manual includes everything you need to know to get started and enjoy your headphones. If you experience any issues while setting up or using your ANC001 headphones, feel free to reach out to us at: 📧 Jams-service@outlook.com Before using the product, please read this manual carefully and keep it for future reference. You can also find answers to common questions in the FAQ section at the end of this manual.	01 Packaging Contents Display 02 Product Overview 03 How To Use 05 Mode Switching And Wearing 06 Button Description 07 Charging Instructions 08 FAQ 12 FCC STATEMENT	Packaging Contents Display  01	Product Overview  02	How to use  03	How to use ③ Connect Pairing 1: Press and hold the Power/MFB button for about 2 seconds until the LED indicator starts flashing red and white. You will hear the voice prompt “Power on,” followed by “Pairing.” 2: On your device, go to Bluetooth settings, turn on Bluetooth,select “ANC001 ” from the list of available devices, and wait for the voice prompt “Connected.”  04	Mode switching and wearing 1. Normal Mode (Default) The headphones are in Normal Mode by default. To return to Normal Mode from ANC, press the MFB button twice quickly. Voice prompt: “ANC Off.” 2. Transparency Mode To hear surrounding sounds while listening to music, press the MFB button twice. Voice prompt: “Transparency Mode.” 3. ANC Mode (Active Noise Cancelling) To activate noise cancellation, press the MFB button twice again while in Transparency Mode. Voice prompt: “ANC Mode.” How to Wear To achieve optimal sound quality,effective noise cancellation, andmaximum wearing comfort, please adjust the headband to fit yourhead properly. 1. Put the headphones on your head, left to left and right to right. 2. To adjust headphones, move the headband up and down until it fitsyour head comfortably.3. To adjust the headphone's earmuffs,let it fit your ears comfortably 
--	---	--	--	--	--	--	--

Button Description <table><tr><th>Button</th><th>Function</th><th>Operation Instruction</th></tr><tr><td></td><td>Play/Pause</td><td>Click once</td></tr><tr><td></td><td>Answering call</td><td>Click once</td></tr><tr><td></td><td>Hang up the phone</td><td>Click once</td></tr><tr><td></td><td>Power on/off</td><td>Press and hold for 5 seconds</td></tr><tr><td></td><td>Noise reduction mode</td><td>Click twice quickly</td></tr><tr><td></td><td>Next song</td><td>Long press for 1 second</td></tr><tr><td></td><td>Previous song</td><td>Long press for 1 second</td></tr><tr><td></td><td>Mute a call</td><td>Long press for one second during a call</td></tr></table> Activation * Active Noise Canceling mode (ANC) blocks the noise from surrounding environmentwhile wearing ANC001.	Button	Function	Operation Instruction		Play/Pause	Click once		Answering call	Click once		Hang up the phone	Click once		Power on/off	Press and hold for 5 seconds		Noise reduction mode	Click twice quickly		Next song	Long press for 1 second		Previous song	Long press for 1 second		Mute a call	Long press for one second during a call	Charging Instructions  ① When the red LED indicator starts flashing or you hear the voice prompt "Battery low," it's time to charge your ANC001 headphones. ② Connect the included charging cable to the charging port on the headphones. You should hear a slight click. Then, plug the USB end of the charging cable into a USB charger or computer port. ③ Once connected, the LED indicator will turn solid red to show that charging has started. When fully charged, the light will turn solid blue. ④ Charging takes approximately 2 hours.	FAQ F: Can I connect one headset to two devices? A: Yes, Please refer to the steps below. 1. Follow the standard pairing steps to connect the headset to your first device. 2. Once connected, turn off Bluetooth on the first device. The headset will automatically enter pairing mode again (the LED indicator will flash red and blue). 3. Turn on Bluetooth on the second device, select "ANC001" from the Bluetooth list, and then successfully connect with the "Connected" voice prompt.	FAQ  4. Now, turn Bluetooth back on the first device and reconnect to "ANC001" from the Bluetooth list. Your headset is now connected to two devices. Tips for Dual-Device Connection 1.When connected to two devices, audio can only play from one device at a time. 2.To switch playback to the other device, pause or stop the music on the first device before starting playback on the second.	FAQ Q: Do the headphones reconnect automatically? A: Yes, if the earphones have been previously paired, press and hold the power button for 2 seconds until you hear the voice prompt "Power on". The earphones will automatically reconnect to the last paired device. Other previously paired devices will need to be manually connected through their Bluetooth settings. Q: What should I do if the device cannot search for the headset Bluetooth model? A:If the LED indicator continues to flash red and blue after the headset is turned on, but your device cannot find the Bluetooth name of the headset: "ANC001" Please turn Bluetooth off on your device and then turn it back on. Also turn the headset off and back on to put it back into the search and pairing state. After the device Bluetooth restarts, search for the headset Bluetooth model "ANC001" and try to pair it again. Your device will successfully detect and connect to the headset.	FAQ Q: Can I use the headset while charging? A: No. We do not recommend using the headset while charging as it may affect your wearing comfort. Q: Are these headphones fully noise cancelling? A: No, ANC001 has its own physical noise reduction effect, and the active noise reduction mode can effectively reduce external noise by 42db. It also has three modes that can be switched at will. Q: How can I check the battery level of the headphones? A: You can check the remaining battery level directly on your connected device — it is usually displayed as a battery icon or percentage. When the battery is low, you'll hear a voice prompt saying "Battery low." Please charge the headphones promptly after hearing this warning to avoid interruptions to your listening experience.	FCC STATEMENT This device complies with Part 12 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 12 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Warranty Policy We provide an 18-month warranty policy. Please consult the customer service manager for specific warranty conditions. Email: Jams-service@outlook.com	JAMSYNC FC Made in China Thank you for choosing our product! Your satisfaction is our top priority, and we are committed to providing you with the best possible experience. If you need any help or support, please don't hesitate to reach out to us — we're always here for you. Disclaimer While every effort has been made to ensure that the information and procedures in this guide are accurate and complete, we are not responsible for any errors or omissions, and we reserve the right to make any changes to any product mentioned herein without prior notice.
Button	Function	Operation Instruction																																
	Play/Pause	Click once																																
	Answering call	Click once																																
	Hang up the phone	Click once																																
	Power on/off	Press and hold for 5 seconds																																
	Noise reduction mode	Click twice quickly																																
	Next song	Long press for 1 second																																
	Previous song	Long press for 1 second																																
	Mute a call	Long press for one second during a call																																
06	07	08	09	10	11	12																												