

Pooloob

Robotic Pool Cleaner

PFI Pro

Remote Control and APP User Guide




To stay current on our latest updates and features,
download the "**Smart Life**" APP.

BEFORE USE

STEP 1: Install the brush.

Install the brush at the suction port on the bottom of the robotic pool cleaner.




STEP 2: Charge the Robot

Fully charge your robotic pool cleaner before using it.

- Charging must be done in a cool, dry place.
- Clean and dry the charging port before connecting the adapter.

Charging indicator

- A breathing indicator light means the battery is charging.
- A solid green indicator light means charging is complete.




BEFORE USE

STEP 3: Charge the Buoy

The buoy utilizes a solar-powered charging system, offering an energy-efficient and eco-friendly solution.


For optimal charging, position the buoy's solar panel to face direct sunlight during strong sunlight conditions and charge for 5 hours.



STEP 4: Install the Buoy

Install the buoy plug into the buoy connector on the top of the robotic pool cleaner and tighten the screws.


While the robot operates in the pool, the buoy can harness strong sunlight to recharge itself.



PRODUCT USAGE INSTRUCTIONS


STEP 1: Turn on the Robot Power

Press and hold the power button until the indicator light comes on.



STEP 2: Turn on the Bony Power


Press the button at the bottom of the buoy. The indicator light will turn on, and the power will be activated.



PRODUCT USAGE INSTRUCTIONS

STEP 3: Place the robot into the water



Face the bottom of the robotic pool cleaner towards the pool wall and gently place it into the water.



Note: In normal conditions, if the robotic pool cleaner is not placed in the water within 5 minutes, it will automatically shut down.

STEP 4: Working

Your robot will begin working within five seconds of reaching your pool floor. At this point, you can use the remote control or the app to operate your robot.



CONNECTING THE SMART LIFE APP AND ROBOT

STEP 1: DOWNLOAD THE Smart Life APP

Search “Smart Life”  in the app store or scan the QR code and download.

NOTE: For more information on connecting your robot, see next page.



STEP 2: Log in APP

Sign up your **Smart Life** APP or log in if you have.


STEP 3: Bluetooth

Enable Bluetooth of your mobile phone.



STEP 4: Prep Bouy for Bluetooth

Firmly press and hold the button on the buoy for 3 seconds to activate the communication function, the buoy light will flash for 3 minutes.




STEP 5: Pair your Robot



SPECIFICATIONS

TIP: While the buoy can recharge itself in sunlight during robot operation, it's recommended to place it in sunlight after each use to ensure sufficient power for the next use.



Bluetooth

Standard	Bluetooth Low Energy4.2/5.0
Data Transfer Rate	1Mbps, 2Mbps
Frequency Band	2400 MHz to 2483.5 MHz

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement: This device complies with FCC RF exposure limits for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Customer Support

support@Pooloob.com

Eco-friendly Paper

We use eco-friendly paper to support environmental sustainability.