



  KESAIYI CL26 Wireless Ear Clip Headphones User Manual	Product Parameters Product model: Kesaiyi CL26 Bluetooth version: 5.3 Wireless pairing name: Kesaiyi CL26 Wireless range: 10m (unobstructed) Talk time: 5 hours Music playtime: 5 hours Battery capacity: - Headphone: 25mAh - Charging case: 200mAh Charging time(charging case): 1.5 hours Charging case input interface: Type-C Product size: 70mm x 40m x 38mm Product net weight: 35.5g Net weight of one headphone: 4.5g Product Components - Headphones – 1 Pair - Charging case - Type-C charging cable - User manual	Product diagram 	Wearing • Remove the headset from the packaging and open the charging case. • Remove the headphone from the left side of the charging case • Hold the headphone to wear in the left ear as shown in the diagram. When wearing, please straighten your ear outward.  • Adjust the angle of the headphone up and down until the direction of the sound outlet is aligned with the auricular cavity.  • Perform the same steps for the other headphone and the right ear.	Bluetooth connection - first time use 1. Turn on your Bluetooth device. 2. Open the charging case cover and remove the headphones to turn on the phones. Search for the pairing name: Kesaiyi CL26. 3. This product can be used with Bluetooth devices. Charging 1. The headset needs to be charged in the charging case 2. Connect the Type-C charging cable provided by the manufacturer with the USB interface output 3. When the headset is placed in the charging case, the headset can be charged while the charging case is being charged.	Operating instructions Power on - Remove the headphones from the charging case Power off - Put the headphones into the charging case Play/Pause - Click on one of the headphones Previous - Double-click on the left headphone Next - Double-click on the right headphone Siri - Long press on either headphone Answer call - Click on one of the headphones Hang up - Click on one of the headphones Volume up - Triple-click on the right headphone Volume down - Triple-click on the left headphone Manual on/off: Long press the left/right headphone for 3 seconds	Pairing 1. Automatic re-connection: Remove both headphones from the charging case. After the headphones are automatically power on, they will be automatically connected. After successful connections, the two ears will hear a "connected" sound 2. If there is no sound from either headphone, please put both headphones into the charging case and then open the case and take out the headphones again. The two headphones will automatically reconnect to the phone	Precautions - Keep the product away from high temperatures and high humidity. - Please keep the volume at a reasonable level, high volume may damage your hearing. For your safety, do not use the product while driving or cycling. - Do not use the product in places such as railway crossings, pedestrian crossings, construction sites, etc. - Do not place heavy objects on the product as this may cause deformation. - Do not beat the product excessively. - To clean the product, use a soft, dry cloth. - Do not immerse the product in water. Do not drop the product into a sink or other water-filled container.	Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.	  KESAIYI CL26 Wireless Ear Clip Headphones User Manual
---	---	---	--	---	---	---	--	--	---