

正面

RL01

75mm

105mm

User Manual

1.75m Extra Wide & Thick Mobile Phone Tripod

English

01

Magnetic accessories

Selfie stick tripod

User Manual

English

02

Product Specifications

Specification	Details
Expand height	1.5m
Product model	CS05A
aluminum alloy tube	seven sections
lock-bearing	15kg
Storage size	60*30*330mm
material	Nylon reinforced fiber + aluminum alloy tube
net weight	395g
Horizontal and vertical shooting	support
aluminum alloy tube	seven sections
material	Nylon with fiber-reinforced material
Support with wireless	Adjusting
Bluetooth version	5.2
Compatible devices	Android 4.3 and above, iOS supported
Battery capacity	55 mah
voltage current	5V, 10mA

English

03

Phone Tripod Installation

1. Uninstall the Center Pole

Find the red ring near the top. Turn it to unlock.

2. Open the Legs

Press the button at the tripod bottom. Hold the button down while pulling the three legs out at the way.

3. Set the Height & Lock

Pull up the center pole to your height. Turn the red ring again to lock it.

English

04

Light Ring Installation

1. Install the Magnetic accessories screw holes into the bracket interface. (pic 4)

2. Key the Magnetic accessories fixed. Tight the light by rotating the screw. (pic 5)

3. Turn the screw to tighten the Magnetic accessories or loosen it to remove the Magnetic accessories and other accessories.

4. Rotate the screw knob on one side of the bracket to adjust the angle 180 degrees. (pic 6)

TIP: You can install the phone clip on the Magnetic accessories first, and then install the Magnetic accessories on the tripod.

pic 4

pic 5

pic 6

Attach ring light to tripod

Rotate it to hold the light

Rotate the screw knob to adjust the angle

English

05

Phone Holder Installation

Loosen the Tightening Knob: Turn round knob at the base of the phone holder to loosen it.

Slide in the Mount: Slide the square base of the phone holder (cold shoe mount) into the mounting slot on your ring light.

Secure the Holder: Turn the knob to tighten it until the phone holder is firmly locked in place.

Cold shoe mount

Equipped with a cold shoe mount for attaching external hotshoes, microphones and other accessories to enhance your shooting quality and audio performance

Cold shoe mount

English

06

Magnetic accessories

Super strong magnetic attraction, can be attached to magnetic phone cases

English

07

Remote Shutter Instructions

Pairing & Setup
Activate Remote: Swing the switch upward to turn on the power → LED flashes slowly, enter pairing mode.

Enable Phone Bluetooth
Open phone Settings → Turn on Bluetooth.

Connect Device
1. Select "CS05A" from available devices.
→ Automatic pairing completes in 5-10 secs. The light will turn off.
2. Open your phone's camera application. Single-press: Take photos.

Android Phone Compatibility fix
(If remote can't be zoom in/out of Shutter)
Open Phone Settings → Camera.
Enable "Volume Button = Shutter" (Disable zoom function)
Path may vary: Settings > Advanced > Shutter option"

Close the Tripod
Unlock: Increase the locking mechanism button again to unlock the tripod legs.
Collapse: Gently push the tripod legs inward, collapsing them back towards the handle. Ensure that the tripod legs are fully collapsed and locked in the closed position.

English

English • Deutsch • Français • Italiano • Español

反面

1.75m Selfie stick tripod

English

08

Portable storage

English

09

Minimalist & Universal

both the phone holder and tripod feature a cold shoe mount on the side, allowing you to attach external accessories such as flash lights, microphones and more (accessories not included).

English

10

Wireless Remote Control

① Turn the remote on using switch, the green LED light will flash.

② To pair the remote to your Bluetooth device, on your device go to: settings>Bluetooth>Turn Bluetooth On.

③ When the remote is in pairing mode connect to "CS05A" in the available device list, the green LED light will stop flashing when connected.

Attention:
When you are using our products, if the remote control has the following situations, you can try to see part of the suggested solutions to solve the problem or contact us directly.
1. Batteries are dead
Judgement basis: the remote control can not be turned on, long press the remote control button, the light does not blink.
Solution: you can change the battery to solve the problem, the battery model is AAA or get in touch with us.
2. Cannot connect the bluetooth
Judgement basis: Bluetooth name can be searched, but it shows that it can't be paired.
Solution: Because of the frequency of Bluetooth update speed, some mobile phones may not be paired successfully, you can get in touch with us, we come to help you solve it.
3. Cannot take photos after Bluetooth connection
Judgement basis: After connecting, press the remote control, the phone shows the volume key can not take pictures.
Solution: Please change the shutter in the camera settings to the volume button in your phone.

English

11

Warning/Attention

1. This product contains small parts that may pose a choking hazard. Keep out of reach of children. If the product is used as a power source, using an incorrect power source can damage the product and cause injury.
2. Do not use the product if it appears damaged or if any parts are loose or missing.
3. This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

Warning/Aufmerksamkeit
1. Dieses Produkt enthält kleine Teile, die eine Erstickungsgefahr darstellen können. Halten Sie das Produkt von Kindern fern.
2. Verwenden Sie nur die vorgeschriebene Stromquelle. Die Verwendung einer falschen Stromquelle kann das Gerät beschädigen und zu Verletzungen führen.
3. Verwenden Sie das Gerät nicht, wenn es beschädigt ist oder Teile fehlen oder lose sind.

Avvertimento/Attenzione
1. Questo prodotto contiene parti di piccole dimensioni che possono rappresentare un rischio di soffocamento. Tenere fuori dalla portata dei bambini.
2. Utilizzare solo la sorgente d'alimentazione specificata. L'utilizzo di una sorgente d'alimentazione non corretta può danneggiare il prodotto e causare lesioni.
3. Non utilizzare il prodotto se appare danneggiato o se alcune parti sono assenti o mancanti.

Advertencia/Atención
1. Este producto contiene partes de pequeñas dimensiones que pueden representar un riesgo de asfixia. Manténgalo fuera del alcance de los niños.
2. Utilice únicamente la fuente de alimentación especificada. El uso de una fuente de alimentación incorrecta puede dañar el dispositivo y causar lesiones.
3. No utilice el producto si aparece dañado o si falta alguna pieza.

English

12

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
1) This device may not cause harmful interference, and
2) this device must accept any interference received, including interference that may cause undesired operation.

Note:
This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to residential installations. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If you experience interference, you may need to take the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

English

13

Warning

a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
b) Even used batteries may cause severe injury or death.
c) Warning: Keep away from the children. If swollen, please call a local poison control center for treatment information.
d) Battery type: AAA (standard).
e) Nominal voltage: 5V 100mAh.
f) The product contains non-rechargeable batteries.
g) Do not touch discharge, storage, disassemble, heat above 60°C, or incinerate. Doing so may result in injury due to venting, leakage or explosion, resulting in chemical burns.

WARNING
a) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries."
b) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations."
c) The statement "Always, completely, secure the battery compartment, if the battery compartment does not close securely stop using the product, remove the batteries, and keep them away from children."

CAUTION
a) The product contains non-rechargeable batteries.
b) Do not touch discharge, storage, disassemble, heat above 60°C, or incinerate. Doing so may result in injury due to venting, leakage or explosion, resulting in chemical burns.
c) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations."
d) The statement "Always, completely, secure the battery compartment, if the battery compartment does not close securely stop using the product, remove the batteries, and keep them away from children."

English

14

CE UKCA FCC

English

15