

Smart glasses

User Manual



Downloads and Links

Download App

- **Way 1:** Please use your cell phone to scan the QR code below to download and install the APP.
- **Way 2:** Search for "Da Echo" in the application market of major cell phone brands, such as Android or Apple, download and install it.




How to link

- **Cell phone pairing:** 1. Turn on the BT function of your cell phone.
2. Turn on your glasses to connect and pair them via Bluetooth.
3. Open the "Da Echo" app (you need to register an account for the first time), click "Get Started", select the corresponding model, and click "Start".
- **Auto Reconnect:** With cell phone pairing record, within the connection range, it automatically connects back to the paired devices.



Appearance



LED Light Description

Power on: The red and blue lights on the motherboard flash alternately;
Power off: The red light on the motherboard stays on for 1 second and then goes out;
Manual disconnection: Enter broadcast mode, with red and blue lights flashing alternately;
Charge: The red light is constantly on when charging, and the blue light is constantly on when fully charged;
Take photos: The left flashing light flashes once, and the blue light on the motherboard flashes once;
Video: The left flashing light is constantly on, and the blue light on the motherboard is constantly on;
Recording: The blue light on the motherboard is constantly on;
Functional conflict: The red light illuminates for 1 second and then goes off.

Operating Instructions

- **Power on:** In the shutdown state, press and hold the front physical button for 3 seconds.
- **Shutdown:** When the device is powered on, press and hold the front physical button for 3 seconds.
- **Take a picture:** When the power is on, click the front physical button to start taking a picture.
- **Video recording:** Turn on the video recording: Under the power on condition, double click the front physical button to start the video recording;
End video recording: In the video, click the front physical button to end the recording.
- **Recording:** Turn on Recording: With the power on, double click the rear physical button to start recording.
End audio recording: In the recording, click the rear physical button to end the recording.
- **Calls: Answer an incoming call:** Receive an incoming call, double-click the touch key;
Reject an incoming call: Receive an incoming call, long press the touch key;
Hang up a call: During a call, long press the touch key.
- **Wake up by voice:** Under power-on condition, click the rear physical button or use the voice command "Hello,Echo" to activate voice control.
- **Music: Play/Pause:** When the music playback app is already launched, single-finger double-tap the touch button starts/pauses the playback of music;
Next song: When the music playback app is already launched, triple-tap the touch button with a single finger;
Volume Plus: When playing music, slide the touch button forward;
Volume down: When playing music, slide the touch button backwards.
- **Reset to factory settings:** In any state, continuously press and hold the front and back physical button for 5 seconds.
- **Automatic sleep mode:** The device will automatically shut down after 30 minutes when not in use; you need to press and hold the front physical button for 3 seconds to turn it back on.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy, if not installed and used not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

