

OWS 2 说明书 做折页

材料：108克铜版纸+单黑单面印刷+过光油 成品尺寸：80mm*80mm

80mm

80mm



OWS 2
USER MANUAL



FCC ID:2BFZC-OWS2

I Packing list

- Host*1
- User manual*1
- Charging cable*1


II Product parameters

- ### 1.Charging case parameters
- Input voltage: DC5V
 - Battery capacity: 500 mAh
 - Charging port: Type-C
 - Standby time: about 120 days
 - Charging current: 300 mA
 - Charging time: about 2.5 hours

- ### 2.Headset parameters
- Bluetooth name:Juyeecon ows 2
 - Channel system: Dual channel
 - Battery capacity:65mAh
 - Duration: About 8 hours
 - Frequency response:20Hz~20KHZ
 - Charging time: about 1.5 hours


Support bluetooth protocol: A2DP\AVCTP\AVDTP\AVRCP\HFP\SP\SM\ATT\GATT\RFCOMM\SDP

III Product appearance



IV Prepare before wearing

Before use the device , follow up step1 to open the charge case and take out the earphone ,remove the insulation sticker ,then put the earpone into the charge case as step2, repeat the step1 to step 2 for another earphone . after finish the both eaphone activating , then take out the both earphoe to wear and device will auto power on . connect and pair with Bluetooth as the following (V)step , and then use it.



V Bluetooth Connection

- Binaural use: Open the charging case , the headphone will automatically turn on and pair up. Pairing of headset and mobile phone: turn on Bluetooth settings
- turn on Bluetooth,select Bluetooth device “ Juyeecon ows 2 ” (as shown in the figure), click and connect.



VI Product Operation

	Charging indicator light
Charge case charging	The orange lights are on
Battery full charge	The white light is always on and then off
Low battery	The orange light stays on and then turns off

Earphone indicator light	
Earphone power on	Take off the earphone from charge case the device auto power on
Earphone charge	The indicator light of earphone continue light Red
Earphone charge full	The indicator light of earphone power off

Feature	Touch function of earphone	
	Operation instruction	
Voice assistant	Touch the left or right earphone for 2 seconds to wake up voice assistant.	
Play or Pause	Touch the left or right earphone 2 times (music mode)	
To answer phone	Touch the left or right earphone 2 times (Incoming telegram)	
To reject phone	Touch the left or right earphone for 2 seconds (in call)	
Hang up phone	Touch the left or right earphone 2 times (in call)	
To switch to the pre/next song	Touch the left earphone 3 times to switch to the previous song, touch the right earphone 3 times to switch to the next song.	

Volume “+/-”	Touch the left earphone to increase the volume and touch the right earphone to decrease the volume.
--------------	---

* If the max volume of the headphone is still too low, please make the “absolute volume” on your phone to be enabled.

VII Matters needing attention

- Do not use corrosive cleaning agents to clean the product.
- Do not allow this product to be heated or near fire sources, such as cooking stoves.
- Do not allow this product to be exposed to direct sunlight for a long time.
- Do not dispose of this product in the fire to avoid explosion.
- Do not attempt to disassemble this product for any modification, as it does not contain any repair components.
- Do not use this product in the rain.
- If you do not intend to use this product for a long time, please store it in a dry environment and charge the headset at least once a month to extend its life and avoid extreme temperatures and dust.

Attention: The product has a built-in rechargeable battery. Please do not disassemble or replace it by yourself. Use the correct method to charge the device. Do not place the device near a fire source or expose it to direct sunlight, otherwise the battery heating will damage the safety device and cause the battery to explode or burn.



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Product model : _____

Purchase date : _____

Agent : _____

Invoice date : _____

Telephone : _____

Customer Name : _____

Postal Code : _____

