2.4G Ergonomic Wireless Keyboard and Mouse Combo




USER MANUAL

Packing List




1. Keyboard x1
2. Mouse x1
3. USB receiver x1
4. USB C to USB adapter x1
5. User manual x1


Overview




1




USB receiver and Type-C adapter storage slot




2



Operation Guides



3



4

1. Fetch the wireless keyboard and mouse. Take out the USB receiver from the keyboard battery compartment.
2. Insert one 1.5 V AA battery into the keyboard according to the positive and negative sign.
3. Insert one 1.5 V AA battery into the mouse according to the positive and negative sign.
4. Plug the receiver into the USB port of your computer.
5. When the computer installs drives automatically, they start to serve.

5

Functions of Combination Keys

KEY	Win	Mac
FN+A	Win system	/
FN+S	/	Mac system
FN+F1	Screen brightness -	Screen brightness -
FN+F2	Screen brightness +	Screen brightness +
FN+F3	Convert Window	Convert Window
FN+F4	Calculator	Not for Mac OS
FN+F5	Microphone	Exhale Siri
FN+F6	Search	Search
FN+F7	Previous Track	Previous Track
FN+F8	Play/Pause	Play/Pause
FN+F9	Next Track	Next Track
FN+F10	Mute	Mute
FN+F11	Volume -	Volume -
FN+F12	Volume +	Volume +

6

Features

1. The mouse and keyboard share a common receiver. And the receiver is in the battery compartment at the bottom of the keyboard.
2. Adjustable mouse DPI levels: 800-1200-1600-2400 (default setting is 1200).
3. It has automatic sleep mode and wake up mode. When the keyboard and mouse haven't been used for 90 seconds, it will enter sleep mode. Press any button to wake up.

Keyboard Special Functions

1. FN+WIN: Lock the WIN key.
2. FN+A: Switch to Windows mode. (Indicated by 5 blinks of the NUM lock light).
3. FN+S: Switch to macOS mode. (Indicated by 5 blinks of the CAPS lock light).

7

Solution to Connection Failures

Keyboard:
1. Turn off the keyboard power switch and remove the USB receiver from your computer.
2. Turn on the keyboard power switch.
3. Press and hold the FN + K keys to pair the keyboard. The red Num Lock light on the keyboard will flash. Plug the USB receiver into your computer and place the keyboard near the receiver. When the red light stops flashing, the keyboard is ready for use.

Mouse:
1. Turn off the mouse power switch and remove the USB receiver from the computer.
2. Turn on the mouse power switch.
3. Press and hold the left, middle, and right mouse buttons simultaneously. The green LED light below the scroll wheel will flash. Plug the USB receiver into the computer and bring the mouse close to the receiver. When the green light stops flashing and the red light on the bottom of the mouse turns on, the mouse is ready for use.

8

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection
against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

9

---Reorient or relocate the receiving antenna.
---Increase the separation between the equipment and receiver.
---Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
---Consult the dealer or an experienced radio/TV technician for help.
Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirement.
This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment.
This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

10

Contact Us

Whatever you need, we're here to help.
Just get in touch, and we'll try our best to respond within 24 hours.
After-sales email：csforcustomer@gmail.com

文件编号	K582+HYC289	东莞市朗奥电子有限公司			
文件名称	K582+HYC289键鼠套装-2.4G无线-说明书				
文件版本	V1.0				
材质工艺	100×75MM	设计者	周凯	日期	20260615
	128g书写纸 风琴折	核对	Lydia		