




25. Caution, the brake may become hot in use. Do not touch after use.




26. Eliminate any sharp edges caused by use. Do not modify or transform the vehicle, including the steering tube and sleeve, stem, folding mechanism and rear brake.



27. Users should always wear shoes when riding the scooter.




28. Anticipate your path and speed. Follow road and sidewalk rules, and obey all local laws when riding. Ride responsibly. Respect traffic rules, sidewalk codes, and local regulations. Always control your speed and follow the rules. Observe all local laws while riding.



2 Introduction to Functions

1. Product Overview



***The accessories and any additional items which are not approved by the manufacturer shall not be used.**

Accessories




Manual



Screw



Screwdriver



Power Adapter

Note: Please check out all the items in the package carefully. If anything is missing or damaged, please contact email: service@ride5thwheel.com


Product Contents	Quantity
User Manual	1
M5*12 Screw	6
M5*16 Screw	4
Screwdriver	2
Power Adapter	1

3 Product Display

Unfolded status



Folded status





This QR code is a video tutorial for product use. It is recommended to scan this QR code to learn more about how to use the product.




Pay attention

1. Press the power key to open the scooter.
- ⚠ 2. **For safety, the factory setting of scooter is non-zero start, you need to slide the scooter to 2mph(3km/h), and the throttle can be used normally.**
3. The scooter can be turned on normally and cannot ride in walking mode, but can only be pushed.
- ⚠ 4. **Can't start when charging.**
5. Do not throw away the manual, please refer to the manual for specific operations.
6. Devices are not intended for use at elevations greater than 2000 m above sea level.
7. Prolonged Exposure to UV Rays, Rain and the Elements May Damage the Enclosure Materials, Store Indoors When Not in Use.
8. WARNING-Risk of Fire- No User Serviceable Parts.
AVERTISSEMENT - Risque d'incendie - Aucune des pièces ne peut être réparée par l'utilisateur.
9. WARNING - Risk of Fire and Electric Shock - Battery and/or battery components are not user replaceable.
AVERTISSEMENT - Risque d'incendie et de décharge électrique - Les batteries ou leurs composants ne peuvent pas être remplacés par l'utilisateur.

4 Scooter Assembly


1. Take out the scooter, install the kickstand with the tool kit and unfold it. Then unfold scooter and fix the folding mechanism.
(Refer to "Folding and Carrying" for details of unfolding.)



3. Use the tools included in the package to tighten the screws.



2. Insert the handlebar into the scooter bar.



4. After assembly, check whether the power switch can work normally.

