



17. Engage the kickstand when the vehicle is not in use; Flip up the kickstand before use; Do not park the vehicle on the slope.




18. The minimum height of the user is 55 inch(140cm), while the maximum height is no more than 86.6inch(220cm); the maximum age of the user is 60 years old, while the minimum age is no less than 14 years old.




19. Braking performance and friction between the tire and road deteriorates in wet conditions, so it is harder to control the speed and easier to lose control. Slow down and brake early when it is raining.




20. WARNING Keep plastic covering away from children to avoid suffocation.



21. The user shall take the time to learn the basics of the practice to avoid any serious accident that can take place in the first month.




22. Notify your presence when approaching a pedestrian or cyclist when you are not seen or heard. Avoid high traffic areas or overcrowded areas.




23. Cross the protected passages while walking. In all cases, take care of yourself and others.




24. Do not divert the use of the vehicle. This vehicle is not intended for acrobatic use.




25. Caution, the brake may become hot in use. Do not touch after use.



26. Eliminate any sharp edges caused by use. Do not modify or transform the vehicle, including the steering tube and sleeve, stem, folding mechanism and rear brake.



27. The user has the obligation to always wear shoes when riding.




28. In any case, anticipate your trajectory and your speed while respecting the code of the road, the code of the sidewalk and the most vulnerable. If any, local special laws and regulations should be observed during riding of this product.



2 Introduction to Functions

1. Product Overview



***The accessories and any additional items which are not approved by the manufacturer shall not be used.**


Accessories




User Manual



M5*12 Screw×6
(2 spare)



3.0mm
Screwdriver



Power Adapter


Note: Please check out all the items in the package carefully. If anything is missing or damaged, please contact email: service@ride5thwheel.com

Power cord in different regions may have different versions.


Product Contents	Quantity
User Manual	1
M5*12 Screw	6 (2 spare)
Screwdriver	1
Power Adapter	1

3 Product Display

Unfolded status



Folded status





This QR code is a video tutorial for product use. It is recommended to scan this QR code to learn more about how to use the product.




Pay attention
before riding!

1. Press the power key to open the scooter.
- ⚠ 2. **For safety, the factory setting of scooter is non-zero start, you need to slide the scooter to 2mph(4km/h), and the throttle can be used normally.**
3. The scooter can be turned on normally and cannot ride in walking mode, but can only be pushed.
- ⚠ 4. **Can't start when charging.**
5. Do not throw away the manual, please refer to the manual for specific operations.
6. The suspension system have been fixed well in the manufacture, please contact with customer service if any issue occurred.
7. Devices are not intended for use at elevations greater than 2000 m above sea level.
8. Prolonged Exposure to UV Rays, Rain and the Elements May Damage the Enclosure Materials, Store Indoors When Not in Use.
9. WARNING - Risk of Fire- No User Serviceable Parts.
10. WARNING - Risk of Fire and Electric Shock - Battery and/or battery components are not user replaceable.


4 Scooter Assembly

1. Unfold the folding mechanism of the scooter and put down the kickstand.


Unfold the scooter and fix the folding mechanism.
(Refer to "Folding and Carrying" for details of unfolding.)



2. Insert the handlebar into the scooter stem.



3. Use the tools included in the package to tighten the screws.



4. After assembly, check whether the power switch can work normally.

