


1 Photo documentation of the EUT


1.1 Internal views

Open housing




The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Top view of the Main-Board PCB




The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Bottom view of the Main-Board PCB




The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Top view of the Processor-Board PCB



The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Bottom view of the Processor-Board PCB



The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

1.2 Internal views – Antenna


Top view of the Valve-Drive




Top view of the antenna module




Inside view of the antenna module



Top view of the Antenna PCB



Bottom view of the Antenna PCB



Top view of the Mixer-Antenna Assembly PCB (variant incl. housing)




Bottom view of the Mixer-Antenna Assembly PCB (variant incl. housing)



The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Antenna positions inside the equipment



- End of Attachment B -