



- FUNCTION:**
- FORWARD/BACKWARD
 - TURN LEFT/TURN RIGHT
 - WATER GUN

2-4G
REMOTE CONTROL

6+

PATROL VESSEL
WATER SURFACE REMOTE CONTROL SERIES



R/C

6+

WATER SURFACE REMOTE CONTROL SERIES

FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.




JETTING WATER

2-4G
REMOTE CONTROL

PATROL VESSEL
WATER SURFACE REMOTE CONTROL SERIES

SAFETY PRECAUTIONS

- For parents: please read the instructions with your children before using the product for the first time.
- Removed all packaging material before giving the product to a child.
- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating your car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Adult supervision is recommended when operating this car.
- Remove all batteries when not in use to avoid accident operation.
- Never operate your car in a confined or crowded area and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
- Make sure ON/OFF switch on your vehicle is in the "OFF" position when it is not in use.
- Do not leave car or transmitter near sources of heat or under direct sunlight for a long periods of time.
- Do not leave car or transmitter outside overnight.
- Dampness is harmful to interior components.



ATTENTION:
RISQUE DE SUFFOCATION-Petites pièces.
N'est pas destinée aux enfants de moins de trois ans.

WARNING:
CHOKING HAZARD-Small parts.
Not for Children under 3 years.

NOT SUITABLE FOR CHILDREN UNDER 3 YEARS
DUE TO SMALL PARTS
غير مناسب للأطفال دون سن 3 سنوات
بما في ذلك الألعاب الصغيرة
COUNTRY OF ORIGIN: CHINA
بلد المنشأ: الصين

صنعت وفقاً للمواصفات والمعايير الدولية
Tested according to international standards

CE, Recycle, 0-3, and other safety symbols.

SPECIFICATIONS AND COLORS OF CONTENTS MAY VARY FROM PHOTO.
KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

MADE IN CHINA CR2051-1

BATTERY WARNING

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
- Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state or local laws.
- Do not dispose of batteries in a fire - they may leak or explode.
- Only use manufacture specified battery(ies), charger(s) and / or adapter, if applicable, specifies by the manufacturer.
- Always use, replace and recharge (if applicable) batteries under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Exhausted batteries are to be removed from the toy.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.