

Manual



The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.



you have a iPhone, iPad, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later. 2) If you don't have an iOS device or smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved.

These features were created specifically to discourage people from trying to track you without your knowledge.

4. Specifications

Battery: CR2016 3V
Working voltage: 3V
Quantity of battery: 3 pieces
Wireless range: 10-300 meters
Buzzer: Max 100 D8


5. Button function

5.1 Power on (Find my function is on).
Press the function button 3 seconds to turn it on. It should a ring-ringing chime indicating it is powered on.
If the product is not linked with your apple ID, it will be closed within 10 minutes automatically. You need to trigger the find my function again to continue pairing.
5.2 Power off (Find my function is off).
Hold the function button for three seconds, then release it. you will hear two beeps indicating it is powered off.
5.3 Enable learn more information query.
Press the function button two times rapidly and you will hear a confirmation sound. This operation will be displayed on the find my app to guide the person who gets the device to obtain the device

1. Getting Started

1.1. Power On/Off

1.1.1 Power On: Hold the circular dot on the device's power button for 3 seconds, and when you hear a ring-ringing chime, it indicates that the device has been powered on. (Refer to the diagram)



1.1.2 Power Off: Press the device button twice, and you will hear a confirmation sound. Then press and hold the power button for 3 seconds. If you press it for less than 3 seconds or more than 3 seconds, the device will not power off. then release it., you will hear two beeps indicating it is powered off.
Remark: Setting a shutdown timer are designed to prevent accidental shutdowns, ensuring the device can continue to locate effectively.

1.2. Check For Updates

To use the Apple Find My app to locate item Locator, the latest version of iOS, iPadOS, or macOS is recommended. The Find My app on Apple Watch requires the latest version of watchOS.

information, such as the owner's contact information (if the item is set to the lost mode on the app), and the serial number of the device.

5.4 Restore factory settings
Press the function button two times, you can hear one beep, then Press the function button four times rapidly and then hold it a fifth time until you hear a ring-ringing chime, now the device is reset.

A reset operation is required to make the device enter the pairing state.

FAQ

1. Why find my device's location not updating.
There are two principles for product positioning reporting. If there are many Apple devices nearby, each new user in the vicinity of this device will report their location, typically within 2-5 minutes. If the device has not moved, the built-in sensors will detect this, and the device will enter a sleep mode. With the reported location ranging from 30 minutes to several hours. Don't worry, the location you see might be from 30 minutes or several hours ago, but it's very likely that the item hasn't moved, and the location you see is the last known location.
2. When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following action is recommended: 1. Change the phone's network, such as switching between WiFi and mobile. The first pairing may takes a long time, please wait patiently. 2. Reset your device. 3. Repair with Find My APP.


Privacy and Security

1. 操作说明

为了防止设备意外关机导致无法定位，我们改善了启动和关机方法。

1.1 开机关机

1.1.1 设备开机: 按住设备电源按钮上的圆形圆点开机键，按住3秒钟，当您听到铃声时，表示设备已开机。（参考图例）



1.1.2 关机: 按下设备按钮两次，会听到确认声，然后长按开关按钮3秒（如果您按住开关按钮不超过3秒钟或超过3秒钟，设备将不会关机），然后松开设备开关...，您将听到两声蜂鸣声，表示设备已关机。

8.1 添加联系人以共享此物品，与您共享过设备的人将能够一起寻找设备，并且他们不会收到未识别的跟踪通知。
8.2 要使用共享项目，请确保您和您的朋友已安装iOS 17、iPadOS 17或macOS 14 Sonoma公共测试版或更新版本。

10. 防追踪检测

如果发现任何与其所有者分离的“查找”网络配件正在移动，随着时间的推移，您将通过以下两种方式之一收到通知：(1) 如果您有iPhone或iPad，“查找”将向您发送 Apple 设备发送通知。
此功能在 iOS 或 iPadOS 14.5 或更高版本上可用。
(2) 如果您没有 iOS 设备，“查找”网络配件离开主人一段时间后，移动时会发出声音。这些功能是专门为了阻止人们在您不知情的情况下试图跟踪您而创建的。

常见问题

1. 为什么查找我的位置没有更新
产品定位报告有两个规则。首先，附近要有苹果设备，如果附近有苹果设备，则该设备附近的每个用户都会报告其位置，通常会在 2-5 分钟内报告。如果设备没有移动，内置传感器将检测到这一情况，设备将进入睡眠模式，报告位置的时间从 30 分钟到几个小时不等。别担心，虽然位置显示可能是数小时前，这很可能是物品没有发生移动，没有触发传感器更新位置，也就是说物品的位置没有发生变化。

2. Add Your Locator

2.1 Start the App

2.1.1 Open Find My app on your supported Phone or iPad.
2.1.2 Allow notifications from the app.

2.2 Connect your Locator

2.2.1 Power on your Locator, select the “Items” tab then tap the “Add Item” tab. Tap “Other Supported Items”.
2.2.2 Make sure your item Locator is close to your phone. Wait... until you see the pop-up “Wireless tag” then tap “Connect”.
2.2.3 Choose a recognizable name and emoji for your item Locator and tap “Continue”.
2.2.4 Find My will ask for confirmation to add your Locator for your Apple ID - tap “Continue”.
2.2.5 Tap “Finish” and your Locator will be set up and ready to be connected to whatever item you wish to locate, e.g., your keys.

3. Function introduction

3.1 Locate Your Item

When your item is nearby, tap “Play Sound” to make your Locator beep, then you can find it. When it is out of range, you can find Locator's Last Known Location.

3.2 Notifications

You will receive a notification when you leave your Locator behind when it's no longer in range of your device.
Note: “Notify When Found” can only be activated when your Locator is out of range.


3.3 Share Items

The people you've shared it with will be able to locate it, and they

Your Locator sends out a secure Bluetooth signal that can be detected by nearby devices in the Find My network. These devices send the location of your Locator to iCloud - then you can go to the Find My app and see it on a map. The whole process is anonymous and encrypted to protect your privacy.

WARNING

1. Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
2. Even used batteries may cause severe injury or death.
3. Call a local poison control center for treatment information.
4. Non-rechargeable batteries are not to be recharged.
5. Do not force discharge, recharge, disassemble, heat above 120°C/220°F or incinerate.
Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
6. The compatible battery type is CR2032.
7. The nominal battery voltage: DC 3V
8. Ensure the batteries are installed correctly according to polarity (+ and -).
9. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
10. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
11. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.



备注： 设置关机时间是为了防止设备意外关机，确保设备能够持续有效的定位。

1.2 系统检测

要使用 Apple Find My 应用程序来定位物品定位器建议使用 iOS、iPadOS 或 macOS 最新版本。Apple Watch 上的“查找物品”应用程序需要最新版本 watchOS。

2. 添加设备

2.1 打开 APP
2.1.1 在受支持的 iPhone 或 iPad 上打开“查找”应用程序。
2.1.2 允许来自应用程序的通知。

3. 连接定位器

3.1 定位器开机，打开“查找”APP。
3.2 点击“物品”图标，点击“添加物品”，然后点击“添加其他物品”。
3.3 找到“Wireless tag”弹窗后，点击“连接”为您的物品定位器选择一个可识别的名称和表情符号，然后点击“继续”。
3.4 “查找”APP 将要求确认添加您的定位器 Apple ID - 点击“继续”，点击“完成”，您的定位器将被设置好，您可以把它放到您想要查找的任何物品，例如您的钥匙。

4. 定位您的物品

4.1 当物品在附近时，寻找物品

won't receive unidentified-tracking notifications.

To use Share Items, make sure you and your friends have installed the iOS 17, iPadOS 17, or macOS 14 Sonoma public betas or newer.

3.4 Lost mode

When your item is lost, enable lost mode. you will receive a notification when location becomes available. You can leave a phone number or email address for the finder of your item to contact you.
Note: When “Lost Mode” is enabled, your Locator is locked and no one else can pair with it. And DO NOT REMOVE ITEM in the APP. Your Item Locator will be locked and cannot be used by any person.

3.4 Remove item

Make sure your item is nearby, you can remove item in the app, it should make a ring-ringing chime indicating it is removed successfully, then the item can be used by other people.

Note: When “Lost Mode” is enable, DO NOT REMOVE ITEM in the APP otherwise your Item Locator will be locked and no one else can pair with it.

3.5 Factory Reset Your Locator

When your item is out of the range of your phone, and your Locator is removed from Find My app, the device can't be used by other people. you need reset your locator, then it can be used by other people.
How to restore factory settings: Press the function button two times, you can hear one beep. Then Press the function button four times rapidly and then hold it a fifth time until you hear a ring-ringing chime, now the device is reset. The device can be repaired to a new Apple ID account as a new device.

3.6 Unwanted Tracking Detection

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways. (1) If

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet the general RF exposure requirement.

The device can be used in portable exposure condition without restriction.



使用说明



Apple Find My 网络提供了一种简单、安全的方式，可以使用 iPhone、iPad、Mac 上的 Find My 应用程序或 Apple Watch 上的查找项目应用程序查找兼容的个人项目。

要使用 Apple Find My 应用程序查找此项目，建议使用最新版本的 iOS、iPadOS 或 macOS、Apple Watch 上的“查找项目”应用程序需要最新版本 watchOS。

将 Works with Apple 徽标一起使用意味着产品的设计特别适用于徽标中标识的技术，并已获得产品制造商的认证，以满足 Apple Find My 网络产品规范和要求。苹果公司不对本设备的操作或本产品的使用或其是否符合安全和监管标准负责。



6.1 打开丢失模式

6.1.1 打开“查找”应用程序并选择“物品”选项卡

6.1.2 从列表中点击您的定位器。
6.1.3 在“丢失模式”下，启用“丢失”将弹出一个详细说明书丢失模式的屏幕，点击“继续”。
6.1.4 输入您的电话号码或电子邮件地址，然后点击“下一步”。

6.1.5 点击“启用”以启用“丢失模式”。
6.1.6 注意：当启用“丢失模式”时，“找到时通知我”将自动启用。
6.1.7 注意：启用“丢失模式”后，您的定位器将被锁定并且无法与新设备配对。

7. 恢复出厂设置

7.1 在查找APP中移除物品

7.1.1 打开“查找”APP，并选择“物品”选项卡
7.1.2 从列表中点击您的定位器。
7.1.3 请确保“丢失模式”已禁用
7.1.4 滑动到屏幕底部并点击“删除项目”。

7.2 恢复出厂设置

成功从“查找”APP中删除定位器后，双击定位器按钮，您将听到一声蜂鸣声，然后快速按定位器的功能按钮四次，第五次长按直到听到一声铃声，此时定位器已重置并准备好与新的设备配对。

8. 共享此物品

隐私与安全

您的定位器会发送一个安全的蓝牙信号，“查找”网络附近的设备可以检测到该信号。这些设备会将定位器的位置发送到 iCloud，然后您可以转到“查找”应用程序并在地图上看到它。整个过程是匿名和加密的，以保护您的隐私。

警告

警告：请务必将电池放在儿童接触不到的地方，由于化学灼伤和潜在的食道穿孔，吞咽可能会导致严重的伤害或者死亡，如果小孩不慎误吞了纽扣电池，请立即拨打急救电话并及时就医。

产品内置纽扣电池，禁止六岁及以下儿童使用。

