



Wireless Mechanical Keyboard

Knob
Version

Fully Assembled Version

Keyboard

1x Fully Assembled Keyboard

Including

1x Aluminum Case

1x PCB

1x PC Plate

1x Sound Absorbing Foam

1x IXPE Foam

1x PET Film

1x Latex Bottom Pad

1x Bottom Case Acoustic Foam


1x Bottom Case PET Film

16x Gaskets (12 Installed and 4 in the Box)

5 sets x Stabilizers

1 set x Keycaps (PBT Double-shot)

1 set x Switches



Cable

1x Type-C Cable

1x Type-A to Type-C Adapter

1x Extension Adapter for Receiver

Receiver


1x Type-A 2.4 GHz Receiver

Tools

1x Keycap & Switch Puller

1x Screwdriver

1x Hex Key




Barebone Version

Keyboard Kit

1x Keyboard Kit (Without Keycaps & Switches)

Including

- 1x Aluminum Case
- 1x PCB
- 1x PC Plate
- 1x Sound Absorbing Foam
- 1x IXPE Foam
- 1x PET Film
- 1x Latex Bottom Pad
- 1x Bottom Case Acoustic Foam
- 1x Bottom Case PET Film
- 16x Gaskets (12 Installed and 4 in the Box)
- 5 sets x Stabilizers



Cable


- 1x Type-C Cable
- 1x Type-A to Type-C Adapter
- 1x Extension Adapter for Receiver

Receiver

- 1x Type-A 2.4 GHz Receiver

Tools


- 1x Keycap & Switch Puller
- 1x Screwdriver
- 1x Hex Key



Quick Start Guide


If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.

Mac / Windows




1 Connect 2.4 GHz Receiver


Switch toggle to 2.4 GHz mode




Press fn + 4 (for 3 seconds)



Connect the 2.4 GHz receiver to the device USB port.




Note: For the best wireless experience, we recommend using the extension adapter for receiver and putting the 2.4 GHz receiver somewhere on your desk close to your keyboard for a low rate of latency and fewer signal interferences.




2 Connect Bluetooth



Press fn + 1 (for 3 seconds) and pair with device named Keychron Q3 Ultra 8K



Switch toggle to Bluetooth




fn + 1

3 Connect Cable




Switch toggle to Cable



[Cable symbol] = Cable Mode

4 Switch To The Right System

Please make sure the system toggle on the top right corner has been switched to the same system as your computer's operating system.




5 The Backlight

Press fn + Q to change the lighting effect



fn + Q


Press fn + tab to turn the backlight on/off



fn + tab

6 Adjust The Backlight Brightness

Press fn + W to increase the backlight brightness



fn + W


Press fn + S to decrease the backlight brightness



fn + S


7 Adjust The Backlight Speed

Press fn + T to increase the light effect speed



fn + T

Press fn + G to decrease the light effect speed



fn + G

8 The Keychron Launcher App

Please visit launcher.keychron.com to use the online Launcher web app to remap the keys, create macro commands, or flash the firmware. If the Launcher cannot recognize your keyboard, please reach our support to get the instructions.



* The online Launcher can only run on the latest version of Chrome, Edge, and Opera browsers.

9 The Layers

There are four layers of key settings on the keyboard. The layer 0 and layer 1 are for the Mac system. The layer 2 and layer 3 are for the Windows system.

If your system toggle is switched to Mac, then the layer 0 will be activated.

If your system toggle is switched to Windows, then the layer 2 will be activated. Remember that if you are using it in Windows mode, please make changes to the layer 2 instead of the top layer (the layer 0). This is a common mistake people are making.

