

尺寸:70*72*15mm
材质:250单粉对裱250单粉+哑胶+V槽



TX16说明书 128g双铜双面 4色 风琴折 折后尺寸60*60mm

Maysell TEXTURE TAG USER GUIDE Works with Apple Find My	Overview introduction Texture tag integrates with Apple Find My Network, providing a secure and user-friendly solution for finding belongings. It effortlessly locates keys, wallets and more using Apple Find My Network, prioritizing security. Designed for user convenience, Texture tag simplifies daily life. Say good bye to lost items with Texture tag and Apple Find My Network, experiencing a future of enhanced item finding and peace of mind. Trust Texture tag to redefine how you manage essentials effortlessly. How To Pair Note: iOS or macOS with the latest version. (Figure1) (Figure2) (Figure3) 1.1 Place the Texture tag next to your Apple device like iPhone. 1.2 Turn on Bluetooth on iPhone and connect to Internet. 1.3 Press the finder front button hear one beep to power on.	1.4 Open the 'Find My' app. 1.5 In 'Find My' app, tap '+', then 'Add Other Item'. As shown in Figure 1. 1.6 Once your Texture tag is located, tap 'connect'. As shown in Figure 2. 1.7 Enter a name and choose an emoji for your Texture tag and tap 'Continue'. As shown in Figure 3. 1.8 Find My will ask for confirmation to add your Texture tag to your Apple ID 'Tap Agree'. 1.9 Tap 'Finish' and your Texture tag will be set up and ready to be used. Battery Texture tag Contains a coin-shaped battery. During the product's lifespan, it may be necessary to replace the battery. By observing the correct negative and positive connections, only replace batteries of the same type (CR2032) and rating. Battery replacement 2.1 Pry off the back cover. 2.2 Replace a new battery. 2.3 Close the back cover. Additional Tips 3.1 To switch from active mode to disable mode (airplane mode), simply remove the battery.	3.2 To switch from disable mode (airplane mode) to working mode, install the battery any. Texture tag will be successfully paired after this. 3.3 Press and hold the button until you hear 1 prompt tone, followed by 2 consecutive prompt tones, and then 3 consecutive indicator tones. Continue to press for 5 seconds. When you hear a long indicator tone, release the button to restore the device to its factory settings. 3.4 To remove the texture tag from your Apple devices, open the 'Find My' app, select 'Items', find the device, and scroll down to click on 'Remove this device'. 3.5 If the texture tag fails to connect to the 'Find My' app, follow the instructions in section 3.3 to perform a factory reset, and then restart the pairing process. Important matters Texture tag contains delicate electronic parts, including a battery to avoid damage, loss of function, or potential harm. Please refrain from dropping, hitting, puncturing, crushing, disassembling, exposing it to extreme heat or liquids, or placing it in areas with a high concentration of industrial chemicals.	WARNING: Do not swallow the battery. There is a chemical burn hazard. Choking Hazard Warning Texture tag, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children. Medical Device Interference Texture tag contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other medical devices. To ensure safety, maintain a safe distance between your medical device and texture tag. We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you suspect that Texture tag is interfering with your pacemaker defibrillator or any other medical device, discontinue its use immediately. Important Handling Guidelines Is normal for Texture tag to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth. Avoid applying	pressure with sharp objects on the rubber seal or the battery terminal contacts inside the device. Do not allow moisture to enter any openings or use aerosol sprays, solvents or abrasive materials to clean the device. Legal notice Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My Network product Specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, AirPods, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
---	---	---	--	---	--

正面

Maysell TEXTURE TAG 使用说明书 Works with Apple Find My	概述介绍 Texture tag 是苹果公司为 iOS 网络服务，为物品追踪提供了一个安全且用户友好的解决方案。使用 Find My 网络轻松定位钥匙、钱包等，并优先考虑安全性。FINDER 专为方便用户而设计，简化了日常使用。使用 FINDER 和苹果 Find My 网络告别丢失物品。保持您的物品更安全、更安心。信任 FINDER 重新定义您管理重要物品的新方式。 如何配对 注:请使用 iOS 或者 macOS 最新版本。 (1) (2) (3)	1.4 打开“查找”应用程序。 1.5 在“查找”应用程序中，点击添加物品-其他支持物品。如图1所示。 1.6 点击“继续，如图2所示。 1.7 点击您的物品，并选择一个表情。然后点击“继续”，如图3所示。 1.8 将您的物品与 FINDER 添加您的 Apple 设备。点击“同意”。 1.9 点击完成即可添加成功。 电池 FINDER 包含一枚硬币形状的电池。在产品使用寿命期间，可能需要更换电池。请按照正确的正负极连接，只能更换同类型 (CR2032) 和额定值的电池。 电池处理 2.1 撬开背面盖。 2.2 更换新电池。 2.3 盖上盖子。 其他提示 3.1 将 FINDER 放在您的苹果设备 (如 iPhone) 旁边。 3.2 打开您的设备 (如 iPhone) 上打开蓝牙并连接到互联网。 3.3 按一下 FINDER 按钮，听到一声蜂鸣声即可开机。	泡。在此之后，FINDER 将成功配对。 3.2 按住按钮，直到听到 1 个提示音。然后是两个连续提示音。接着是 3 个连续指示音。继续按住按钮，直到听到长指示音。松开按钮，直到您的物品发出 1 声长音。 3.3 按您的设备并选择添加物品-FINDER。将打开“查找”应用程序。选择“物品”，继续设置。然后向下滚动点击“移除此设备”。 3.5 如果 FINDER 无法连接到 Find My 应用程序，请按照第 3.3 中的说明，执行恢复出厂设置，然后重新自动配对过程。 重要事项 FINDER 包含精密的电子部件，包括电池。为避免损坏、功能丧失或潜在伤害，请避免跌落、撞击、刺穿、拆卸、暴露在高温或液体中，或将其放在儿童或宠物可触及的地方。 警告: 请勿吞下电池。存在化学灼伤危险。	紧急危险警告 FINDER、电池舱门、电池本身和外壳可能会导致化学危险或对儿童造成伤害。请将这些物品放在儿童够不到的地方。 医疗干扰警告 FINDER 包含发射电磁场的组件和无线电路。这些元件可能干扰或妨碍其他医疗或设备。为确保安全，请在您的医疗设备和 FINDER 之间保持安全距离。我们强烈建议您咨询您的医生和医疗设备制造商，以获取针对您具体情况的建议。如果怀疑 FINDER 干扰了您的辅助设备或其他医疗设备，请立即停止使用。 重要处理指南 FINDER 在日常使用时可能会出现正常磨损。为避免安全，请避免跌落、碰撞、刺穿、拆卸、暴露在高温或液体中，或将其放在儿童或宠物可触及的地方。请勿将腐蚀性液体或压力。不要将湿气引入任何开口，也不要使用气溶胶、溶剂或研磨材料清洗设备。 法律公告 使用 Works with Apple Find My 网络苹果产品已经设计为专门与苹果中确定的技术配合使用，并已通过产品制造商的认证。	Apple 不对该设备的运行、使用或是否符合安全及监管标准负责。Apple, Apple Find My, Apple Watch, iPhone, iPad, AirPods, Mac, macOS 和 watchOS 是苹果股份有限公司在美国和其他国家注册的商标。iOS 是苹果在美国和其他国家/地区的商标或注册商标，经许可使用。
--	--	--	--	--	--

反面

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two

conditions: (1) This device may not cause harmful interference, and (2) this device must accept any

interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device,

pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation. This equipment generates, uses and can

radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is

connected.

•Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could

void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.