

128g 双铜双面 4 色 风琴折 折后尺寸 60*67mm

GUO-LINK

USER GUIDE



Overview introduction

The device integrates with Apple Find My Network providing a secure and user-friendly solution for finding belongings. Use the Find My network to easily locate bikes, backpacks, suitcases, etc., and prioritize security. Apple Find My Network, experiencing a future of enhanced item finding and peace of mind. Trust it to redefine how you manage essentials effortlessly.

How To Pair

Note: iOS or macOS with the latest version.



- 1.1 Place the device next to your Apple device like iPhone.
- 1.2 Turn on Bluetooth on iPhone and connect to Internet.
- 1.3 Press the finder front button hear one beep to power on.
- 1.4 Open the 'Find My' app.
- 1.5 In 'Find My' app, Tap '+', then 'Add Other Item'. As shown in Figure 1.

- 1.6 Once your device is located, tap 'connect'. As shown in Figure 2.
- 1.7 Enter a name and choose an emoji. As shown in Figure 3 and tap 'Continue'.
- 1.8 Find My will ask for confirmation to add your device to your Apple ID. Tap 'Agree'.
- 1.9 Tap 'Finish' and it will be set up and ready to be used.

Battery

The device contains a battery in the shape of a coin. During the life of the product, batteries may need to be replaced. To replace the battery, unlock the combination lock first, slide the dial switch on the back of the combination lock, and then pry the front cover of the combination lock, then remove the lower cover to replace the button battery.

Replace the battery

- 2.1 Unlock the combination lock.
- 2.2 Slide the DIP switch.
- 2.3 Pry the face cover.
- 2.4 Replace the button battery.

Password setting

- 3.1. Make sure that the password is unlocked correctly, rotate the reset wheel (orange) clockwise until it cannot continue to rotate, and hold it still.
- 3.2. Rotate the password wheel to set the new password you

want (It is recommended to set a single, easy-to-remember password for the first time, such as 0-0-1).

- 3.3. After the setting is complete, rotate the reset wheel counterclockwise until the single horizontal line on it coincides with the password alignment line. (Note: The password will only be successfully modified if the reset wheel is properly aligned.)
- 3.4. Please keep in mind the new password you set. To change it again, repeat the steps above.

Additional Tips

- 4.1 To switch from Work Mode to Disabled Mode (Flight Mode), just press and hold the button. Keep holding until you hear 1 beep, followed by 2 consecutive beeps, then 3 consecutive beeps—after that, it will turn off.
- 4.2 To switch from the disabled mode (flight mode) to the working mode, please restart the device. After this, it will be successfully paired.
- 4.3 Press and hold the button until you hear 1 prompt tone, followed by 2 consecutive prompt tones, and then 3 consecutive indicator tones. Continue to press for 5 seconds. When you hear a long indicator tone, release the button to restore the device to its factory settings.
- 4.4 To remove the device from your Apple devices, open the Find My app, select 'Items', find the device, and scroll down

to click on 'Remove this device'.

- 4.5 If the device fails to connect to the 'Find My' app, follow the instructions in section 4.3 to perform a factory reset, and then restart the pairing process.

Important matters

The device contains precise electronic components, including batteries. To avoid damage, loss of function or potential injury, please avoid dropping, impact, puncture, crushing, disassembly, exposure to high temperatures or liquids, or placing it in areas with high concentrations of industrial chemicals.



WARNING: Do not swallow the battery; There is a chemical burn hazard.

Choking Hazard Warning

The device, its battery compartment door, battery, and outer casing may pose a choking hazard or cause injury to young children. Keep these items out of the reach of small children.

Medical Device Interference

The device contains components and radios that emit electromagnetic fields. These may potentially interfere with pacemakers or other medical devices. For safety, maintain a

safe distance between this device and your medical device.

We strongly recommend consulting your doctor and the manufacturer of your medical device for information specific to your situation. If you suspect this device is interfering with your pacemaker or any other medical device, stop using it immediately.

Important Handling Guidelines

Discoloration of the device with regular use is normal. To clean it, use a soft, dry, lint-free cloth. Avoid applying pressure to the rubber seals inside the device or the battery terminal contacts with sharp objects.

Do not allow moisture to enter any openings in the device, and do not use aerosols, solvents, or abrasive materials to clean the device.

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPods, Mac, macOS and watchOS are the trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

ICC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. RF Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.