




YZ75



User Manual

マニュアル ユーザー手册

Website: www.yunzii.com
For any support: support@yunzii.com



CUSTOMER SERVICE



DISCORD



OFFICIAL STORE



INSTAGRAM

QUICK START GUIDE

MODEL: YZ75 Wireless
SIZE: ≈330mm×138mm×32mm
HOTSWAP: YES
SYSTEM: Windows/Mac/Linux/
Android/iOS
BATTERY: 5000mAh

CONNECT: 2.4GHZ Wireless/Bluetooth/
Wired connection
WEIGHT: 950±50g
LAYOUT: 82 KEYS
KEYCAPS: PBT
LIGHT: RGB
PCB: South Facing PCB

FUNCTION



FN +	FUNCTION
FN + Esc (5s)	Reset
FN + Win	Win Lock
FN + Del	Ins
FN + Back	Battery Saving Mode
FN + P	Keyboard Lock
FN + F1	Screen Brightness-
FN + F2	Screen Brightness+
FN + F3	Task switch
FN + F4	Open Web
FN + F5	E-mail
FN + F6	My computer
FN + F7	Previous song
FN + F8	Play / Pause
FN + F9	Next song
FN + F10	Mute
FN + F11	Volume-
FN + F12	Volume+

FUNCTION KEY



FN +	FUNCTION
FN + Esc (5s)	Reset
FN + Del	Ins
FN + Back	Battery Saving Mode
FN + P	Keyboard lock
FN + F1	Screen Brightness-
FN + F2	Screen Brightness+
FN + F3	Screenshot
FN + F4	Open Web
FN + F5	Mute
FN + F6	Volume-
FN + F7	Volume+
FN + F8	Previous song
FN + F9	Play / Pause
FN + F10	Next song
FN + F11	Search
FN + F12	Home page

INDICATOR LIGHT



CAPS Lock



Lock Win/Fn



Keyboard Lock



Battery

Email: support@yunzii.com

CONNECTIONS AND RGB GUIDE

CONNECTION MODE

FN +	FUNCTION
FN + 1	BT1
FN + 2	BT2
FN + 3	BT3
FN + 4	2.4G
FN + 5	Wired

CONNECTION STEPS

Bluetooth Connection:

1. Turn on the ON/OFF button on the backside of the keyboard.
2. Short press the FN+1/2/3 to select the Bluetooth channel, and the 1/2/3 key will flash slowly.
3. Long press the FN+1/2/3 for 5s to the Bluetooth pairing mode, the 1/2/3 key will flash fast.
4. Select the YZ75 3.0/YZ75 5.0 to connect it, and the RGB will stay on when paired successfully.

Note: If the pairing fails, the keyboard indicator turns off and goes to sleep, please reconnect it.

2.4G Connection:

1. Turn on the ON/OFF button on the backside of the keyboard.
2. Short press the FN+4 to the 2.4G channel, and the 4 key will flash slowly.
3. Long press the FN+4 for 5s to the 2.4G pairing mode, the 4 key will flash fast.
4. Plug the 2.4G dongle into your device, the device will automatically recognize your keyboard, and the RGB will stay on when paired successfully.

Note: If the pairing fails, the keyboard indicator turns off and goes to sleep, please reconnect it.

Wired Connection:

1. Take the original keyboard cable from the package
2. Plug the cable into your device
3. The keyboard will automatically recognize your system, and then the connection is successful.

Note: If the keyboard has not recognized the wired connection, please long press FN+5 for 3s to the wired mode.

How to change the devices

1. Short press FN+1/2/3/4/5 for 3s to change the connection devices.
2. When the keyboard is in pairing mode, the indicator light will flash slowly; When paired successfully, the keyboard RGB and indicator light will stay on for 2s.
3. If the pairing fails, the keyboard indicator turns off and goes to sleep mode.

Battery

When the battery is lower than 5%, the indicator light will flash red slowly, the backlights will turn off; In charging, the indicator light will stay yellow; when charging is complete, the indicator light will stay green.

Power Query

Press Fn+Space to check the remaining power of the keyboard, the RGB backlights off, and the number keys 1 to 0 will light up to show the power ratio. e.g. Numbers 1-5 light up means 50% battery left.

Power save mode

The keyboard will automatically turn off the backlight without operation within 5 minutes, and enter a deep sleep without operation for 30 minutes.

RGB SETTINGS

FN +	FUNCTION
FN + Back	RGB Light On/Off
FN + End	Change Back Light Effect
FN + Home	Change Back Light Color
FN + PgUp	Light Effect Direction
FN + ←→	Back Light Speed
FN + ↑↓	Back Light Brightness
FN + RIGHT CTRL	Change Side Light Effect
FN + RIGHT ALT	Change Side Light Color
FN + []	Side Light Brightness
FN + ; "	Side Light Speed V

Website : www.yunzii.com

Email: support@yunzii.com

KEYBOARD SOFTWARE

Download method:

1. Open the official website of yunzii, click on the software.
2. Unzip the downloaded software package and click the exe file to install.
3. After the installation is complete, use the wired mode to connect to the computer, and the software will automatically recognize the keyboard.
4. After the connection is completed, start using the software.

Software Download : www.yunzii.com

System Support: Windows


Email: support@yunzii.com

Driver update


Open the software and click Update software in the lower right corner to get the latest version of the software.

REPLACE KEYCAPS AND SWITCH

Included Tools



Mechanical Switch



Remove Keycaps

1. Grab your Keycap Puller Tool and place it above the keycap you want to remove at a 90 degree angle.
2. Push your Keycap Puller down until the metal hooks to open themselves and grab the keycap from underneath.
3. Grab your Keyboard firmly and pull the keycap in a vertical motion.

Install Switches

1. Check that all the switch metallic pins are perfectly straight and clean.
2. Align the switch lamp hole with the backlight, The pins align themselves to the keyboard PBC.
3. Press the switch down until you hear a click. This means your switch clips have attached themselves to the keyboard plate.
4. Inspect the switch to ensure it's properly attached to your keyboard, and test it.

Install Keycaps

1. Make sure the Keycap is properly oriented in your keyboard and place it above the switch.
2. Push the keycap into the switch shaft firmly.

Remove Switches

1. Grab your Switch Removal Tool and align the gripping teeth vertically (on the Y-Axis) at the center of the switch, as shown in the example graphic above.
2. Grab the switch with the Switch Puller and apply pressure until the switch releases itself from the plate.
3. Using firm but gentle force pull the switch away from the keyboard using a vertical motion.



Note: if the key doesn't work, you may have bent one of the switches while installing it. Pull the switch out and repeat the process.

Pins may be damaged beyond repair and need replacement if this process is not done correctly. Never apply excessive force when replacing keycaps or switches. If you cannot remove or install keycaps or switches, please contact customer service as soon as possible to avoid damage to the keyboard due to operating errors.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.