

True Wireless Stereo Earbuds
LT-004
Instruction

Please read the instruction manual carefully before using the product and keep it with proper care.

1. Product parameter

Model No.: LT-004

Material: ABS

Wireless version: V5.3

Music time: About 4 hours

Talking time: About 3 hours

Battery capacity: 3.7V,30mAh(earphones)
3.7V,300mAh(charging case)

Wireless pair name: LT-004

Working distance: >10m

Frequency response: 20Hz~20KHz

Charge interface: Type-c

Compatibility: compatible with all wireless devices

Charging time: 1 hour (earphones)
2 hours (charging case)

2. Packing list

Charging case *1pcs	Earphone (L&R) *2pcs	Charging cable *1pcs	Eartips *4pcs	User manual *1pcs
------------------------	-------------------------	-------------------------	------------------	----------------------

3. Software default operation

Binaural mode button function


- Power On Tone: Power On English Tone POWER ON
- Voice: English
- Main/auxiliary ear pairing: the headset is turned on the main/auxiliary ear automatic pairing
- Power on/off Power on: out of the charging compartment/long press the headset touch 3S.
Power off: into the charging compartment/long press the headset touch 5S.
- Volume up: Triple touch on right ear
- Volume down: triple-tap left ear touch
- Next: Double-tap Right Ear Touch
- Previous song: Double-click left ear touch
- Play/Pause: Click the left/right ear touch to play and pause the music
- Answer/Hang up: When there is an incoming call, click
- Reject call: Long press for 2 seconds when the call comes
- Siri: Long press the touch key 2S beep to release the hand to wake up Siri

4. Product Operating Method

1. Initial use


Step 1 - Turn on

The earphones automatically power on after open the cover.



Step 2 - Pairing mode

The earphones automatically enter pairing mode after power on.




Step 3 - Wireless connectivity

Turn on the Wireless function of the mobile phone, select the device model: LT-004, then click it to connect earphone to mobile phone.



Step 4 - Shutdown

The earphone automatically shutdown after place the earphone back in charging case and close the cover.



Note:

1) Indicator light

Power on: Red and white lights flash alternately

Off: Red light on for 5 seconds

Pairing: Red and white light flashes alternately

Successful connection: No light flashing

Music Playing: No blinking light

Music Pause: No light

Incoming call: White light flashing

Incoming call: White light flashes

Low battery: Red light flashing

Charging: Red light always on

Fully charged: Fully charged white light on for 10 seconds and off

Charging: Red light flashing

Fully charged: Red light on for a long time

Low battery: Red light blinks for 2 seconds

5. Product safety information

Please read **all** the instructions and warnings before using this product. Non-standard use **will** damage the product or personal safety.

- The battery is included in the product. Please do not expose it to sunlight, fire or similar overheating; Do not store the product in high temperature, strong light and strong magnetic field. Do not place it in other harsh environments such as fire source. If water enters, dry it naturally and use it again.
- Improper use of the product can easily cause damage to the product or may endanger personal and property safety.
- Consumer **shall** be liable for any personal and property damage resulted from their improper use against the user manual or ignoring the warning, to which our company **will** not bear any legal liability.
- Disintegration of this product by non-professionals is strictly prohibited.
- Use of household appliances or loads in excess of the output current of this product shall be avoided (no output due to circuit protection).
- Intense physical actions including knocking, throwing, trampling on and squeezing, etc. **shall** be avoided.
- The ambient temperature of product is 0-45°C.

Warning



Please follow the above safety instructions otherwise it will cause fire, electric shock, damage or other damage.

6. FAQs:

Q1. Why my product can not be turned on/off?

- A: 1) Make sure that the charging case has battery left, put the earphones back in the charging case, and close the lid to turn off the earphones automatically.
2) When the charging case is out of battery, please turn off the bluetooth function on your phone and the earphones will turn off automatically in 5 minutes;
3) Keep the charging area of the earphones and Pogo pin of the charging case clean, and regularly clean them with dry cloth.

Q2. Why is the touch function not sensitive?

- A: 1) Make sure that the functional area of the earphones is clean and water-free;
2) Make sure that the fingers to touch the earphones are without water or other foreign objects;
3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 1s;
4) If the earphones can not be returned to normal after the above steps, please put the earphones back into the charging case, manually ignore the phone wireless device and turn off wireless, and restore factory settings before reconnection.

Q3. Why can't my product connect to the wireless device again?


- A: 1) The earphones will be disconnected if they are out of the connection range of 10 meters. The earphones will automatically shut down if they are not back to the connection range within 5 minutes.
2) If the earphones fail to connect to the wireless device again within 5 minutes, please put the earphones into the charging case and close the lid, and then take them out.

Q4. Why is one of my earphones without sound after I take them out?

- A: 1) If this problem occurs, please put the earphones into the charging case and close the lid, and then take them out.
2) If it is unable to connect after the above operation, please turn off the bluetooth of other mobile phones close to the mobile phone and restore factory settings before connecting.

Q5. The mobile phone cannot find the Wireless headphone, the bluetooth connection is unstable or disconnected during use, thus resulting in unsmooth sound/interruption?

- A: 1) Please do not exceed the bluetooth connection distance of the mobile phone, so as to avoid interference from the wall or the human body;
2) Please make sure the earphone has enough power, and re-enter the pairing mode to connect;
3) If it is unable to connect after the above operation, please turn off the bluetooth of other mobile phones close to the mobile phone and restore factory settings before connecting;
4) Due to the property of the Wireless earphone, the electromagnetic waves in your area may interfere with the bluetooth connection, resulting in sound problem or disconnection, please stay away from such areas before connecting.



真无线蓝牙耳机LT-004

使用说明书

使用产品请仔细阅读本使用说明，并请妥善保管

一、产品参数

型号：LT-004	蓝牙配对名：LT-003
材质：ABS	连接距离：约10米
蓝牙版本：V5.3	频响范围：20Hz-20KHz
音乐时间：约4小时	接口：Type-c
通话时间：约3小时	适用：具有蓝牙功能的设备
电池容量：3.7V, 30mAh (耳机)	充电时间：约1小时 (耳机)
3.7V, 300mAh (充电仓)	约2小时 (充电仓)

二、包装清单

充电盒*1pc	耳机(L&R)*2pcs	充电线*1pc	耳帽*4pcs	说明书*1pc
---------	--------------	---------	---------	---------

3. 软件默认操作

对耳模式按键功能


- 开机音：开机英语音 POWER ON
- 声音：英语
- 主耳/副耳配对：耳机打开后主耳/副耳自动配对
- 开机/关机 开机：从充电盒中取出/长按耳机触控 3S。
- 关机：进入充电舱/长按耳机触控 5S。
- 提高音量：右耳轻触三下
- 音量减小：触摸左耳三下
- 下一首歌：双击右耳触控
- 上一首歌：双击左耳触控
- 播放/暂停：单击左/右耳朵触控按钮播放和暂停音乐
- 接听/挂断：有来电时，单击
- 拒接来电：来电时长按 2 秒

四、产品操作方法

1.首次使用


第1步--开机

打开充电仓盖子后，耳机自动开机。



第2步--配对模式

耳机开机后自动进入配对模式。




第3步--蓝牙连接

打开手机蓝牙功能，选择蓝牙配对名LT-004，点击进行连接手机与耳机。



第4步--关机

将耳机放回充电盒，并盖上盖子，耳机自动关机。



注意:

1) 指示灯

接通电源: 红灯和白灯交替闪烁

关闭: 红灯亮 5 秒

配对: 红灯和白灯交替闪烁

连接成功: 无灯闪烁

播放音乐: 指示灯不闪烁

音乐暂停: 无指示灯

来电: 白灯闪烁

来电: 白灯闪烁

电池电量不足: 红灯闪烁

充电: 红灯常亮

充满电: 充满电白灯亮 10 秒后熄灭

充电: 红灯闪烁

充满电: 红灯长亮

电池电量不足: 红灯闪烁 2 秒钟

五、产品安全信息

在使用本产品前请阅读所有的指示与警告，不规范使用将会给产品与人身安全带来损害。

- 产品内含电池，请不要暴露在日照，火烤或者类似过热环境中；不要将本产品存储在高温，强光及强磁场环境下，不要放置在水源等其它恶劣环境中，如果进水，请自然晾干后再使用。
- 产品使用不当，容易造成产品本身或者可能危及人身财产安全。
- 如因消费者违反产品说明书不恰当使用，造成的人身及财产损失将自行承担一切后果，本公司将不承担任何法律责任。
- 非专业人员严禁分解本产品。
- 避免使用超出本产品输出电流的用电器或负载(电路会保护，无输出)。
- 避免强烈的物理作用，包括敲击、投掷、践踏、挤压等。
- 产品使用环境温度：0-45℃

警告



请遵循以上安全说明，否则会导致起火、触电、损害或者其他伤害

六、常见问题解答：

1. 为什么我的产品不能关机？

答：1) 确保充电盒有电的情况下，将耳机放回充电盒，并关上盖子，耳机将自动关机；

2) 当充电盒没有电时，请关闭手机上的蓝牙功能，等待5分钟后，耳机将自动关机；

3) 保持耳机充电区与充电盒充电弹针的洁净，并定期用干净的干棉布进行清洁。

2. 为什么触摸功能不灵敏？

答：1) 请确保耳机触摸功能区域干净且无水渍；

2) 请确保进行触摸操作的手指无水渍或其他异物；

3) 请确保触摸位置正确，并在1秒内完成快速双击或三击操作；

4) 如上操作仍无法恢复正常，请将耳机放回充电仓，手动忽略手机蓝牙设备并关闭蓝牙，进行恢复出厂设置操作后再进行连接。

3. 为什么我的产品无法回连？

答：1) 超出连接范围10米耳机将断开连接，5分钟内未重新回到连接范围内，耳机将自动关机；

2) 超出5分钟未重新回连的，请将耳机放回充电盒并盖上盖子，再将耳机取出。

4. 为什么我的耳机取出后一边没有声音？

答：1) 出现此情况时，请将耳机放回充电盒并盖上盖子，再将耳机取出；

2) 如上操作仍无法连接，请将手机周围手机蓝牙全部关闭，进行恢复出厂设置操作后再进行连接。

5. 手机搜索不到蓝牙耳机，蓝牙连接不稳定或使用中和手机断连，出现声音卡顿/断续？

答：1) 请不要超出手机蓝牙连接距离10米，避免受到墙体或人体的隔挡干扰；

2) 请确保耳机有足够电量，并重新进入配对模式进行连接；

3) 如上操作仍无法连接，请将手机周围手机蓝牙全部关闭，进行恢复出厂设置操作后再进行连接；

4) 由于蓝牙耳机的特性，您所在区域的电磁波可能干扰蓝牙的连接，导致出现无声或者断连的情况，请远离此类区域再进行连接。

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.