

User manual



Read these safety instructions before using the device and store them for future reference.

YThis wireless Bluetooth headset contains two pairs of sports clip-on YKY-J02 and handle YKY-B01 headphones, which are connected to the device even during other activities (such as exercise) , you can still listen to music and answer calls. Before using their mobile devices, make sure they are compatible with this device.

Be careful not to wet the equipment when using it. If the equipment is damaged by water, it may malfunction. Avoid storing or using the device at temperatures lower than -15°C or higher than 55°C, which could shorten the headset or battery life.

Specifications


Model: MD5
Bluetooth connection: YKY-B01、 YKY-J02
Bluetooth Version: V 5.3
Bluetooth Range: 10meters
Playback time: 4-5 hours
Charging time: 1-1.5 hour
Standby time: 100 hours

Accessories:


- 1*user manual
- 1*type-c charging cable

Key function diagram

Charging box



Earphone



Use headphones

1. Insert the headset into the acupoint of the headset charging box correctly. If the indicator light does not blink, connect the charging box to the charger and charge it for more than 10 minutes.
2. Close the charging box.
3. Open the charging box and take out the headset, the headset will automatically enter the pairing mode
4. On the mobile device, enable Bluetooth function to search for " YKY-B01and YKY-J02 " and connect it to the mobile device
5. If you can't pair your J02 headphones with your B01 headphones, put them back in the charging box and close the lid, then take out the J02 headphones from the charging box to finish pairing.

Touch control

Touch pannel	Left earbuds	Right earbuds
Long Touch	Power on/off	Power on/off
Single Touch	Play/ Suspend	Play/ Suspend
Long press (2 seconds)	Next track	Previous track
Tap twice	Volume +	Volume -

Function	Touch pannel
Answer calls	Single Touch
Reject incoming call	Long press (2 seconds)
Redial last number	Single Touch
Voice Assistant	Third times Touch
Language switching	Double-click twice when not connected

When the left and right ears cannot pair. Please click four times when not connected to your phone Earphones (both sides need to be pushed). After four clicks take effect, it will automatically shut down. The reset is now complete.Put the earphones into the charging compartment and take them out to pair them again.

Charging

You need to charge your device for 10 minutes before using it for the first time or after a long period of absence. When the battery of the earplug is low, it will issue "Please charge", which can put the earphone into the charging box. When the earphone is charging, the red light will be displayed, and the light will be off if the charge is slow.Please close the charging case when storing or charging the headphones. The charging case has a built-in battery, please use a type-c cable to charge it box, then connect it to a computing or other charger for charging, charging When charging, the indicator light flashes, and the fully charged indicator light is always on.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

