


LED WIRELESS CHARGING SPEAKER

XM-X69



▲ Warning:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Increase the separation between the equipment and receiver.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

Parameter

Working voltage: The battery voltage of 3.4V-4.2V will trigger a low battery alarm and shut down when it reaches around 3.4V

Battery parameters: 3.7V/1200MA-18650 battery

Charging time: About 2.5-3 hours

Features: Wireless, USB flash drive, T-card, audio, radio, white noise, Wireless charging, making and receiving calls, 12 lighting effects

Wireless transmission distance: 10-15 meters

Play duration: One hour at maximum volume

Charging voltage: 5V

Speaker: 4Ω5W

Wireless charging: 5-10W

Key Definition Explanation

Button 1: Long press to turn on/off, short press to adjust the lights

Button 2: White noise/FM/wireless, short press to pause. Connect to wireless and double-click button 2 to make phone calls

Button 3: Short press the white noise timer function, with a timer duration of 15/30/60 minutes

Button 4: Long press to decrease volume, short press to previous track

Button 5: Long press the volume to increase the maximum volume by U30, short press the song

Button 6: Short press to set the alarm hour area, the second short press to set the alarm minute area, and the third short press to confirm the alarm Clock opening and closing

Button 7: Short press to set clock hour area, second short press to set clock minute area

Safety Instructions:

1. Do not expose the product into the water or humid areas, such as bathrooms.
2. Please do not hit or drop the product hard to avoid manual damage.
3. When not in use for a long time, please turn off the power.