

中文

使用耳机

开机: 长按多功能按键约3秒, 耳机震动1秒, LED显示电量闪烁。

关机: 长按多功能按键约3秒, 耳机震动1秒, LED显示熄灭。

配对: 打开手机/设备上的无线设置, 选择耳机名称, 确认连接。

接听/挂断: 单击多功能按键。

拒接: 长按多功能按键约2秒。

播放/暂停: 单击多功能按键。

音乐音量/通话音量: 单击音量加/减键。

上下曲: 长按音量加/减键2秒。

语音切换: 开机未连接的状态下双击功能按键。

AI运动模式/普通模式: 耳机开机默认为普通模式, 3击MFB键切换。

氛围灯开启/关闭: 双击音量加/减键控制氛围灯开启/关闭。

一拖二配对: 正常连接第一台手机后, 关闭第一台的无线功能, 耳机进入待配对状态, 然后手动连接第二台手机, 再打开第一台手机无线功能耳机自动回连。

产品参数

无线版本V6.0

功能: 听音乐 多点连接 末号重拨 来电报号

充电时间约1.5小时

充电电压DC 5V

传输距离约10米

产品是由ABS材质构成

长时间高音量使用耳机可能会损伤你的听力

注意事项

需要注意的内容

● 不管任何时候都不要拆开你的耳机, 因为这样做可能损坏你的耳机或导致电池自燃。请把耳机带到指定的维修服务点维修, 或更换电池。

● 当你戴着耳机开车时, 请遵守你所在国家或地区的规定。

● 避免把耳机放在高温环境<高于50°C/122°F>, 比如放在太阳下暴晒, 这样会损坏耳机性能, 会减少电池寿命。

● 避免耳机浸于液体中, 因为这样做可能损坏你的耳机。

● 建议充电器提供的功率必须在无线电设备所需的最小[2.5]瓦和最大[5.5]瓦之间, 以达到最大充电速度。

Made in China

常见问题

我的耳机是否可用于笔记本电脑、台式计算机和PDA?	您的耳机可用于支持低无线版本和功能的设备。有关更精确的信息, 请参阅耳机规格。
通话时为什么听到杂音或干扰声音?	无线电话和无线网络设备一类的装置可能会产生干扰。通常听起来像静电噪声, 像降低干扰。请勿将耳机靠近其他使用或发出无线信号的设施。
耳机会干扰车上的电子设备, 收音机或计算机吗?	蓝牙耳机产生的功率远低于普通手机产生的功率。此外, 它发出的信号完全符合国际无线标准。因此, 您不必担心会干扰标准的消费电子产品设备。
其他无线耳机手机用户可以听到我的通话吗?	耳机与手机对接时, 仅会在这两个无线设备之间建立加密链接, 限制功率非常低, 无线信号远低于普通手机信号的功率, 因此第三方难以监控耳机所采用的无线技术。
在通话时为什么会听到回音?	调节耳机关闭, 或移开其他区域再试。
如何激活耳机?	用干的软布擦拭。
耳机无法充满电?	耳机可能未接好。请检查耳机接触是否正常, 然后重新连接并给耳机充电。
我无法使用中所述的部份功能。	可用的功能可能随连接的设备的不同而不同。若耳机一次连接两部设备, 部分功能可能不可用。

英语

--

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.