

ANC 降噪功能 无线耳机 使用说明书	产品参数 - 无线标准: V5.4 - 工作距离: 约10米 - 无线频率: 2.402-2.485GHz - 充电盒容量: 3.7V, 300mAh - 充电输入: DC 5V-500mA - 充电时间: 约2小时 - 耳机的可充电: 3.7V, 30mAh*2 - 播放续航: 约4.5小时 (80%音量) - 通话时间: 约4小时 (80%音量) - 充电盒给耳机充电次数: 约4次 - 充电续航: >300次 - 充电接口: Type-C 注: 本产品规格参数均为实验室测试数据, 不同环境使用会有所不同; 产品不断升级改进, 具体功能和产品图片可能与实际略有不同, 请以实物为准。	操作方式-耳机 - 开机: 打开充电盒盖, 耳机自动开机, 等待设备连接 - 充电盒关机: 双击背面按键选择关机 (背盖显示: 关机/退出/退出/设置) - 暂停/播放/上下曲: 中间圆形“触摸”键, 左图标上一曲, 右图标一曲 - 音量+/-: 左侧标减小音量, 右侧增加音量 - 接听电话: 单击左或右耳机 - 挂断电话: 双击左或右耳机 - 来电拒接: 长按左或右耳机2秒 - 下一曲: 三击右耳机 - 上一曲: 三击左耳机 - 音量-: 向下滑动左/右耳机减小音量 - 音量+: 向下滑动左/右耳机增加音量 - 触控操作: 长按左或右耳机2秒 - ANC降噪模式: 长按右耳机2秒, ANC ON-ANC OFF-透模式-循环操作 - 骨传导模式: (默认): 在播放模式下, 4级由左或右耳机切换并显示在屏幕上 - 清除配对设备列表: 同时6级单击左和右耳机 - 入耳检测: 安装默认采用,iOS默认开启, 5级可开启或关闭入耳检测	操作方式-充电盒彩屏 - 充电仓开机: 首次使用时需充电激活耳机, 最长充电需按6秒钟开机 - 充电仓关机: 双击背面按键选择关机 (背盖显示: 关机/退出/退出/设置) - 暂停/播放/上下曲: 中间圆形“触摸”键, 左图标上一曲, 右图标一曲 - 音量+/-: 左侧标减小音量, 右侧增加音量 - 均降降噪模式: 单击左/右图标, 可以切换音效 - 设置闹钟: 可以设置5分钟, 10分钟, 30分钟, 60分钟 - 语言切换: 单击左/右图标进行语言切换 - 设置闹钟提醒: 单击左/右图标可切换闹钟提醒 - 查找耳机: 单击L/R, 界面出现, 点击开始, 对应L/R耳机发出声音, 点击停止结束 - 时间设置: 可以手动更改的时间设置 (30/60/90/120/150/180分钟, 其耳机连接手机后, 时间同步设备时间) - 耳机充电提醒: 单击中间圆形按钮查看电量, 单击左/右图标切换至上或下一个提醒提醒 90/5 分钟并查看剩余电量的剩余(40%电量) - 如前定制的功能: 先开启手机上的提醒功能, 再双击耳机的上面面板, 即可控制手机提醒	充电 - 耳机电量低提醒: 当电池电压低于3.3V时, 每隔1分钟提醒一次 - 耳机充电: 耳机放入充电盒, 关闭盖子后自动充电, 约1.5小时充满 - 充电盒电量低提醒: 电量低于10%时, 充电仓面板显示红色 (充电仓电压低于3.4V时, 充电仓电量低, 提醒不显示) - 充电盒充电: 彩屏显示充电图标, 30秒后充电, 约1.5小时充满	注意事项 - 切勿使用具有腐蚀性的清洁剂清洁本产品; - 切勿将本产品加热或靠近火源, 如炉灶等; - 切勿将本产品长时间浸泡在水中, 避免潮湿; - 切勿将本产品置于火中, 避免发生火灾; - 请勿尝试拆开本产品或任何故障, 因为它并不包含任何维修组件; - 切勿在雨中或使用本产品; - 如果长期内不打算使用本产品, 请将其存放在干燥的环境中, 并每月至少为耳机充电一次以延长寿命, 避免危险的短路和火灾。 ※ 首次使用时需充电或长按背面按键6秒钟激活充电仓
[1]	[2]	[3]	[4]	[5]	[6]

ANC
Noise Reduction

Wireless Earphones
user manual

Main sound hole

Tuning hole

Ear cap

Touch area

Charging Port

MIC

LCD

Touch Screen

Product parameters

- Working range: V5.4
- Working range: bass-free 10 meters
- Wireless frequency: 2.402-2.48GHz
- Charging box capacity: 3.7V, 300mAh
- Charging input: DC 5V/500mA
- Charging time: about 2 hours
- Earphone bulk/battery life: 3.7V, 30mAh*2
- (Play music about 4.5 hours (80% volume)
- Talk time about 4 hours (80% volume)
- Number of times the charging case charges the earphones: About 4 times
- Charge and discharge cycle: >300 times
- Charging port: Type-C

Note: The specifications and parameters of this product are all laboratory test data, which will be different in different environments; the product is constantly being upgraded and improved, and the specific functions and product pictures may be slightly different from the actual product, please refer to the actual product.

Operation Method - Earphones

- Power on: Open the charging case cover, the headphones will automatically turn on, wait for Wireless connection
- Power off: Put the earphones into the charging case, And close the charging case cover
- Pairing mode: The earphones automatically enter pairing mode when turned on
- Pause/Play: Click on the left or right earphones
- Answer/Incoming calls: Click on the left or right earphones
- Hang up the phone: Double click on the left or right earphones
- Call rejection: Long press the left or right earphones for 2 seconds
- Next song: Three clicks on the right earphone
- Previous song: Three clicks on the left earphone
- Volume+ / Swipe down the left/right earphones to decrease volume
- Volume- / Slide up the left/right earphones to increase volume
- Voice assistant: Long press the left earphone for 2 seconds
- ANC noise reduction function: Long press the right earphone for 2 seconds, and the ANC ON/OFF - transparent mode will cycle through operation
- Music mode (default): In game mode, switch to music mode by 4 consecutive clicks on the left or right earphone
- Close, click on the left/right earphone simultaneously clicking on the music mode 6 times in a row
- Laser detection: Android defaults to off; iOS defaults to on, 5 consecutive clicks can turn on or off in ear detection

Operation method - charging case color screen

- Charging case Power on: When using it for the first time, it needs to be charged to activate the power on, or long press the button on the back for 6 seconds
- Charging case Power off: Double click the button on the back to select shutdown (interface display: Shutdown/hear/restore factory settings)
- Play/Pause/Play/Pause: Enter icon "Play" and "Pause", left icon for previous song, right icon for next song
- Volume+/-: Left icon reduces volume, right icon increases volume
- Equalizer interface: Click on the left or right icons to select sound effects
- Set alarm clock: Can be set for 5 minutes, 10 minutes, 30 minutes, 60 minutes
- Adjusting screen brightness: The left icon reduces brightness, while the right icon increases brightness (increasing brightness consumes more power)
- Language switching: Click on the left/right icon to switch languages
- Set lock screen wallpaper: Click on the left/right icon to replace the lock screen wallpaper
- Find headphones: Click on LR, the interface will appear, click on the corresponding LR headphones will emit sound, click on stop to end
- Time setting: You can manually change time and save it (if the charging case is not used for a long time, the time will be automatically updated when the headphones are connected to the phone)
- Video like function: Click on the head-shaped icon in the middle to like the video, click on the left/right icon to play the previous or next video
- Playback (iOS phones need to enable touch assist in the touch assist function)
- Photo control function: First, turn on the camera on the phone, then click on the take photo icon on the color screen to control the phone to take photos

charging

- Reminder of low headbony battery: When the battery voltage is below 3.3V, remind every 1 minute
- Earphone charging: Put the earphones into the charging case, close the lid, and automatically charge them. It takes about 1.5 hours to fully charge them
- Low battery reminder for charging case: When the battery level is below 10%, the charging case icon displays red (automatically shut down of the charging case, close the cover of the charging case will automatically shut down and the color screen will not display)
- Charging case charging: The color screen displays the charging icon, which goes off after 30 seconds and takes about 3 hours to fully charge

Universal wireless connection operation

1. Please put the wireless headset and mobile phone (or other connected devices) together;

2. Ensure that the earphones are charged, open the charging case cover, and the left and right earphones are connected to each other. The earphones can enter pairing mode;

3. Turn on the Wireless function of the user's mobile phone (or other Wireless device), and search or scan its At this time, the mobile phone will search for all nearby Wireless devices. Click the corresponding Wireless model name to connect. After successfully pairing and connecting, you can make a headset call, listening to songs, etc.

Considerations when connecting wirelessly

- Please control the distance between the wireless headset and the mobile phone (or other connected equipment) within 1 meter, the closer the better
- Open the charging case cover to connect;
- When connecting, make sure that the left and right earphones are interconnected and in the on state
- The charging box must have enough power: If the headphones cannot be turned on when the cover is opened, put the headphones in the charging box, close the cover of the charging case and plug in the charger to charge for at least one hour;

Precautions

- Never use cosmetic cleaning agents to clean this product.
- Do not allow this product to be heated or come into contact with fire sources, such as cooking stoves.
- Do not expose this product to direct sunlight for a long time to avoid high temperature;
- Do not dispose of this product in fire to avoid explosion;
- Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components;
- Do not use this product in the rain.
- If you do not plan to use this product for a long period of time, please store it in a dry environment And charge the headset at least about one month to extend the life and avoid extreme temperatures and dust.

※ First use requires charging or long pressing the button for 6 seconds to activate the charging case

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction