


S36

EN



User Manual

Please read the manual before use.

FCC ID: 2BGX7-S36

What include



Charging Case x1



Earbuds x2



Earcaps x3
(M size is on earbuds)





USB-C Charging

Connect




1. When you use it for the first time to take out the earphone from the charging box, the indicator light on the earphone will flash and wait for 10 seconds.
2. Enable phone bluetooth function.
3. Locate device bluetooth name "S36" on your phone to pair, the indication lights will turn off when connected successfully.


Touch Control



Play/Pause




Switch Song




Adjust Volume




Voice Assistant




Answer/Hang up



Reject Call



Power on



Power off

X1: Tap once. X2: Tap twice quickly LP: Long press
X3: Tap thrice quickly. 3S: Press and hold for 3 seconds.
X1 3S: Tap once first then quickly press and hold for 3 seconds.

Troubleshooting

1. Connected while no sound:

Long press the right earphone to increase the volume

2. One earbud can not be charged:

Clean the charging contacts of the earbud and its charging box

3. The charging box can not be charged:

Ensure the charging cable is normal and there is no alien or over dirt in the type-C port

4. Earbuds can not be turned off:

1. Directly put the earbuds back to its charging case
2. Tap any earbud once then quickly press and hold for 3S

5. Earbuds can not pair with phone:

Turn off the bluetooth of mobile phone first. Take the earbuds out of charging case and wait 15S before the 2 earbuds auto-pair themselves first. Then, turn on the bluetooth of phone to connect

6. Earbuds can not power off in box:

When the battery of charging box is low, the earbuds will not auto power off when put back in the box. Pls charge the box timely

Safety instructions

1. Keep the earbuds away from children under 3 yrs to avoid swallowing by mistake.
2. Never listen to music at high volumes in case to damage your listening.
3. Keep the product away from extremely hot and cold environments. It will damage the battery and circuit.
4. Only charge your device from 5V USB ports in your phones, laptops or PCs.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment



Please clean the charging contacts of the earbuds and charging case frequently to avoid charging failures.