


4-IN-1

Speaker Phone Stand Wireless Charger LED Night Light




User Manual for MI-BT144

Included:

- 1 x Bluetooth® Speaker 4-in-1 Wireless Charger
- 1 x USB Type-C Charging Cable (80cm length)
- 1 x User Manual

Detailed Instructions and Diagrams



Technical Specifications:

- Dimensions: 95mm x 97mm x 161mm (Width x Depth x Height)
- Power Input: USB Powered (5V 1A ~ 9V 2A max)
- Speaker Output Power: 3W (Mono)
- Bluetooth® Version: 5.3 (IC Model: Jieli 6965A)
- Bluetooth® Range: Up to 10 meters
- Charging Port: USB Type-C
- Wireless Charging Output: 15W / 10W / 7.5W / 5W
- Wireless Charging Adapter Requirement: 9V/2A or 5V/3A adapter (sold separately)
- Indicators: RGB Lights + Charging Indicator LED

Charging Instructions:

- Compatible Devices: This product is compatible with smartphones and devices that support wireless charging standards of 15W, 10W, 7.5W, or 5W.

Power Connection:

- Connect one end of the provided USB Type-C cable to the charging port on the product.
- Connect the other end to a compatible power adapter (sold separately). The adapter MUST provide 9V/2A for higher charging outputs (10W/15W) or 5V/1A (5W).
- Plug the adapter into a standard wall outlet.
- Press the power button on the back of the product to turn it on.

Wireless Charging:

- Place your device centered on the designated wireless charging area of the product.
- Ensure no metal objects or thick cases are between the device and the charging surface.

Indicator & RGB Lights:

- Charging Indicator LED: This light will illuminate to indicate the charger is powered and actively charging a correctly placed compatible device.
- The product features RGB lights. These lights are designed to provide relaxing ambient lighting.
- Use the LED light button to activate/deactivate the lighting feature.

Bluetooth® Function Instructions:

- Power On: Ensure the product is connected to power via the USB Type-C cable and compatible adapter.
- Pairing Mode: The product uses "Easy Mode Pairing". When powered on and not already connected, it should automatically enter pairing mode.

Device Connection:

- On your Bluetooth®-enabled audio device (e.g., smartphone, tablet), go to the Bluetooth® settings menu.
- Scan for available devices. Select the "MERKURY BT144" device from the list.
- If prompted, accept the pairing request. A confirmation sound may play.
- Playing Audio: Once paired, audio played on your connected device will output through the speaker.
- Disconnecting/Reconnecting: Turn off Bluetooth® on your device or power off the speaker to disconnect. When both are powered on and in range, they should automatically reconnect.

Note: This product does NOT support BLE Pairing, AP Mode Pairing, TWS (pairing two speakers), or outputting sound to Bluetooth® headsets.

Troubleshooting:

- 1) Speaker Not Powering On:
 - Ensure the USB Type-C cable is securely connected to both the product and a compatible power adapter plugged into a working outlet.
 - Verify the power adapter meets the required specifications (9V/2A or 5V/1A).
 - 2) Wireless Charging Not Working:
 - Confirm your phone/device supports wireless charging.
 - Ensure the device is centered on the charging area.
 - Check the Charging Indicator LED for status.
 - 3) Bluetooth® Pairing Fails:
 - Ensure the speaker is powered on and in range (<10m).
 - Confirm the speaker is in pairing mode (may require turning it off/on if not found).
 - Check your audio device's Bluetooth® settings is on and enabled.
 - Remove the speaker from your device's Bluetooth® paired devices list and retry pairing.
 - 4) No Sound from Speaker:
 - Ensure Bluetooth® connection is active.
 - Check the audio source is playing.
 - Check the volume on your Bluetooth® Enabled Audio device.
- Precautions:**
- Indoor use ONLY.
 - You MUST use a compatible power adapter (9V/2A or 5V/1A) for the wireless charging function.
 - Keep the product away from water, liquids, and excessive humidity. Do not use in bathrooms or near sinks.
 - Do not cover the product while in use, especially during wireless charging, as this may cause overheating. Place it on a stable, flat, hard surface in a well-ventilated area.
 - To clean, gently wipe the product surface with a dry or slightly damp cloth. Do not use harsh chemicals to clean the product or submerge the product.

Technical Support:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, you can contact our technical support representatives and they will assist you with any questions you might have. For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support:

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Merkury Innovations

45 Broadway, 3rd Fl
New York, New York 10006
www.merkuryinnovations.com
E-mail: support@merkuryinnovations.com

©2025 Merkury Innovations, LLC.

To explore our full selection of products, visit us at: www.merkuryinnovations.com
iPhone® is a trademark of Apple Inc., registered in the U.S. and other countries.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc.
Qi is a trademark of Wireless Power Consortium.
The illustrated product and specifications may differ slightly from those supplied.
All other trademarks and trade names are those of their respective owners.

Made in China

* IMPORTANT Please read before using this product