

EMPEZAR LIFEPHONE Simple					
EMPEZAR LIFEPHONE Simple					
1- Inserte la tarjeta SIM y la memoria tarjeta		2- Cargue la batería y cambie el teléfono encendido	3- Precauciones de la FCC	6- Medidas Correctivas	9- Uso Corporal
1- Inserte la tarjeta SIM y la memoria tarjeta Inserte la tarjeta SIM y la memoria tarjeta en la ranura SIM y la ranura de memoria. Asegurese de que la tarjeta esté correctamente insertada y que el contacto esté limpio. Si la tarjeta no funciona, intente limpiarla con un paño suave y seco. ●Importante: El teléfono no debe ser usado en áreas donde se prohíba el uso de dispositivos inalámbricos, como en aviones, hospitales, lugares de trabajo o áreas de riesgo. El uso de dispositivos inalámbricos en estas áreas puede interferir con los sistemas de comunicación y causar lesiones o daños materiales. 2- Cargue la batería y cambie el teléfono encendido Conecte el cargador al puerto de carga y asegurese de que el cable esté correctamente conectado. Encienda el teléfono presionando el botón de encendido. Si el teléfono no se enciende, asegurese de que la batería esté correctamente insertada y cargada. ●Importante: El teléfono no debe ser usado en áreas donde se prohíba el uso de dispositivos inalámbricos, como en aviones, hospitales, lugares de trabajo o áreas de riesgo. El uso de dispositivos inalámbricos en estas áreas puede interferir con los sistemas de comunicación y causar lesiones o daños materiales. 3- Precauciones de la FCC Este dispositivo cumple con la Parte 15 de la Norma FCC. Si se usa en un país que no sea Estados Unidos, asegurese de que el dispositivo cumpla con las regulaciones locales. El uso de dispositivos inalámbricos en áreas donde se prohíba el uso de dispositivos inalámbricos puede causar interferencias y daños materiales. 4- Modificaciones Cualquier cambio o modificación no aprobada por el fabricante puede anular la garantía del dispositivo. El uso de dispositivos inalámbricos en áreas donde se prohíba el uso de dispositivos inalámbricos puede causar interferencias y daños materiales. 5- Información para el Usuario Este equipo ha sido diseñado para cumplir con las normas de la FCC. El uso de dispositivos inalámbricos en áreas donde se prohíba el uso de dispositivos inalámbricos puede causar interferencias y daños materiales. El uso de dispositivos inalámbricos en áreas donde se prohíba el uso de dispositivos inalámbricos puede causar interferencias y daños materiales.					
6- Medidas Correctivas Si el teléfono no funciona correctamente, asegurese de que la batería esté correctamente cargada y que el teléfono esté correctamente encendido. Si el problema persiste, intente reiniciar el teléfono. Si el problema persiste, contacte al servicio al cliente. 7- Información de Tasa de Absorción Específica (SAR) Este teléfono cumple con la tasa de absorción específica (SAR) de la FCC. El uso de dispositivos inalámbricos en áreas donde se prohíba el uso de dispositivos inalámbricos puede causar interferencias y daños materiales. 8- Límite SAR El límite SAR de este teléfono es de 1.6 W/kg. El uso de dispositivos inalámbricos en áreas donde se prohíba el uso de dispositivos inalámbricos puede causar interferencias y daños materiales.					
9- Uso Corporal Este teléfono cumple con la norma de la FCC para el uso corporal. El uso de dispositivos inalámbricos en áreas donde se prohíba el uso de dispositivos inalámbricos puede causar interferencias y daños materiales. Powered by Android™ Android es una marca registrada de Google LLC.					

Get Started LIFEPHONE Simple				
Get Started LIFEPHONE Simple				
EN	1- Insert the SIM and memory card Insert the SIM and memory card into the SIM and memory slots. Make sure the card is correctly inserted and the contact is clean. If the card does not work, try cleaning it with a soft, dry cloth. ●Important: The phone should not be used in areas where the use of wireless devices is prohibited, such as on airplanes, in hospitals, at work, or in areas of risk. The use of wireless devices in these areas can interfere with communication systems and cause injury or property damage. 2- Charge the battery and switch the phone on Plug a compatible charger into a wall outlet and connect the USB-C cable. You can also charge your phone from a computer with a USB cable. Turn the phone on by pressing the power button. If the battery is completely discharged, it may take several minutes before the charging indicator is displayed. ●Important: The phone should not be used in areas where the use of wireless devices is prohibited, such as on airplanes, in hospitals, at work, or in areas of risk. The use of wireless devices in these areas can interfere with communication systems and cause injury or property damage. 3- FCC Precautions This device complies with Part 15 of the FCC rules. If you use it in a country that is not the United States, you must make sure that it complies with the country's rules. The use of wireless devices in areas where the use of wireless devices is prohibited can cause interference and damage to property. 4- Modifications Any changes or modifications not approved by the manufacturer may void the warranty of the device. The use of wireless devices in areas where the use of wireless devices is prohibited can cause interference and damage to property. 5- User Information This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. The actual SAR value of the device can vary depending on many factors, including the position of the antenna and the position of the user's head.	6- Corrective Measures If the equipment does not work properly, make sure the battery is fully charged and that the phone is correctly inserted. If the problem persists, try restarting the phone. If the problem persists, contact the service center. 7- Specific Absorption Rate (SAR) Information This phone complies with the SAR limits of the FCC. The use of wireless devices in areas where the use of wireless devices is prohibited can cause interference and damage to property. 8- SAR Limit The SAR limit of this phone is 1.6 W/kg. The use of wireless devices in areas where the use of wireless devices is prohibited can cause interference and damage to property.	9- Body Use This phone complies with the FCC rules for body use. The use of wireless devices in areas where the use of wireless devices is prohibited can cause interference and damage to property. Powered by Android™ Android is a trademark of Google LLC.	