

[illegible]

Yanmai
奕音

Packing List

Receiver x1
Transmitter x1
Belt x1
Charging Cable x1
Manual x1

Function Introduce

• Transmitter

1. External microphone 3.5mm jack: connect microphone
2. Working indicator light:
1) Voice amplify mode: When connected, the blue light is always on.
When there is no connection, the blue light flashes.
2) Bluetooth mode: When connected, the green light remains on.
When there is no connection, the green light flashes.
3. Speaker: Emits a "beep" sound when low power alarm is triggered.
4. Volume up key:
1) Voice amplify mode: Short press to increase volume, long press is invalid.
2) Bluetooth mode: Short press to increase receiver volume, long press for the next song.
5. Volume down button:
1) Voice amplify mode: Short press to decrease volume, long press is invalid.
2) Bluetooth mode: Short press to decrease receiver volume, long press for the previous song.
6. Power on/off button (mode switch button):
1) Short press to switch between voice amplify mode/Bluetooth mode.
2) Long press to turn on/off.
7. Charging Indicator: When charging single light flashing, when charge full all 4 indicators light on.
8. Type-C interface: 1) Charging Port 2) Digital Audio Interface
9. Clamp
10. Belt buckle position
11. Antiskid Foot Pad

• Receiver

1. On-Off/Connecting Button: Long press the button (After turning on show current power level, then enter pairing mode after 3 seconds. Press the button 3 times continuous to re-enter pairing mode.
2. Mute button: turn on/off the sound pickup
3. Status/Power Indicator:
1) Paired: Show current power level: As the battery is depleted, the lights turn off one by one. When there is a power outage, the red light flashes.
2) No Pairing: 4 indicators all flashing.

Receiver description

1. External microphone 3.5mm jack: connect microphone
2. Working indicator light:
1) Voice amplify mode: When connected, the blue light is always on.
When there is no connection, the blue light flashes.
2) Bluetooth mode: When connected, the green light remains on.
When there is no connection, the green light flashes.
3. Speaker: Emits a "beep" sound when low power alarm is triggered.
4. Volume up key:
1) Voice amplify mode: Short press to increase volume, long press is invalid.
2) Bluetooth mode: Short press to increase receiver volume, long press for the next song.
5. Volume down button:
1) Voice amplify mode: Short press to decrease volume, long press is invalid.
2) Bluetooth mode: Short press to decrease receiver volume, long press for the previous song.
6. Power on/off button (mode switch button):
1) Short press to switch between voice amplify mode/Bluetooth mode.
2) Long press to turn on/off.
7. Charging Indicator: When charging single light flashing, when charge full all 4 indicators light on.
8. Type-C interface: 1) Charging Port 2) Digital Audio Interface
9. Clamp
10. Belt buckle position
11. Antiskid Foot Pad

Description of the transmitter

1. On-Off/Connecting Button: Long press the button (After turning on show current power level, then enter pairing mode after 3 seconds. Press the button 3 times continuous to re-enter pairing mode.
2. Mute button: turn on/off the sound pickup
3. Status/Power Indicator:
1) Paired: Show current power level: As the battery is depleted, the lights turn off one by one. When there is a power outage, the red light flashes.
2) No Pairing: 4 indicators all flashing.

Operation Method

Voice amplify mode connection method: Turn on the receiver and transmitter, and the receiver and transmitter will pair automatically.
Bluetooth mode connection method: Turn on the receiver, press the power button again to switch Bluetooth mode, and then turn on again.
Mobile Bluetooth search for model "K3" and connect for pairing.

Common Problem

Question: Single microphone cannot connect.
Answer: 1. Please ensure that the battery is sufficient.
2. Ensure you using the amplification mode.
Question: The second microphone cannot be connected for the dual microphone.
Answer: Please turn off and restart first, connect the second disconnected microphone first, and then turn on and connect the first microphone.
Question: Do I need to connect every time when I turn on the device.
Answer: Automatic connection upon startup. If unable to connect automatically, please try several more times.
Question: Echo and latency issues.
Answer: The volume or receiver can be adjusted according to the size of the space, keep the microphone two meters away from the receiver and these problems can be solved.
Question: The light stays on and the connection is successful, but there is no sound.
Answer: 1. Please speak in amplification mode.
2. Please check the mute button. If mute please short press the mute button of the transmitter.

Specifications

• Receiver

Charging Current	DC5V-900mA
Charging Time	About 3 hours
Bluetooth Version	5.3
Speaker	4Ω/10W
Using Time	More than 1 hours
Battery Capacity	2500mAh
Transmission Method	2.4G
Frequency Response	100Hz-13KHz

• Transmitter

Charging Current	DC5V-200mA
Charging Time	About 1.5 hours
S/N	±85dB
Directivity	Omnidirectional
Using Time	About 10 hours
Battery Capacity	300mAh
Sensitivity	-50±3dB
Receiving Distance	≥20M

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Product: SHENZHEN QIYIN ELECTRONIC CO., LTD.
Manufacturer: HUIZHOU YINBA TECHNOLOGY CO., LTD.
Manufacturing Add: Qiying Industrial Park,shiataun, Changning Town, Boluo County, Huizhou City, Guangdong, China
www.hkyanmai.com

CE FC RoHS

Models:K5 | Made in China | Executive Standard:GB4943.1-2022

Patent# ZL 202530129289.6
Patent# ZL 202530152007.8