

75*75mm

LX-21pro //



用户手册

User manual

产品规格

耳机配名称	LX-21pro	产品类型	夹耳式
芯片版本	V5.4	播放时长	约4-5H
喇叭尺寸	φ13	频率响应	20HZ-20kHz
耳机电池容量	35mAh	充电仓电池容量	400mAh
充电方式	顶针触点	充电时间	0.5-1H

耳机按键功能

开/关机	开机:长按触摸键3秒 / 关机:长按触摸键5秒,主/副耳
播放/暂停	单击左/右耳:播放/暂停音乐
切换上/下曲	上一曲:双击左声道切换歌曲 / 下一曲:双击右声道切换歌曲
音量调节	音量加:三击右声道加音量 / 音量减:三击左声道减音量
语音助手	长按左/右声道唤醒SIRI
来电状态	接听/挂断:单击接听,通话中单击挂断电话拒接来电:长按左/右声道2秒拒接电话
切换中英文	未连接手机双击功能键即可切换中英文

指示灯展示

耳机配对	1. 请将蓝牙耳机和手机(或连接设备)距离控制在1m范围内,距离越近越好。 2. 充电仓拿出耳机,取出耳机自动开机,确认进入配对模式。 3. 打开手机或其他所需连接的设备的蓝牙搜索功能,手机上会显示出蓝牙名称“LX-21”。 4. 选择蓝牙名称“LX-21”(部分手机需输入“0000”作为配对密码)会自动与手机连接。 5. 蓝牙耳机的配对时间为5分钟,超时自动关机。如还需要连接手机,请重新按照1至4步骤操作,直到蓝牙连接成功。
耳机指示灯	1. 开机:蓝色指示灯闪烁3次; 2. 关机:红色指示灯闪烁3次; 3. 配对状态:红蓝灯交替闪烁,副耳灯灭; 4. 指示灯灭:低电量状态、连接成功、音乐状态、通话状态。

禁止 ⚠

- 1. 禁止拆解、撞击、挤压电池或投入火中、插入异物,以免引起电池漏液、过热起火或爆炸。
- 2. 本设备并非玩具,儿童应在成人监护下使用本设备配件要求。
- 3. 若出现严重鼓胀禁止继续使用。
- 4. 禁止置于高温环境中,远离火源。
- 5. 电池浸水或其它液体中后禁止使用。

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

LX-21pro //



User manual

Product specifications

Headphone Pairing Name	LX-21pro	Type of product	Clip-on Earbuds
Chip version	V5.4	Duration of playback	4-5H
Size of horn	φ13	Frequency response	20Hz-20kHz
Headphone battery capacity	35mAh	Charging bay battery capacity	400mAh
Mode of charging	Thimble contact	Charging time	0.5-1H

Headphone button function

Turn on/off the computer	Power on: Long press the touch key for 3 seconds/ Power Off: long press the touch key for 5 seconds, main/secondary ear
Play/pause	Click left/right ear: Play/Pause music
Toggle up/down	Previous track: Double click left track to switch song/ Next track: Double click right track to switch song
Volume adjustment	Volume Up: Three clicks on right channel Volume up/ Volume down: three clicks on left channel volume down
Voice assistant	Long press the left/right channel to wake up SIRI
Incoming call status	Answer/Hang up: Click answer, click Hang up during the call to reject the call: long press the left/right channel for 2 seconds to reject the call
Language conversion	If you are not connected, double-click the function button to switch between Chinese and English

Indicator light display

Bluetooth pairing	1. Please control the distance between Bluetooth headset and mobile phone (or connected device) within 1m. The closer the distance, the better. 2. Take out the headset in the charging bin, take out the headset and turn it on automatically, and confirm to enter the pairing mode. 3. Open the Bluetooth search function of your phone or other device you want to connect to. The Bluetooth name "LX-21" will be displayed on your phone. 4. Select the Bluetooth name "LX-21" (some mobile phones need to enter "0000" as the pairing password) and connect with the mobile phone automatically. 5. The pairing time of the Bluetooth headset is 5 minutes, and the device will be automatically shut down when the timeout is expired. If you still need to connect your phone, follow steps 1 to 4 again until the Bluetooth connection is successful.
Headphone indicator light	1. Boot: the blue indicator light flashes 3 times; 2. Shutdown: red indicator flashing 3 times; 3. Pairing state: red and blue lights flashing alternately, secondary ear lights off; 4. Indicator light off: low power state, successful connection, music state, call state.

Prohibition ⚠

- 1. It is prohibited to disassemble, impact, squeeze the battery, or put it into fire or insert foreign objects to avoid battery leakage, overheating, fire or explosion.
- 2. This device is not a toy, and children should use its accessories under adult supervision.
- 3. Do not continue to use if severe swelling occurs.
- 4. Do not place in high temperature environments and keep away from sources of fire.
- 5. Do not use batteries immersed in water or other liquids.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

75*75mm